

Sigma-7 400 \vee

Product Catalog



Quick. Fast. Reliable.

Fa

Juni

Contents

Rotary Servomotors

SGM7J	18
SGM7A	29
SGM7G	47
Linear Servomotors	
SGLF (Models with F-Type Iron Cores)	66
SERVOPACKs	
SGD7S Single Axis	88
SGD7W Dual Axis	98
Option Modules	
Option Module Safety	108
Option Module Feedback	112
Cables & Peripherv	

Cables & Periphery

Cables for Rotary Servomotors	122
Cables for Linear Servomotors	126
Serial Converter Units	129
Cables and Connectors for SERVOPACKs	134
Periphery	141

Appendix

Capacity Selection for Servomotors	154
Capacity Selection for Regenerative Resistors	161
International Standards	162
Warranty	163

Seven reasons for Sigma-7

The Sigma Series of Servo Drives has evolved into the Sigma-7 Servo Drives, which provides you with the ultimate experience in seven key areas and delivers the optimal solution that only YASKAWA can offer.



Comprehensive motor and amplifier power range

Wide power range

- Very compact motors from 50 W to 15 kW
- Linear motors iron core and ironless with a peak force up to 7,560 N

Savings through performance

Lower production costs

- Speed loop bandwidth of 3.1 kHz
- Shorter settling time, reduced positioning time, higher throughput

No additional cooling necessary

• Ambient temperature -5 – 55 °C (max. 60 °C with derating)

Energy savings and higher productivity

- High peak torque, fast acceleration, no amplifier oversizing
- Lightweight mechanics

Higher performance

- Overload 350 % for 3 5 seconds
- High peak torque, fast acceleration





Safety features

Smooth integration of mandatory legal safety standards

- The STO function is implemented by default in all Sigma-7 series servo amplifiers
- Build safer machines Sigma-7 satisfies the requirements of SIL 3 and PL-e
- The safety functions SS1, SS2 and SLS can be integrated by using the safety module



High efficiency

Very low heat generation

- Optimized magnetic circuit improves motor efficiency
- Improved motor efficiency reduces heat generation by about 20 %



High accuracy

Next level 24-bit absolute encoder for maximum accuracy

• Resolution of 16 million pulses per revolution for extremely precise positioning



Impressive system performance

Very high precision teamed up with fast, smooth operation

- Ripple compensation for highest demands in smoothness and dynamics
- Even for machines for which speed loop gains cannot be set high



Outstanding reliability

Even more reliability for your production

- More than 12 million servo systems in the field
- Improved machine reliability, reduced service and maintenance costs, less downtime



264

CHARGE

244

NO

Servomotors



SERVOPACKS

Option Modules



Sigma-7 Series Combinations

Combination of SERVOPACKs and Option Modules

	Option Module		
SERVOPACK Model	Satety Module	Feedback Option/Fully Closed Loop Module (SGDV-OF□□□A)	
Single-axis EtherCAT Communications Reference Type (SGD7S-DDDA0BDDF64)	0	0	
Single-axis MECHATROLINK III Communications Reference Type (SGD7S-DDD30BDDDF64)	0	0	
Dual-axis EtherCAT Communications Reference Type (SGD7W-DDDA0BDD)	O*	_	
Dual-axis MECHATROLINK III Communications Reference Type (SGD7W-DDD30BDDD)	0*	-	

O : Possible

- : Not Possible

*Only for one axis

Combination of Rotary Servomotors and SERVOPACKs


		J				
Rotary servomotor model			SERVOPACK mod	SERVOPACK model		
		Rated output	SGD7S-	SGD7W-		
	SGM7J-02D□F	200 W	1000	2R6D*		
SGM7J	SGM7J-04D□F	400 W	1R9D	2R6D* oder 5R4D*		
(Medium inertia, high speed) 3.000 min ⁻¹	SGM7J-08D□F	750 W	3R5D	2R6D oder 5R4D*		
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	SGM7J-15DDF	1.5 kW	5R4D	5R4D		
	SGM7A-02D□F	200 W	1000	2R6D*		
	SGM7A-04D□F	400 W	1R9D	2R6D* oder 5R4D*		
	SGM7A-08D□F	750 W	3R5D	2R6D oder 5R4D*		
	SGM7A-10DDF	1.0 kW	5040	5R4D*		
SGM7A	SGM7A-15DDF	1.5 kW	5R4D	5R4D		
Low inertia, high speed)	SGM7A-20D□F	2.0 kW	8R4D			
3,000 min ⁻¹	SGM7A-25D□F	2.5 kW	1000			
	SGM7A-30D□F	3.0 kW	120D			
	SGM7A-40D□F	4.0 kW	1700	_		
	SGM7A-50D□F	5.0 kW	170D			
	SGM7A-70D□F	7.0 kW	260D			
	SGM7G-05D□F	450 W	1R9D	2R6D* oder 5R4D*		
	SGM7G-09D□F	850 W	3R5D	5R4D*		
	SGM7G-13D□F	1.3 kW	5R4D	5R4D		
GM7G	SGM7G-20D□F	1.8 kW	8R4D			
Standard models Vledium inertia,	SGM7G-30D□F	2.9 kW	120D			
.ow speed, high torque)	SGM7G-44D□F	4.4 kW	170D			
,500 min ⁻¹	SGM7G-55D□F	5.5 kW	210D	_		
	SGM7G-75D□F	7.5 kW	260D			
	SGM7G-1AD□F	11.0 kW	280D			
	SGM7G-1ED□F	15.0 kW	370D			
	SGM7G-05D□R	450 W	3R5D	2R6D oder 5R4D*		
SGM7G	SGM7G-09D□R	850 W	5R4D	5R4D		
High-speed models Medium inertia,	SGM7G-13D□R	1.3 kW	8R4D			
High speed, high torque)	SGM7G-20D□R	1.8 kW	120D	_		
1,500 min ⁻¹	SGM7G-30D□R	2.9 kW	170D			
	SGM7G-44D□R	4.4 kW	210D			

* If you use this combination, performance may not be as good, e.g., the control gain may not increase, in comparison with using a Sigma-7 single axis SERVOPACK.

Combination of Linear Servomotors and SERVOPACKs

Linear Servomotor Model		Rated Output Force	SERVOPACK Model		
Linear Servomotor Model	Linear Servomotor Moder		SGD7S-	SGD7W-	
	SGLFW2-30D070A	45 N	1R9D	2R6D	
SGLFW2 F-Type with iron core	SGLFW2-30D120A	90 N	1R9D	2R6D	
	SGLFW2-30D230A	180 N	1R9D	2R6D	
	SGLFW2-45D200A	280 N	3R5D	2R6D	
	SGLFW2-45D380A	560 N	5R4D	5R4D	
			8R4D	-	
	SGLFW2-90D200A	560 N	5R4D	-	
	SGLFW2-90D380A	1,120N	120D	-	
	SGLFW2-90D560A	1,680 N	170D	-	
	SGLFW2-1DD380A	1,680 N	170D	-	
	SGLFW2-1DD560A	2,520N	260D	-	


SGD7S SERVOPACK and Rotary Servomotor




8

System Configuration Examples

SGD7S SERVOPACK and Linear Servomotor




SGD7W SERVOPACK and Rotary Servomotor




System Configuration Examples

SGD7W SERVOPACK and Linear Servomotor



Model Designations

Rotary Servomotors



Bolded options are considered standard

warehouse products

The shaft diameter for 1.3 kW Servomotors is 22 mm.

*2 Available up to 4.4 kW.

YASKAWA SIGMA-7 | CATALOG

SERVOPACKs

Single Axis Amplifier

SGD7S	-	1R9	D	AO	В	000	F64
Sigma-7 Series Sigma-7S Models		 1st 3rd	4th	5th + 6th	7th	8th 10th	11th 13th digit

1st 3rd digit - Maximum Applicable Motor Capacity					
Specification					
phase, 400 V					
0.5 kW					
1.0 kW					
1.5 kW					
2.0 kW					
3.0 kW					
5.0 kW					
6.0 kW					
7.5kW					
11.0 kW					
15.0 kW					

Code	Specification
D	400 V AC
5th + 6	oth digit - Interface
Code	Specification
A0	EtherCAT communication reference
30	MECHATROLINK-III *, RJ45 communication reference
7th dig	it - Design Revision Order
в	Standard Model

4th digit - Voltage

8th 10th digit - Hardware Options Specifications				
Code	Specification	Applicable Models		
000	Without Options	All models		
026	With relay for holding brake	All models		

11th	13th digit - FT/EX Specification
Code	Specification
F64	Zone table
	otions are considered standard e products.

Dual Axis Amplifier

SGD7W	-	2R6	D	AO	В	-
Sigma-7 Series Sigma-7W Models		1st 3rd	4th	5th + 6th	7th	8th

	1st 3rd digit - Maximum Applicable Motor Capacity					
Code	Specification					
Three-	phase, 400 V					
2R6	2 × 0.75 kW					
5R4	2 × 1.5 kW					

4th digit - Voltage				
Code	Specification			
D	400 V AC			

5th + 6th digit - Interface					
Code	Specification				
A0	EtherCAT communication reference				
30	MECHATROLINK-III, RJ45 communication reference				
7th dig	jit - Design Revision Order				

iait -	Desian	Revision	Order	

10th digit

Standard Model В

	8th 10th digit - Hardware Options Specifications					
Code	Specification	Applicable Models				
-	Without Options	All models				
026	With relay for holding brake	All models				

Bolded options are considered standard warehouse products.

Cables & Periphery

Model Designations

Linear Servomotors with F-Type Iron Cores

Mov S (ving Co G L		W2	_	30	D	070	А	S	1	Е	
	7 Series Servomotors:	1st	2nd		3rd + 4t	h 5th	 6th - 8th	9th	 10th	11th	 12th	digit
1st dig Code	it - Servomo Specificati	-	уре		5th digi Voltage		ver Supply	/		10th d Senso		ification
F	With F-type		ore		Code	Specif	fication			Code	Speci	ification
2nd dig	git -				_	400 VA				Т		ut polarity sensor, nermal protector
Code	Coil/Magn Specificati		vay		6th 8t Length		: - /ing Coil			S		oolarity sensor and al protector
W2	Moving Coi				Code	Speci	fication					
3rd + 4	th digit - Ma	agnet	Height		070	70 mm	ı			11th d	igit - O	ptions
Code	Specificati				120	125 m	m			Code		ng Method
30	30 mm				200	205 m				1	Self-c	ooled
45	45 mm				230	230 m				L	Water	-cooled*
90	90 mm				380	384 m	m			4.046 -1		
1D	135 mm				9th digi	t - Des	ign Revis	ion			igit - O	•
					Order					Code		ection
					Code	Specif	fication			Е	Metal (Phoe	round connector
					А	Standa	ard Model				(1106	

A Standard Model

* Contact your YASKAWA representative for information on water-cooled model.

Magnetic Way

S (3	L	F	M2	- 30	270	А	
Sigma- Linear S		— eries omotors:	1st	2nd	3rd + 4th	5th - 7th	8th	digit
dist allo		Servomo	tor T	upo.	5th	7th digit -		
				ype			etic W	av
Code	Sp	ecificatio	on		Lengt	n of Magne		ay
	Sp		on			n of Magne		ay
Code F 2nd dig	Sp Wi git -	ecification th F-type	on iron c	ore	Lengt Code	n of Magne Specific		ay
Code F 2nd dig	Sp Wi git - g Co	ecification th F-type bil/Magne	on iron c etic W	ore	Lengtl Code 270	n of Magne Specific 270 mm		ay
Code F 2nd dig	Sp Wi git - g Co	ecification th F-type	on iron c etic W	ore	Lengt Code 270 306	n of Magne Specific 270 mm 306 mm		ay

1 1 12	magnotio may
3rd + 4	th digit - Magnet Height
Code	Specification
30	30 mm
45	45 mm
90	90 mm

135 mm

1D

Code	Specification
270	270 mm
306	306 mm
450	450 mm
510	510 mm
630	630 mm
714	714 mm

Design	Revision Order
Code	Specification
A	Standard Model

Note: This information is provided to explain model numbers. It is not meant to imply that models are available for all combinations of codes.

Related Documents

Related Documents

The documents that are related to Sigma-7 series AC Servo Drives are shown in the following table. Refer to these documents as required.

Catalog Name	Document Name	Description of Desumant		
(Catalog No.)	(Document No.)	Description of Document		
	Sigma-7 Series Product Manual			
	Sigma-7 Single Axis SERVOPACK with 400V-Input Power and EtherCAT (CoE) Communications References Product Manual (SIEP S800001 80□)			
	Sigma-7 Single Axis SERVOPACK with 400V-Input Power and MECHATROLINK III Communications References Product Manual (SIEP S800002 14□)	Provide detailed information on selecting Sigma-7 Series SERVOPACKs and information on installing, connecting, setting, performing		
	Sigma-7 Dual Axis SERVOPACK with 400V-Input Power and EtherCAT (CoE) Communications References Product Manual (SIEP S800002 19□)	trial operation for, tuning, and monitoring the Servo Drives.		
	Sigma-7 Dual Axis SERVOPACK with 400V-Input Power and MECHATROLINK III Communications References Product Manual (SIEP S800002 20□)			
Sigma-7 Series Catalog AC Servo Drives Sigma-7 Series (YEU_MuC_Sigma7_400V_Cat_EN_v4)	Sigma-7-Series User Manual Safety Module (SIEPC 72082906 E□) Supplement for using with Sigma-7 SERVOPACKs (400 V-Input power models) (900-200-100)	Provides details information required for the design and maintenance of Safety Module SGDV-OSA01A000FT900.		
	Series Servomotor Product Manual			
	Rotary Servomotor with 400 V-Input Power Product Manual (SIEP S800001 86□)	Provides detailed information on selecting, installing, and connecting		
	Linear Servomotor with 400 V-Input Power Product Manual (SIEP S80001 81□)	the Sigma-7 Series Servomotors.		
	Others	Describes the exercting procedures for a		
	Digital Operator Operating Manual (SIEP S800001 33□)	Describes the operating procedures for a Digital Operator for a Sigma-7 Series Servo System.		
	Engineering Tool SigmaWin+ Version 7.2 Online Manual Component (SIET S800001 34)	Provides detailed operating procedures for the SigmaWin+ Engineering Tool for a Sigma-7 Series Servo System.		

Content - Rotary Servomotors




Content - Rotary Servomotors

Rotary Servomotors

SGM7J	18
SGM7A	29
SGM7G	47



Model Designations



15D

400 \

08D

04D

Specifications and Ratings

Specifications

Voltage


Model SGM7J-

Time Rating		Continuous							
Thermal Class		В							
Insulation Resista	ance	500 VDC, 10) MOhm min.						
Withstand Voltag	je	1,800 VAC	for 1 minute						
Excitation		Permane	nt magnet						
Mounting		Flange-i	mounted						
Drive Method		Direc	t drive						
Rotation Directio	n	Counterclockwise (CCW) for forward re	ference when viewed fro	om the load side					
Vibration Class*1		V	15						
	Surrounding Air Temperature	0 °C to 40 °C (With derating, usage is possible between 40 °C and 60 °C)*4							
	Surrounding Air Humidity	20% to 80% relative humidity (with no condensation)							
Environmental Conditions	Installation Site	 Must be indoors and free of corrosive and explosive gases. Must be well-ventilated and free of dust and moisture. Must facilitate inspection and cleaning. Must have an altitude of 1,000 m or less. (With derating, usage is possible between 1,000 m and 2,000 m.)*5 Must be free of strong magnetic fields. 							
	Storage Environment	Store the Servomotor in the following environment if you store it with the power cable disconnected. Storage Temperature: -20 °C to 60 °C (with no freezing) Storage Humidity: 20% to 80% relative humidity (with no condensation)							
Shock Resis-	Impact Acceleration Rate at Flange	490 m/s ²							
tance*2	Number of Impacts	2 ti	mes						
Vibration Resis- tance*3	Vibration Acceleration Rate at Flange	49 m/s ²							
Applicable SERVOPACKs	SGD7S- 1R9D 3R5D 5R4D								

02D

*1. A Vibration class of V15 indicates a vibration amplitude of 15 µm maximum on the Servomotor without a load at the rated motor speed.

*2. The shock resistance for shock in the vertical direction when the Servomotor is mounted with the shaft in a horizontal position is given in the above table.



*3. The vertical, side-to-side, and front-to-back vibration resistance for vibration in three directions when the Servomotor is mounted with the shaft in a horizontal position is given in the above table. The strength of the vibration that the Servomotor can withstand depends on the application. Always check the vibration acceleration rate that is applied to the Servomotor with the actual equipment.



Vertical

*4. If the surrounding air temperature will exceed 40°C, refer to the section "Applications where the Surrounding Air Temperature of the Servomotor Exceeds 40°C".


*5. If the altitude will exceed 1,000 m, refer to the section "Applications where the Altitude of the Servomotor Exceeds 1000m".

Ratings

Voltage			400 V						
Model SGM7J-			02D	04D	08D	15D			
Rated Output *1		W	200	400	750	1500			
Rated Torque *1,	*2	Nm	0.637	1.27	2.39	4.77			
Instantaneous Ma	aximum Torque *1	Nm	2.23	4.46	8.36	14.3			
Rated Current *1		Arms	1.5	1.4	2.2	4.5			
Instantaneous Ma	aximum Current *1	Arms	5.5	5.3	8.2	14.0			
Rated Motor Spe	ed *1	min ⁻¹		30	00				
Maximum Motor	Speed	min ⁻¹		60	00				
Torque Constant		Nm/Arms	0.461	0.965	1.17	1.13			
Motor Moment of	f Inertia	$\times 10^{-4} \text{ kg m}^2$	0.263 (0.333)	0.486 (0.556)	1.59 (1.77)	4.02 (4.90)			
Rated Power Rat	e *1	kW/s	15.4 (12.1)	33.1 (29.0)	35.9 (32.2)	56.6 (46.6)			
Rated Angular Ac	cceleration Rate *1	rad/s ²	24200 (19100)	26100 (22800)	15000 (13500)	11900 (9700)			
Heat Sink Size (A	luminium)	mm	$250 \times 250 \times 6 \qquad \qquad 300 \times 3000 \times 300 \times 3000 \times 300 \times 30$						
Protective Structu			Totally enclosed, self-cooled, IP67						
	Rated Voltage	V		24 VD0	6.5 7.5				
	Capacity			1.27					
	Holding Torque	Nm	0.637		2.39	4.77			
Holding Brake	Coil Resistance	Ω (at 20 °C)		10%	88.6±10%	76.8±10%			
Specifications *4	Rated Current Time Required to	A (at 20 °C)	0.	25	0.27 0.31				
	Release Brake	ms	6	60	80				
	Time Required to Brake	ms		10	100				
Allowable Load Moment of	Standard		15 times	10 times	12 times	6 times			
Inertia (Motor Moment of Inertia Ratio)	With External Regenerative Resistor or Dynamic Brake Resistor Connected		25 t	imes	15 times	12 times			
Allowable Choft	LF	mm	2	25	35				
Allowable Shaft Load *5	Allowable Radial Load	Ν	24	45	392	490			
	Allowable Thrust Load	Ν	7	4	147				


Note: The values in parentheses are for Servomotors with holding brakes.

- 1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. The values for other items are at 20°C. These are typical values.
- 2. The rated torques are the continuous allowable torque values at a surrounding air temperature of 40°C with an aluminum heat sink of the dimensions given in the table.
- 3. This does not apply to the shaft opening. Protective structure specifications apply only when the special cable is used.
- 4. Observe the following precautions if you use a Servomotor with a holding brake.
 - The holding brake cannot be used to stop the Servomotor.
 - The time required to release the brake and the time required to brake depend on which discharge circuit is used. Confirm that the operation delay time is appropriate for the actual equipment.
 - The 24-VDC power supply is not provided by YASKAWA.
- 5. The allowable shaft loads are illustrated in the following figure. Design the mechanical system so that the thrust and radial loads applied to the Servomotor shaft end during operation do not exceed the values given in the table.



Motor Speed-Torque Characteristics

A : Continuous duty zone B : Intermittent duty zone




Notes:

- These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. These are typical values.
- The characteristics in the intermittent duty zone depend on the power supply voltage. The intermittent duty zones in the graphs show the characteristics when a three-phase, 400-VAC power supply voltage is used.
- If the effective torque is within the allowable range for the rated torque, the Servomotor can be used within the intermittent duty zone.
- If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torquemotor speed characteristics will become smaller because the voltage drop increases.

Servomotor Overload Protection Characteristics

The overload detection level is set for hot start conditions with a Servomotor surrounding air temperature of 40°C.



Note:

The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher.

Use the Servomotor so that the effective torque remains within the continuous duty zone given in Motor Speed-Torque Characteristics above.

Load Moment of Inertia

The load moment of inertia indicates the inertia of the load. The larger the load moment of inertia, the worse the response. If the moment of inertia is too large, operation will become unstable. The allowable size of the load moment of inertia (J_L) for the Servomotor is restricted. Refer to Ratings of Rotary Serovmotors SGM7J. This value is provided strictly as a guideline and results depend on Servomotor driving conditions.

An Overvoltage Alarm (A.400) is likely to occur during deceleration if the load moment of inertia exceeds the allowable load moment of inertia. SERVOPACKs with a built-in regenerative resistor may generate a Regenerative Overload Alarm (A.320). Perform one of the following steps if this occurs.

- Reduce the torque limit.
- Reduce the deceleration rate.Reduce the maximum motor
- speed.
- Install an external regenerative resistor if the alarm cannot be cleared using the above steps.

Servomotor Heat Dissipation Conditions

The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C when a heat sink is installed on the Servomotor. If the Servomotor is mounted on a small device component, the Servomotor temperature may rise considerably because the surface for heat dissipation becomes smaller. Refer to the following graphs for the relation between the heat sink size and derating rate.


Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the Servomotor Overload Protection Characteristics.

Note:

The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.

Important:

The actual temperature rise depends on how the heat sink (i.e., the Servomotor mounting section) is attached to the installation surface, what material is used for the Servomotor mounting section, and the motor speed. Always check the Servomotor temperature with the actual equipment.



See Servomotor Ratings for more information.


Applications Where the Surrounding Air Temperature of the Servomotor Exceeds 40°C

The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C. If you use a Servomotor at a surrounding air temperature that exceeds 40°C (60°C max.), apply a suitable derating rate from the following graphs. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the Servomotor Overload Protection Characteristics.

Note:

Note:

- 1. Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor.
- 2. The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.




Applications Where the Altitude of the Servomotor Exceeds 1,000 m

The Servomotor ratings are the continuous allowable values at an altitude of 1,000 m or less. If you use a Servomotor at an altitude that exceeds 1,000 m (2,000 m max.), the heat dissipation effect of the air is reduced. Apply the appropriate derating rate from the following graphs.

Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the Servomotor Overload Protection Characteristics.


 Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor.

2. The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.



External Dimensions

SGM7J-02 and -04




Model SGM7J-	L	LL	LM	LB	S	L1	L2	Approx. Mass [kg]
02D □ F2 □	108.5 (148.5)	78.5 (118.5)	51.2	500.025	14 ⁰ -0.011	25	65 (105)	0.9 (1.5)
04D □ F2 □	125 (165)	95 (135)	67.2	500.025	14 -0.011	41.5	81.5 (121.5)	1.2 (1.8)

Note:

88

The values in parentheses are for Servomotors with Holding Brakes.
 Refer to the section Shaft End Specification.
 Refer to the section Connectors Specification.


SGM7J-08



Model SGM7J-	L	LL	LM	LB	S	L1	L2	Approx. Mass [kg]
08D □ F2 □	146.5 (193.5)	106.5 (153.5)	79	700.030	19 _{-0.013}	53	93 (121.5)	2.3 (2.9)

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Refer to the section Shaft End Specification. 3. Refer to the section Connectors Specification.

SGM7J-15



Model SGM7J-	L	LL	LM	LB	S	L1	L2	Approx. Mass [kg]
15D □ F2 □	163.5 (196.5)	123.5 (156.5)	95.6	110 ⁰ -0.035	19 _{-0.013}	72	110 (143)	6.4 (8.1)

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Refer to the section Shaft End Specification. 3. Refer to the section Connectors Specification SGM7J-15D.

Shaft End Specifications

SGM7J-DDDDDDD




Chaff End Dataila	Servomotor Model SGM7J-					
Shaft End Details		02	04	08	15	
Code: 2 (Straight without Key)						
	LR	30)	40		
	S	14 ⁰) 0.011	19 _{-0.013}		
Code: 6 (Straight with Key and Tap)						
	LR	30)	4	0	
H LR H	QK	14	1	22		
	S	14 ⁰	14 ⁰ -0.011		0 -0.013	
	W	5	5		6	
	Т	5		6	3	
Y ≝ I↓↓. ∽ Cross section Y-Y	U	3		3.5		
	Р	M5 ×	: 8L	M6 ×	10L	

Contents

Connector Specifications

SGM7J-02 to -15

• Encoder Connector Specifications




Receptacle
Size: M12
Part number: 1419959
Model: SACC-MSQ-M12MS-25-3,2 SCO
Manufacturer: Phoenix Contact

1	PG 5V
2	PG 0V
3	FG
4	BAT (+)
5	BAT (-)
6	Data (+)
7	Data (-)
8	Empty
Housing	Shield

SGM7J-02 to -08


Servomotor Connector Specifications



	Receptacle	1	(Brake)
	Size: M17	3	U
_	Part number: 1620448	4	V
	Part number. 1020440	5	Empty
	Model: ST-5EP1N8AA500S	6	(Brake)
	MOUEL ST-JEF MOAAJUUS	7	W
	Manufacturer: Phoenix Contact	FG	FG
		Housing	Shield

SGM7J-15

Servomotor Connector Specifications




Receptacle Size: M23 Part number: 1617905 Model: ST-5EP1N8AAD00S Manufacturer: Phoenix Contact

1	V
2	(Brake)
4	(Brake)
5	Ú
6	W
FG	FG
Housing	Shield

Servomotor Connector Rotational Angle

Allowable number of rotations: 10

SGM7G-02 to -15





Model Designations

70

SGM7A	-	02	D	F	F	6	1			
Sigma-7 Series Servomotors:		1st + 2nd	3rd	4th	5th	6th	7th	digit		
SGM7A	1st + 2	2nd digit - Rat	ed Output	3rd di	git - Pow	ver Supply		6th digit - Shaft End		
	Code	Specificatio	n	Voltag	je			Code	Specifications	
	02	200 W		Code	Specif	ication		2	Straight without key	
	04	400 W		D	400 VAC			6	Straight with key and tap	
	08 750 W									
	10	1.0 kW		4th di	git - Seri	al Encoder				
	15	1.5 kW		Code	 Specification 			7th dig	it - Options	
				7	7 24-bit absolu		olute		Specifications	
	20	2.0 kW		F	ith digit - Design Revision			1	Without options	
	25	2.5 kW						С	With holding brake (24 VDC)	
	30	3.0 kW		5th di				F *	With dust seal	
	40	4.0 kW		Order				F		
	50	5.0 kW		F	Standa	ard Model		H*	With dust seal and holding brake (24 VDC)	

absolute	Code	Specifications				
t incremental	1	Without options				
	С	With holding brak				
sign Revision	F*	With dust seal				
dard Model	H*	With dust seal an brake (24 VDC)				

* This option is supported only for SGM7A-10 to -50 Servomotors.

Bolded options are considered standard warehouse products.

7.0 kW


Specifications and Ratings

Specifications

Voltage							400 V						
Model SGM7A	-	02D	04D	08D	10D	15D	20D	25D	30D	40D	50D	70D	
Time Rating			Continuous										
Thermal Class		B F											
Insulation Resist	tance	500 VDC, 10 MΩ min.											
Withstand Volta	ge	1,800 VAC for 1 minute											
Excitation		Permanent magnet											
Mounting		Flange-mounted											
Drive Method		Direct drive											
Rotation Direction	on	Counterclockwise (CCW) for forward reference when viewed from the load side											
Vibration Class*	1						V15						
Environmental Conditions	Surrounding Air Temperature		0 °C to 40 °C (With derating, usage is possible between 40 °C and 60 °C)*4										
	Surrounding Air Humidity	20% to 80% relative humidity (with no condensation)											
	Installation Site	 Must be indoors and free of corrosive and explosive gases. Must be well-ventilated and free of dust and moisture. Must facilitate inspection and cleaning. Must have an altitude of 1,000 m or less. (With derating, usage is possible between 1,000 m and 2,000 m.)*⁵ Must be free of strong magnetic fields. 											
	Storage Environment	Store the Servomotor in the following environment if you store it with the power cable disconnected. Storage Temperature: -20 °C to 60 °C (with no freezing) Storage Humidity: 20 % to 80 % relative humidity (with no condensation)										d.	
Shock Resistance*2	Impact Accelerati- on Rate at Flange	490 m/s ²											
	Number of Impacts		2 times										
Vibration Resistance*3	Vibration Accelera- tion Rate at Flange	49 m/s ² (Models 15A to 30D: 24.5 m/s ² front to back)										14.7 m/s ²	
	SGD7S-	1F	89D	3R5D	5F	R4D	8R4D	12	0D	17	0D	260D	
Applicable SERVOPACKs	SGD7W-	2R6D*6	2R6D*6 or 5R4D*6	2R6D or 5R4D*6	5R4D*6	5R4D				-			


 *1 A Vibration class of V15 indicates a vibration amplitude of 15 μm maximum on the Servomotor without a load at the rated motor speed.

*2 The shock resistance for shock in the vertical direction when the Servomotor is mounted with the shaft in a horizontal position is given in the above table.



Shock Applied to the Servomotor

*3 The vertical, side-to-side, and front-to-back vibration resistance for vibration in three directions when the Servomotor is mounted with the shaft in a horizontal position is given in the above table. The strength of the vibration that the Servomotor can withstand depends on the application. Always check the vibration acceleration rate that is applied to the Servomotor with the actual equipment.



*4 Refer to the section "Applications where the Surrounding Air Temperature of the Servomotor Exceeds 40°C".

*5 If the altitude will exceed 1,000 m, refer to the section "Applications where the Altitude of the Servomotor Exceeds 1000m".

*6 If you use this combination, performance may not be as good, e.g., the control gain may not increase, in comparison with using a Sigma-7 Single Axis SERVOPACK.

Servomotor Ratings

Voltage								400 V						
Model SGM7A-			02D	04D	08D	10D	15D	20D	25D	30D	40D	50D	70D	
Rated Output*1		W	200	400	750	1,000	1,500	2,000	2,500	3,000	4,000	5,000	7,000	
Rated Torque*1,*	2	Nm	0.637	1.27	2.39	3.18	4.90	6.36	7.96	9.80	12.6	15.8	22.3	
Instantaneous Ma Torque*1	aximum	Nm	2.23	4.46	8.36	11.1	14.7	19.1	23.9	29.4	37.8	47.6	54.0	
Rated Current*1 A		Arms	1.2	1.2	2.2	3.2	4.7	6.1	7.4	8.9	12.5	13.8	19.2	
Instantaneous Maximum Arms		5.1	4.9	8.5	12	14	20	25	28	38	42	52.5		
Rated Motor Spe	ed*1	min ⁻¹		3000										
Maximum Motor	Speed ^{*1}	min ⁻¹		6000*6										
Torque Constant Nm/Arms		0.556	1.11	1.16	1.07	1.23	1.18	1.15	1.16	1.06	1.21	1.21		
Motor Moment of Inertia Rated Power Rate*1		×10 ⁻⁴ kg m²	0.139 (0.209) 29.2 (19.4)	0.216 (0.286) 74.7 (56.3)	0.775 (0.955) 73.7 (59.8)	0.971 (1.15)	2.00 (2.25)	2.47 (2.72)	3.19 (3.44)	7.00 (9.20)	9.60 (11.8)	12.3 (14.5)	12.3	
		kW/s				104 (87.9)	120 (106)	164 (148)	199 (184)	137 (104)	165 (134)	203 (172)	404	
Rated Angular Ad Rate*1		rad/s ²	45,800 (30,400)	58,700 (44,400)	30,800 (25,000)	32,700 (27,600)	24,500 (21,700)	25,700 (23,300)	24,900 (23,100)	14,000 (10,600)	13,100 (10,600)	12,800 (10,800)	18,100	
Derating Rate for with Dust Seal	Derating Rate for Servomotor % with Dust Seal		-			95	95				100			
Heat Sink Size	Heat Sink Size mm			$50 \times 250 \times$	6		300 × 3	300 × 12						
Protective Structure*3				Totally enclosed, self-cooled, IP67										
	Rated Voltage	\vee					24VDC	C±10%			-			
	Capacity	W	6 6			.5 12			10			-		
	Holding Torque	Nm	0.637 1.27		2.39	3.18	7.84	7.84 7.84 10		20			-	
Holding Brake	CoilΩ (atResistance20 °C)		96±10% 88.6±			10% 48±10%				59			-	
Specifications*4	Rated Current	A (at 20 °C)	0.	25	0.27		0.5			0.41			-	
	Time required to release Brake	ms	60		80			170			100			
	Time required to brake	ms	100						8	30	-			
Allowable Load	Standard		30 times 20 times				10 times			5 times			15 times	
Moment of Inertia (Motor Moment of Inertia Ratio)	With External I nerative Resist Dynamic Brake Connected	or and	30 times	20 times	30 t	imes		20 times		15 times				
	LF	mm	2	25	3	5	45			63				
Allowable Shaft Load*5	Allowable Radial Load	Ν	24	45	5 392 686 980		1,176							
	Allowable Thrust Load	Ν	7	4	14	47	196							

Note: The values in parentheses are for Servomotors with Holding Brakes.

*1. For the SGM7A-02D to SGM7A-10D, these values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. The values for other items are at 20°C. For the SGM7A-15D to SG-M7A-30D, these values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values.


*2. The rated torques are the continuous allowable torque values at a surrounding air temperature of 40°C with an alu-minum heat sink of the dimensions given in the table.

*3. This does not apply to the shaft opening. Protective structure specifications apply only when the special cable is used.

*4. Observe the following precautions if you use a Servomotor with a Holding Brake.


- The holding brake cannot be used to stop the Servomotor.
 The time required to release the brake and the time required to brake depend on which discharge circuit is used. Confirm that the operation delay time is appropriate for the actual equipment.
- The 24-VDC power supply is not provided by YASKAWA.
- *5. The allowable shaft loads are illustrated in the following figure. Design the mechanical system so that the thrust and radial loads applied to the Servomotor shaft end during operation do not exceed the values given in the table.


*6. For the SGM7A-25D, the maximum motor speed for the continuous duty zone is 5,000 min-1. Use the Servomotor within the continuous duty zone for the average motor speed and effective torque.




Motor Speed-Torque Characteristics


Torque (N·m)







Motor speed (min⁻¹)









Motor speed (min⁻¹)








Torque (N·m)



Motor speed (min⁻¹)







Motor speed (min-1)

Note:


1. For the SGM7A-02D to SGM7A-10D, these values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C.

For the SGM7A-15D to SGM7A-30D, these values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values. 2. The characteristics in the intermittent duty zone

- depend on the power supply voltage. The intermittent duty zones in the graphs show the characteristics when a three-phase, 400-VAC power supply voltage is used.
- 3. If the effective torque is within the allowable range for the rated torque, the Servomotor can be used within the intermittent duty zone.
- 4. If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque-motor speed characteristics will become smaller because the voltage drop increases.

Servomotor Overload Protection Characteristics

The overload detection level is set for hot start conditions with a Servomotor surrounding air temperature of 40 °C.



Note:

The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher. Use the Servomotor so that the effective torque remains within the continuous duty zone given in Motor Speed-Torque Characteristics.

Load Moment of Inertia

The load moment of inertia indicates the inertia of the load. The larger the load moment of inertia, the worse the response. If the moment of inertia is too large, operation will become unstable.

The allowable size of the load moment of inertia (J_L) for the Servomotor is restricted. Refer to Ratings of Rotary Servomotors SGM7J. This value is provided strictly as a guideline and results depend on Servomotor driving conditions.

An Overvoltage Alarm (A.400) is likely to occur during deceleration if the load moment of inertia exceeds the allowable load moment of inertia. SERVOPACKs with a built-in regenerative resistor may generate a Regenerative Overload Alarm (A.320). Perform one of the following steps if this occurs.

- Reduce the torque limit.
- Reduce the deceleration rate.
- Reduce the maximum motor speed.
- Install an external regenerative resistor if the alarm cannot be cleared using the above steps.

Servomotor Heat Dissipation Conditions


The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C when a heat sink is installed on the Servomotor. If the Servomotor is mounted on a small device component, the Servomotor temperature may rise considerably because the surface for heat dissipation becomes smaller. Refer to the following graphs for the relation between the heat sink size and derating rate. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.


Note:


The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.

Important:

The actual temperature rise depends on how the heat sink (i.e., the Servomotor mounting section) is attached to the installation surface, what material is used for the Servomotor mounting section, and the motor speed. Always check the Servomotor temperature with the actual equipment.







See Servomotor Ratings for more information


Applications Where the Surrounding Air Temperature of the Servomotor Exceeds 40°C


The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C. If you use a Servomotor at a surrounding air temperature that exceeds 40°C (60°C max.), apply a suitable derating rate from the following graphs.


Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.

Note: 1. Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor. 2. The derating rates are applicable only when the average motor speed is less than or equal to the rated motor

speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative







120 SGM7A-70 100 Derating rate (%) 80 60 SGM7A-50 40 20 0 30 40 Surrounding air temperature (°C)


Applications Where the Altitude of the Servomotor Exceeds 1,000 m


The Servomotor ratings are the continuous allowable values at an altitude of 1,000 m or less. If you use a Servomotor at an altitude that exceeds 1,000 m (2,000 m max.), the heat dissipation effect of the air is reduced. Apply the appropriate derating rate from the following graphs. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.


Note:

 Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor.

The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.








120 SGM7A-70 100 Derating rate (%) 80 60 SGM7A-30, 40 40 SGM7A 20 0 0 500 1000 1500 2000 2500 Altitude (m)

External Dimensions

SGM7A-02, -04




Model SGM7A-	L	LL	LM	LB	S	L1	L2	Approx. Mass [kg]
02D □ F2 □	108.5 (148.5)	78.5 (118.5)	51.2	50 _{-0.025}	14 ⁰ -0.011	25	65 (105)	0.9 (1.5)
04D D F2 D	125 (165)	95 (135)	67.2	50 ⁰ -0.025	14 ⁰ -0.011	41.5	81.5 (121.5)	1.2 (1.8)

Note: The values in parentheses are for Servomotors with Holding Brakes. Refer to the section Shaft End Specifications for SGMA7A-02 to -10. Refer to the section Connector Specifications.

Option Modules

Cables & Periphery


SGM7A-08



Model SGM7A-	L	LL	LM	LB	S	L1	L2	Approx. Mass [kg]
08D□F2□	146.5 (193.5)	106.5 (153.5)	79	70 ⁰ -0.030	19 ⁰ -0.013	53	93 (140)	2.4 (3.0)

Note: The values in parentheses are for Servomotors with Holding Brakes. Refer to the section Shaft End Specifications for SGMA7A-02 to -10. Refer to the section Connector Specifications.

SGM7A-10



Model SGM7A-LL LM LB s L2 Approx. Mass [kg] L1 131 (178) 3.2 (3.8) 171 (218) 117.5 (164.5) 70⁰-0.030 19⁰_{-0.013} 10D**D**F2**D** 103.5 77


Note:

The values in parentheses are for Servomotors with Holding Brakes. Refer to the section Shaft End Specifications for SGMA7A-02 to -10. Refer to the section Connector Specifications.

Options

• With Dust Seal

Madel COM7A	Dimensions with Dust Seal							
Model SGM7A-	E1	E2	LS1	LS2				
10D	47	61	5.5	11				



Unit: mm

Shaft End Specifications for SGM7A-02 to -10

SGM7A-DDDDDDD



Shaft End Details			Servomotor N	lodel SGM7A-		
		02	04	08	10	
Code: 2 (Straight without Key)						
			30		0	
	S		0 -0.011	19 ⁰ _{-0.013}		
Code: 6 (Straight with Key and Tap)						
	LR	30		40		
	QK	14		22		
	S		0 -0.011		0 -0.013	
	W	5	5	6	6	
	Т	5	5	6	3	
	U	3	3	3.	5	
	Ρ	M5 >	× 8L	M6 ×	10L	


40 YASKAWA SIGMA-7 | CATALOG

Shaft End Details

45

3

SGM7A-15, -20, and -25



45

<u>3</u> 0.5 10

10.04 A


00.04 A

Model SGM/A-	L L	LL	LM	L1	L2	LB	Dimen	510115	
							S	Q	Mass [kg]
15D 🗆 F2 🗖	204 (245)	159 (200)	121 (162)	90	145 (187)	95 ⁰ -0.035	24 ⁰ -0.013	40	4.7 (6.1)
20D 🗆 F2 🗖	220 (261)	175 (216)	137 (178)	106	161 (203)	95 ⁰ -0.035	24 ⁰ -0.013	40	5.5 (6.9)
25D 🗆 F2 🗖	243 (294)	198 (249)	160 (211)	129	184 (235)	95 ⁰ -0.035	24 ⁰ -0.013	40	6.9 (8.8)

LI LM

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to Shaft End Specifications for SGM7A-15 to -70 for details. Refer to the section Connector Specifications.

SGM7A-30 to -50



Model SGM7A-	L	LL	LM	L1	L2	LB	Shaft Dimen		Approx.
							S	Q	Mass [kg]
30D 🗆 F2 🗖	259 (295)	196 (232)	158 (194)	131	183 (219)	110 ⁰ -0.035	28 _{-0.013}	55	10.6 (13.1)
40D 🗆 F2 🗖	298 (334)	235 (271)	197 (233)	170	222 (258)	110 ⁰ -0.035	28 _{-0.013}	55	14.0 (16.5)
50D 🗆 F2 🗖	338 (374)	275 (311)	237 (273)	210	262 (298)	110 ⁰ -0.035	28 ⁰ -0.013	55	17.0 (19.5)

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to Shaft End Specifications for SGM7A-15 to -70 for details. Refer to the section Connector Specifications.

Contents

Rotary Motors

Linear Motors


SERVOPACKs

Option Modules

Cables & Periphery

Appendix

SGM7A-70



Model SGM7A-	L	LL	LM	L1	L2	LB	Shaft Dimen		Approx.
							S	Q	Mass [kg]
70D 🗖 F2 🗖	397	334	291	204	262	110 ⁰ -0.035	28 _{-0.013}	55	19.0

Cooling Fan Specification

- Single-Phase, 220V
- 50/60 Hz
- 17/15W
- 0.11/0.09 A

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to Shaft End Specifications for SGM7A-15 to -70 for details. Refer to the section Connector Specifications.

Shaft End Specifications for SGM7A-15 to -70

SGM7A-DDDDDDD

Code	Specification
2	Straight without key
6	Straight with key and tap for one location (Key slot is JIS B1301-1996 fastening type.)

Т

Shaft End Details		Servomotor Model SGM7A-							
Shart End Details		15	20	25	30	40	50	70	
Code: 2 (Straight without Key)									
	LR		45			63			
	Q		40			55			
Sdia.	S	2	24 ⁰ -0.013			28 ⁰ -0.013			
Code: 6 (Straight with Key and Tap)									
< LR ►	LR		45			63			
	Q		40			55			
	QK		32			50			
	S	2	24-0.013			28 _{-0.013}			
	W				8				
U P	Т				7				
	U				4				
	Ρ	M8 screw, Depth: 16							

PG 5V PG 0V FG

BAT (+)

BAT (-)

Data (+) Data (-) Empty Shield

Connector Specifications

SGM7A-02 to -70

• Encoder Connector Specifications

	3	2	8
4		\mathbb{Z}°	
))	
	• /		7
Ę	5	6	

Desentedo	1
Receptacle	2
Size: M12	3
	4
Part number: 1419959	5
Model: SACC-MSQ-M12MS-25-3.2 SCO	6
1000EL SACC-1013Q-101121013-20-3,2 300	7
Manufacturer: Phoenix Contact	8
	Housing
	•

SGM7A-02 to -08

6

4

FG

Servomotor Connector Specifications

Receptacle		
Size: M17	1	(Brake)
Part number: 1620448	3	U
Model: ST-5EP1N8AA500S	4 5	V Empty
Manufacturer: Phoenix Contact	6 7	(Brake) W
	FG	FG
	Housing	Shield

SGM7A-10 to -50

Servomotor Connector Specifications




Receptacle Size: M23 Part number: 1617905 Model: ST-5EP1N8AAD00S Manufacturer: Phoenix Contact

1	V
2	(Brake)
4	(Brake)
5	Ù
6	W
FG	FG
Housing	Shield

SGM7A-70

Servomotor Connector Specifications




Receptacle Size: M40 Part number: 1607927 Model: SM-5EPWN8AAD00S Manufacturer: Phoenix Contact

U	U
V	V
W	W
+	Empty
-	Empty
FG	FG
Housing	Shield

SGM7A-70

• Fan Connector Specifications



Receptacle Size: M17 Part number: 1620448 Model: ST-5EP1N8AA500S Manufacturer: Phoenix Contact


1	ALARM TERMINAL
3	FAN MOTOR
4	FAN MOTOR
6	ALARM TERMINAL
7	Empty
FG	FG
Housing	Shield

Servomotor Connector Rotational Angle


Allowable number of rotations: 10


SGM7A-02 to -10

SGM7A-70



SGM7A-15 to -25







SGM7G

Sigma-7 Series Servomotors: SGM7G

_	05	D	F		F	6	F		
	1st + 2nd	3rd	4th	Į	ōth	6th	7th	digit	
1st + 2	2nd digit - Ra	ted Outpu		/	6th dig	git - Shaft End			
Code	Specificatio	on		oltag				Code	Specification
05	450 W			ode		ification		2	Straight without key
09	850 W		D	D 400 VAC					(450 W, 1.8 kW, 2.9 kW) Straight with key and tap
13	1.3 kW							6	(450 W, 1.8 kW, 2.9 kW)
20	1.8 kW	4t	h dig	jit - Se	rial Encode	r	S*1	Straight without key	
30	2.9 kW		C	ode	Spec	ification		0	(850 W, 1.3 kW)
44	4.4 kW		7	7 24-bit absolute					Straight with key and tap (850 W, 1.3 kW)
55	5.5kW		F		24-bi	t increment	tal		(,,
75	7.5kW								
					jit - De	esign Revisi	on	7th die	git - Options
1A	11.0 kW		0	rder					
1E	15.0 kW		C	ode	Spec	ification		Code	Specification
			F		Stan	dard Model		1	Without options
			R*	*2	High-	speed Mode		С	With holding brake (24 VDC)

*1 The shaft end codes are different for 850 kW and 1.3 kW Servomotors. The shaft diameter for 850 W Servomotors is 19 mm. The shaft diameter for 1.3 kW Servomotors is 22 mm.
*2 Available up to 4.4 kW.

7th dig	7th digit - Options									
Code	Specification									
1	Without options									
С	With holding brake (24 VDC)									
F	With dust seal									
Н	With dust seal and holding brake (24 VDC)									

Bolded options are considered standard warehouse products.


Specifications and Ratings

Specifications


Voltage			400 V									
Model SGM70	ì-		05D	09D	13D	20D	30D	44D	55D	75D	1AD	1ED
Time Rating			Continuous									
Thermal Class			F									
Insulation Resis	tance			500 VDC, 10 MΩ min.								
Withstand Volta	ge		1,800 VAC for 1 minute									
Excitation							Permaner	nt magnet				
Mounting							Flange-r	nounted				
Drive Method								drive				
Rotation Direction	on		Counterclockwise (CCW) for forward reference when viewed from the load side									
Vibration Class*							V					
	Surrounding Temperature			0 °C to 40 °C (With derating, usage is possible between 40 °C and 60 °C)*4								
	Surrounding	Air Humidity	 20% to 80% relative humidity (with non-condensing) Must be indoors and free of corrosive and explosive gases. 									
Environmental Conditions	Installation S	ite	 Must b Must fa Must h 2,000 r Must b 	 Must be well-ventilated and free of dust and moisture. Must facilitate inspection and cleaning. Must have an altitude of 1,000 m or less. (With derating, usage is possible between 1,000 m and 2,000 m.)*⁵ Must be free of strong magnetic fields. 								
	Storage Envi	ronment	Store the Servomotor in the following environment if you store it with the power cable disconnected. Storage Temperature: -20 °C to 60 °C (with no freezing) Storage Humidity: 20 % to 80% relative humidity (non-condensing)									
Shock	Impact Acce at Flange	leration Rate					490	m/s²				
Resistance*2	Number of In	1					2 tir	nes				
Vibration Resistance*3	Vibration Acc Rate at Flanc			49 m	1/s² (24.5 m	/s² front to I	back)			24.5	5 m/s²	
	When using	SGD7S-	1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Applicable	a Standard Servomotor	SGD7W-	2R6D*6 or 5R4D*6	5R4D*6	5R4D				-			
SERVOPACKs	When	SGD7S-	3R5D	5R4D	8R4D	120D	170D	210D			-	
	using a High-speed Servomotor	SGD7W-	2R6D or 5R4D*6	5R4D				-	-			

*1. A vibration class of V15 indicates a vibration amplitude of 15 µm maximum on the Servomotor without a load at the rated motor speed.

*2. The shock resistance for shock in the vertical direction when the Servomotor is mounted with the shaft in a horizontal position is given in the above table.



*3. The vertical, side-to-side, and front-to-back vibration resistance for vibration in three directions when the Servomotor is mounted with the shaft in a horizontal position is given in the above table. The strength of the vibration that the Servomotor can withstand depends on the application. Always check the vibration acceleration rate that is applied to the Servomotor with the actual equipment.



*4. If the surrounding air temperature will exceed 40°C, refer to the section "Applications where the Surrounding Air Temperature of the Servomotor Exceeds 40°C".

*5. If the altitude will exceed 1,000 m, refer to the section "Applications where the Altitude of the Servomotor Exceeds 1000m".

*6. If you use this combination, performance may not be as good, e.g., the control gain may not increase, in comparison with using a Sigma-7S SERVOPACK.

Servomotor Ratings


Standard Servomotors

/oltage			400 V										
Aodel SGM7G-			05D	09D	13D	20D	30D	44D	55D	75D	1AD	1ED	
Rated Output *1		kW	0.45	0.85	1.3	1.8	2.9	4.4	5.5	7.5	11	15	
Rated Torque *1, *	*2	Nm	2.86	5.39	8.34	11.5	18.6	28.4	35.0	48.0	70.0	95.4	
nstantaneous Ma	aximum Torque *1	Nm	8.92	13.8	23.3	28.7	45.1	71.6	87.6	119	175	224	
Rated Current *1		Arms	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2	
Instantaneous Maximum Current *1 Arms		Arms	5.5	8.5	14	20	28	40.5	52	65	70	85	
Rated Motor Speed *1 min-1		1,500											
Aaximum Motor	Speed *1	min ⁻¹				3,000)				2,	000	
orque Constant		Nm/Arms	1.71	1.72	1.78	1.50	1.70	1.93	1.80	1.92	2.76	2.86	
Motor Moment of Inertia ×10 ⁻⁴ kg m ²			3.33 (3.58)	13.9 (16.0)	19.9 (22.0)	26.0 (28.1)	46.0 (53.9)	67.5 (75.4)	89 (96.9)	125 (133)	242 (261)	303 (341)	
Rated Power Rate *1		kW/s	24.6 (22.8) 8,590	20.9 (18.2) 3,880	35.0 (31.6) 4,190	50.9 (47.1) 4.420	75.2 (64.2) 4.040	119 (107) 4,210	138 (126) 3,930	184 (173) 3840	202 (188) 2,890	300 (267) 3,150	
Rated Angular Acceleration Rate *1 rad/s		rad/s ²	(7,990) 250 × 250	(3,370)	4,190 (3,790)	(4,090)	4,040 (3,450)	4,210 (3,770)	(3,610)	(3,610)	(2,680)	(2,800	
Heat Sink Size mm			× 6 (aluminium)	()					× 30 (steel))		650 × 35 teel)	
Protective Structu	ure *3					Totally en	iclosed, self	-cooled, IP	67				
	Rated Voltage	V	24 VDC 0/+10%							32			
	Capacity	W		10)		18.5			25		35	
	Holding Torque	Nm	4.5	12.7	19.6		43	3.1	72	2.6	84.3	114.6	
lolding Brake	Coil Resistance	Ω (at 20 °C)	56		59		3	31		23	18	17	
Specifications *4	Rated Current	A (at 20 °C)	0.43		0.41		0.	.77	1.	05	1.33	1.46	
	Time Required to Release Brake Time Required to	ms		100	C				170			250	
	Brake	ms		80)		1	00		8	30		
Nowable Load	Standard		15 times			5 times				10 t	imes		
Noment of Inertia Motor Moment of Inertia Ratio)	With External Rege Resistor and Dynar Resistor Connected	nic Brake	15 times	10 times									
	LF	mm	40		58		79		1	13	1	16	
Load *5	Allowable Radial Load	Ν	490	C	686			1,470		1,764		4,998	
	Allowable Thrust Load	Ν	98	5	343	392	4	490		588		2,156	

Note:

The values in parentheses are for Servomotors with Holding Brakes.

- *1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values.
- *2. The rated torques are the continuous allowable torque values at a surrounding air temperature of 40°C with an aluminum or steel heat sink of the dimensions given in the table.
- *3. This does not apply to the shaft opening. Protective structure specifications apply only when the special cable is used.
- *4. Observe the following precautions if you use a Servomotor with a Holding Brake.
- The holding brake cannot be used to stop the Servomotor.
- The time required to release the brake and the time required to brake depend on which discharge circuit is used. Confirm that the operation delay time is appropriate for the actual equipment.
- The 24-VDC power supply is not provided by YASKAWA.
- *5. The allowable shaft loads are illustrated in the following figure. Design the mechanical system so that the thrust and radial loads applied to the Servomotor shaft end during operation do not exceed the values given in the table.




High-speed Servomotors

Voltage			400 V									
Model SGM7G-			05D	09D	13D	20D	30D	44D				
Rated Output *1		kW	0.45	0.85	1.3	1.8	2.9	4.4				
Rated Torque *1,	*2	Nm	2.86	5.39	8.34	11.5	18.6	28.4				
Instantaneous Maximum Torque *1		Nm	8.8	15	22	28.7	50.0	71.1				
Rated Current *1 A		Arms	2.6	5.3	8.3	10.1	14.4	19.3				
Instantaneous Maximum Current *1 Arms			8.2	14	21	24	40	50				
Rated Motor Speed *1 min-1			1,500									
Maximum Motor Speed *1 min-1				5,0	000		4,5	500				
Allowable Contin	uous Motor Speed	min ⁻¹	5,000		4,000		3,300	3,000				
Torque Constant		Nm/Arms	1.13	1.12	1.09	1.27	1.36	1.58				
Motor Moment of Inertia		$\times 10^{-4}$ kg m ²	3.33 (3.58)	13.9 (16)	19.9 (22)	26 (28.1)	46.0 (53.9)	67.5 (75.4)				
Rated Power Rate *1 kW/s			24.6 (22.8) 8,590	20.9 (18.2) 3,880	35 (31.6) 4,190	50.9 (47.1) 4,420	75.2 (64.2) 4,040	119 (107) 4,210				
Rated Angular Acceleration Rate *1 rad/s ²			(7,990) 250 × 250 ×	(3,370)	(3,790)	(4,090)	(3,450)	(3,770)				
Heat Sink Size		mm	6 (aluminium)		400	0 × 400 × 20 (ste	eel)					
Protective Struct			Totally enclosed, self-cooled, IP67									
	Rated Voltage	V			24VDC 0/+10% 0 18.5							
	Capacity	W	4 5		0							
	Holding Torque	Nm	4.5	12.7	19	1.6	43					
lolding Brake	Coil Resistance	Ω (at 20 °C)	56		59		3					
specifications	Rated Current Time Required to Release Brake	A (at 20 °C) ms	0.43	1	0.41		0.1					
	Time Required to Brake	ms		8	30		10	00				
Allowable Load	Standard		8 times	2 times	4 times	3 times	2 times					
Moment of Inertia (Motor Moment of Inertia Ratio)	With External Regenerative Resistor and Dynamic Brake Resis- tor Connected		15 times	es 4 times 7 times 6 times		6 times 5 tim						
	LF	mm	40		58		7	9				
Loads *5	Allowable Radial Load	Ν	49	0	686	980	1,470					
	Allowable Thrust Load	Ν	98	3	343	392	490					

Note:

The values in parentheses are for Servomotors with Holding Brakes.


- *1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values.
- *2. The rated torques are the continuous allowable torque values at a surrounding air temperature of 40°C with an aluminum or steel heat sink of the dimensions given in the table.
- *3. This does not apply to the shaft opening. Protective structure specifications apply only when the special cable is used.
- *4. Observe the following precautions if you use a Servomotor with a Holding Brake.
- The holding brake cannot be used to stop the Servomotor.
- The time required to release the brake and the time required to brake depend on which discharge circuit is used. Confirm that the operation delay time is appropriate for the actual equipment.
- The 24-VDC power supply is not provided by YASKAWA.
- *5. The allowable shaft loads are illustrated in the following figure. Design the mechanical system so that the thrust and radial loads applied to the Servomotor shaft end during operation do not exceed the values given in the table.



Motor Speed-Torque Characteristics

Standard Servomotors





Motor speed (min-1)

Note:


- 1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values.
- 2. The characteristics in the intermittent duty zone depend on the power supply voltage. The intermittent duty zone in the graphs show the characteristics when a three-phase, 400-VAC power supply voltage is used.
- 3. If the effective torque is within the allowable range for the rated torque, the Servomotor can be used within the intermittent duty zone.
- If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque-motor speed characteristics will become smaller 4. because the voltage drop increases.

Cables & Periphery

High-speed Servomotors








SGM7G-30D

В

А

1000 2000 3000 4000 5000

Motor speed (min⁻¹)



SGM7G-44D

В

А

O 1000 2000 3000 4000 5000

Motor speed (min⁻¹)

75

60


45


30

15

0

Torque (N-m)





Note:

60

48

36

24

12

0

0


Torque (N·m)


- 1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 20°C. These are typical values.
- 2. The characteristics in the intermittent duty zone depend on the power supply voltage. The intermittent duty zone in the graphs show the characteristics when a three-phase, 400-VAC power supply voltage is used.
- 3. If the effective torque is within the allowable range for the rated torque, the Servomotor can be used within the intermittent duty zone.
- 4. If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque-motor speed characteristics will become smaller because the voltage drop increases.

Servomotor Overload Protection Characteristics

The overload detection level is set for hot start conditions with a Servomotor surrounding air temperature of 40 °C.

Standard Servomotors





SGM7G-30


200


150

Torque reference (percent of rated torque)

(%)

100





10000

1000

100

10

1

0

50

Detection time (s)


Note: The overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher. Use the Servomotor so that the effective torque remains within the continuous duty zone given in Motor Speed-Torque Characteristics

SGM7G-44

. SGM7G-55, -75

250

High-speed Servomotors



Note: The overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher. Use the Servomotor so that the effective torque remains within the continuous duty zone given in Motor Speed-Torque Characteristics

Load Moment of Inertia

The load moment of inertia indicates the inertia of the load. The larger the load moment of inertia, the worse the response. If the moment of inertia is too large, operation will become unstable.

The allowable size of the load moment of inertia (JL) for the Servomotor is restricted. Refer to Ratings of Rotary Serovmotors SGM7J. This value is provided strictly as a guideline and results depend on Servomotor driving conditions.

An Overvoltage Alarm (A.400) is likely to occur during deceleration if the load moment of inertia exceeds the allowable load moment of inertia. SERVOPACKs with a built-in regenerative resistor may generate a Regenerative Overload Alarm (A.320). Perform one of the following steps if this occurs.

- Reduce the torgue limit.
- Reduce the deceleration rate.
- Reduce the maximum motor speed.
- Install an external regenerative resistor if the alarm cannot be cleared using the above steps.

Servomotor Heat Dissipation Conditions


The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C when a heat sink is installed on the Servomotor. If the Servomotor is mounted on a small device component, the Servomotor temperature may rise considerably because the surface for heat dissipation becomes smaller. Refer to the following graphs for the relation between the heat sink size and derating rate. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.

Note:

The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative.

Important:

The actual temperature rise depends on how the heat sink (i.e., the Servomotor mounting section) is attached to the installation surface, what material is used for the Servomotor mounting section, and the motor speed. Always check the Servomotor temperature with the actual equipment.



See Servomotor Ratings for more information.


Applications Where the Surrounding Air Temperature of the Servomotor Exceeds 40°C


The Servomotor ratings are the continuous allowable values at a surrounding air temperature of 40°C. If you use a Servomotor at a surrounding air temperature that exceeds 40°C (60°C max.), apply a suitable derating rate from the following graphs. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.


Note:

1. Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor.

The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative








Applications Where the Altitude of the Servomotor Exceeds 1,000 m


The Servomotor ratings are the continuous allowable values at an altitude of 1,000 m or less. If you use a Servomotor at an altitude that exceeds 1,000 m (2,000 m max.), the heat dissipation effect of the air is reduced. Apply the appropriate derating rate from the following graphs. Also, change the overload warning and overload alarm detection timing in advance based on the overload detection level of the motor. Refer to the section Servomotor Overload Protection Characteristics.


Note:

1. Use the combination of the SERVOPACK and Servomotor so that the derating conditions are satisfied for both the SERVOPACK and Servomotor.

The derating rates are applicable only when the average motor speed is less than or equal to the rated motor speed. If the average motor speed exceeds the rated motor speed, consult with your YASKAWA representative








External Dimensions

SGM7G-05




Model SGM7A-	L	LL	LM	L1	L2	LB	Shaft Dimen	Approx.	
							S	Q	Mass [kg]
05D 🗆 F2 🗖	181 (214)	141 (174)	103 (136)	74	127 (161)	80 ⁰ -0.030	16 _{-0.011}	30	3.3 (4.3)

Note:

The values in parentheses are for Servomotors with Holding Brakes.
 Refer to the section Shaft End Specifications.
 Refer to the section Connector Specifications.


SGM7G-09, -13, -20




Model	1	LL	LM	L1	L2	LB	Shaft End I	Dimensions	Approx. Mass [kg]	
SGM7G-							S	Q	Approx. mass [kg]	
09D¤FS¤	197 (233)	139 (175)	101 (137)	69	125 (161)	110 _{-0.035}	19 ⁰ -0.013	40	5.6 (7.6)	
13DOFSO	213 (249)	155 (191)	117 (153)	85	141 (177)	110 ⁰ -0.035	22 ⁰ -0.013	40	7.2 (9.1)	
20D D F2 D	231 (267)	173 (209)	135 (171)	103	159 (195)	110 ⁰ -0.035	24 ⁰ _{-0.013}	40	8.7 (11.1)	

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to the section Shaft End Specifications. Refer to the section Connector Specifications SGM7G.

SGM7G-30, -44, -55 and -75





(3.2)	
	62 dia.
D 44 dia	62
Refer to Shaft End Spe	ecifications.

Shaft End Details (79)

•

Unit: mm


Model SGM7G-	L	ш	LM	L1	L2	LB	Shaft End sio		Approx. Mass [kg]	
SGM/G-							S	Q		
30D0F20	241 (289)	162 (210)	124 (172)	94	149 (197)	114.3 _{-0.035}	35 ₀ ^{+0.01}	76	13.6 (19.6)	
44D D F2 D	265 (313)	186 (234)	148 (196)	118	173 (221)	114.3 ⁰ -0.025	35 ₀ ^{+0.01}	76	18.0 (24.0)	
44D B R2 D	265 (313)	186 (234)	148 (196)	112		114.3 ⁰ -0.025		76	18.0 (24.0)	
55D □ F2 □	336 (380)	223 (267)	185 (229)	143	210 (254)	114.3 ⁰ -0.025	42 _{-0.016}	110	22.0 (28.0)	
75D D F2 D	382 (426)	269 (313)	231 (275)	189	256 (300)	114.3 ⁰ -0.025	42 _{-0.016}	110	30.0 (35.5)	

11

5/

- Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to the section Shaft End Specifications. Refer to the section Connector Specifications.

SGM7G-1A and -1E



Unit: mm

Model		LL	LM	L1	12	LB	KL1	Shaft En	d Dimer	nsions	Approx. Mass [kg]
SGM7G-			2					S	S1	Q	Approx. mass [kg]
1ADDF2D	449 (500)	333 (384)	295 (346)	227	319 (371)	200 _{-0.046}	188	42 _{-0.016}	50	110	57.5 (65.5)
1EDOF2O	511 (600)	395 (484)	357 (446)	289	382 (470)	200 ⁰ -0.046	188	55 ^{+0.030} _{+0.011}	60	110	67.5 (79.5)

Note: 1. The values in parentheses are for Servomotors with Holding Brakes. 2. Servomotors with Dust Seals have the same dimensions. 3. Refer to the section Shaft End Specifications. Refer to the section Connector Specifications.

Shaft End Specifications

SGM7G-DDDDDDD

Code	Specification
2 or S*	Straight without key
6 or K*	Straight with key and tap for one location (Key slot is JIS B1301-1996 fastening type.)


Shaft End Details		Servomotor Model SGM7G-								
		05	09	13	20	30 44	55 75	1A	1E	
Code: 2 or S* (Straight without Key)										
	LR	40	58	58	58	79	113	11	6	
	Q	30	40	40	40	76		110		
	S	16 _ _{-0.011}	19 _{-0.013}	22 ⁰ -0.01 ³	24 ⁰ -0.013	35 ^{+0.01} 0	42 ⁰ -0.016	42 ⁰ -0.016	55 +0.030 +0.011	
Code: 6 or K* (Straight with Key and Ta	ap)									
	LR	40	58	58	58	79	113	11	6	
	Q	30	40	40	40	76		110		
	QK	20	25	25	25	60		90		
	S	16 _{-0.011}	0 19 _{-0.013}	0 22 _{-0.013}	24 _{-0.013}	35 ₀ ^{+0.01}	42 _{-0.016}	42 _{-0.016}	+0.030 55 _{+0.011}	
	W	5	5	6	8	10		12	16	
	Т	5	5	6	7		8		10	
	U	3	3	3.5	4		5		6	
	Ρ		M5 screw	, Depth: 12		M12 screw, Depth: 25	M16 x 3	32L	M20 x 40L	

* The code for the shaft end depends on the model: SGM7G-05, -20, -30, -44, -55, -75, -1A, or -1E: 2 or 6 SGM7G-09 or -13: S or K

Connector Specifications


SGM7G-05D F to -44D F and SGM7G-05D R to -30D R

• Encoder Connector Specifications



	1	PG 5V
Receptacle	2	PG 0V
Size: M12	3	FG
	4	BAT (+)
Part number: 1419959	5	BAT (-)
Madal CACC MCO MIGNE DE D.D.CCO	6	Data (+)
Model: SACC-MSQ-M12MS-25-3,2 SCO	7	Data (-)
Manufacturer: Phoenix Contact	8	Empty
	Housing	Shield


• Servomotor Connector Specifications



Receptacle	1	V
Size: M23	2	(Brake)
Part number: 1617905	4	(Brake)
Fait number. 1017905	5	U
Model: ST-5EP1N8AAD00S	6	W
WOULD ST-SEF TNOAAD003	FG	FG
Manufacturer: Phoenix Contact	Housing	Shield
	-	

SGM7G-55DDF to -1EDDF and SGM7G-44DDR


• Encoder Connector Specifications



Receptacle 2 Size: M12 3
Size: M12 3
Part number: 1419959 4
Fait number. 1419909 5
Model: SACC-MSQ-M12MS-25-3,2 SCO
WIULEI. SACC-WISQ-WITZWIS-23-3,2 300 7
Manufacturer: Phoenix Contact
Handiacturer. I Hoenix Oontact

1	PG 5V
2	PG 0V
3	FG
4	BAT (+)
5	BAT (-)
6	Data (+)
7	Data (-)
8	Empty
Housing	Shield

• Servomotor Connector Specifications



Receptacle Size: M40 Part number: 1607927 Model: SM-5EPWN8AAD00S Manufacturer: Phoenix Contact


U	U
V	V
W	W
+	(Brake)
7	(Brake)
FG	FG
Housing	Shield


Servomotor Connector Rotational Angle

Allowable number of rotations: 10


SGM7G-05DDD to -20DDD

SGM7G-30DDD, -44DDF





SGM7G-44D□R, -55D□F, -75D□F, -1AD□F and -1AD□F



Rotary Motors

Content - Linear Servomotors



Content - Linear Servomotors

Linear Servomotors

SGLF (Models with F-Type Iron Cores)

66

F (Models with F-Type Iron Cores) SG

Model Designations

Moving Coil

SGL	F	W2	-	30	D	070	А	S	1	Ε	
Sigma-7 Series Linear Servomotors:	 1st	2nd		3rd + 4th	5th	 6th - 8th	9th	 10th	11th	12th	digit

digi	t - Servomotor Type
le	Specification
	With F-type iron core
	21
nd dig	it - Coil/Magnetic Way
ode	
12	Moving Coil
<	
d + 4	th digit - Magnet Height
de	Specification
	30 mm
	45 mm
	90 mm
)	135 mm
dia	it - Power Supply
ltage	
de	Specification

* Contact your YASKAWA representative for information on water-cooled model.

digit or Specification Specification Without polarity sensor, with thermal protector With polarity sensor and thermal protector

digit - Options **Cooling Method** Self-cooled Water-cooled* digit - Options Connection Metal round connector

(Phoenix)

Magnetic Way

D 400 VAC

SGL	F	M2	- 30	270	А	
 Sigma-7 Series	1st	2nd	3rd + 4th		8th	digit

Sigma-7 Series	1st	2nd
Linear Servomotors:		

1st dig	it - Servomotor Type		th digit -
Code	Specification	Length	of Magnetic Way
F	With F-type iron core	Code	Specification
		270	270 mm
2nd dig Moving	it - Coil/Magnetic Way	306	306 mm
	Specification	450	450 mm
M2	Magnetic Way	510	510 mm
1112	Maghoto Way	630	630 mm
3rd + 4	th digit - Magnet Height	714	714 mm
Code	Specification		
30	30 mm	8th dig	jit - Design Revis
45	45 mm	Order	
90	90 mm	Code	Specification
1D	135 mm	А	Standard Model


8th digit - Design Revision Order							
714	714 mm						
630	630 mm						
510	510 mm						
450	450 mm						
306	306 mm						
270	270 mm						

Note: This information is provided to explain model numbers. It is not meant to imply that models are available for all combinations of codes.


Precautions on Moving Coils with Polarity Sensors

Note: When you use a Moving Coil with a Polarity Sensor, the Magnetic Way must cover the bottom of the polarity sensor. Refer to the example that shows the correct installation. When determining the length of the Moving Coil's stroke or the length of the Magnetic Way, consider the total length (L) of the Moving Coil and the polarity sensor. Refer to the following table.


Correct Installation



Incorrect Installation



Total Length of Moving Coil with Polarity Sensor



Moving Coil Model SGLFW2-	Length of Moving Coil, L1 (mm)	Length of Polarity Sensor, A (mm)	Total Length, L (mm)		
30D070AS	70		97		
30D120AS	125	27	152		
30D230AS	230		257		
45D200AS	205		237		
45D380AS	384	32	416		
90D200AS	205	52	237		
90D380AS	384		416		

Rotary Motors

Contents

Ratings and Specifications: SGLFW2 Models

Specifications

Linear Servomotor Moving Coil		30D		45D		90D		1DD			
Model SGLFW2-		030A□	120A□	230A□	200A□	380A□	200A□	380A□	560A□	380A□	560A□
Time Rating		Continuous									
Thermal Class		В									
Insulation Resistance		500 VDC, 10 MΩ min.									
Withstand Voltage					1	,800 VAC	for 1 minu	te			
Excitation						Permane	nt magnet				
Cooling Method		Self-cooled or water-cooled*									
Protective Structure		IP00									
	Ambient Temperature	0°C to 40°C (without freezing)									
	Ambient Humidity	20% to 80% relative humidity (without condensation)									
Environmental Conditions	Installation Site	 Must be indoors and free of corrosive and explosive gases. Must be well-ventilated and free of dust and moisture. Must facilitate inspection and cleaning. Must have an altitude of 1,000 m or less. Must be free of strong magnetic fields. 									
Shock Resistance	Impact Acceleration Rate	196 m/s ²									
	Number of Impacts	2 times									
Vibration Resistance	Vibration Acceleration Rate	49 m/s² (the vibration resistance in three directions, vertical, side-to-side, and front-to-back)				back)					

* Contact your YASKAWA representative for information on water-cooled models.

Linear Servomotors SGLF

Contents

Ratings

Linear Servomotor Moving Co		30D		45D			
Model SGLFW2-		070A 🗆	120A 🗆	230A 🗆	200A□	380A	
Rated Motor Speed (Reference Speed during Speed Control)*1	m/s	4.0	4.0	4.0	4.0	4.0)
Maximum Speed*1	m/s	5.0	5.0	5.0	4.5	4.5	5
Rated Force*1, *2	Ν	45	90	180	280	560)
Maximum Force*1	Ν	135	270	540	840	1500	1680
Rated Current*1	Arms	1.4	1.5	1.5	2.2	4.3	}
Maximum Current*1	Arms	5.3	5.2	5.1	8.1	13.6	16.2
Moving Coil Mass	kg	0.50	0.90	1.7	2.9	5.4	Ļ
Force Constant	N/Arms	33.3	64.5	129.0	137.0	136	.7
BEMF Constant	Vrms / (m/s) / phase	11.1	21.5	43.0	45.6	45.	6
Motor Constant	N/ _\ _\	11.3	17.3	24.4	37.6	53.	2
Electrical Time Constant	ms	7.6	7.3	7.3	20	19.	6
Mechanical Time Constant	ms	3.9	3.0	2.9	2.1	1.9)
Thermal Resistance (with Heat Sink)	K/W	2.62	1.17	0.79	0.60	0.4	4
Thermal Resistance (without Heat Sink)	K/W	11.3	4.43	2.55	2.64	1.4	9
Magnetic Attraction N		200 630 1260		2120 4240			
Combined Magnetic Way, SGLF	30 🗆 🗆 🗛			45 □□□ A			
Combined Serial Converter Unit, JZDP-		651	652	653	654	655	
Applicable SERVOPACKs	SGD7S- SGD7W-	1 R9D 2R6D	1 R9D 2R6D	1R9D 2R6D	3R5D 2R6D	5R4D 5R4D	8R4D -


*1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. The values for other items are at 20°C. These are typical values.

*2. The rated forces are the continuous allowable force values at a ambient temperature of 40°C with an aluminum heat sink of the dimensions given in the following table. Heat Sink Dimensions:

150 mm × 100 mm × 10 mm: SGLFW2-30D070A
254 mm × 254 mm × 25 mm: SGLFW2-30D120A and -30D230A
400 mm × 500 mm × 40 mm: SGLFW2-45D200A and -45D380A

Linear Servomotors SGLF

Force-Motor Speed Characteristics



Notes:

1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. These are typical values.

2. The characteristics in the intermittent duty zone depend on the power supply voltage.

3. If the effective force is within the allowable range for the rated force, the Servomotor can be used within the intermittent duty zone.

4. If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque-motor speed characteristics will become smaller because the voltage drop increases.

Ratings

	-11		000		45		
Linear Servomotor Moving Co	DII		90D	1DD			
Model SGLFW2-		200A 🗆	380A 🗆	560A 🗆	380A 🗆	560A 🗆	
Rated Motor Speed (Reference Speed during Speed Control)*1	m/s	4.0	4.0	4.0	3.5	3.5	
Maximum Speed*1	m/s	4.0	4.0	4.0	3.5	3.5	
Rated Force*1, *2	Ν	560	1120	1680	1680	2520	
Maximum Force*1	Ν	1680	3360	5040	5040	7560	
Rated Current*1	Arms	3.8	7.7	11.5	10.9	16.3	
Maximum Current*1	Arms	14.0	28.0	42.0	39.7	59.6	
Moving Coil Mass	kg	5.3	10.1	14.9	14.6	21.5	
Force Constant	N/Arms	154.0	154.0	154.0	163.0	163.0	
BEMF Constant	Vrms / (m/s) / phase	51.3	51.3	51.3	54.3	54.3	
Motor Constant	N/\sqrt{W}	59.2	83.7	102	103	126	
Electrical Time Constant	ms	24	24	24	25	25	
Mechanical Time Constant	ms	1.5	1.4	1.4	1.4	1.3	
Thermal Resistance (with Heat Sink)	K/W	0.45	0.21	0.18	0.18	0.12	
Thermal Resistance (without Heat Sink)	K/W	1.81	1.03	0.72	0.79	0.55	
Magnetic Attraction	Ν	4240	8480	12700	12700	19100	
Combined Magnetic Way, SGLFM2-		90 00 A			1DDDDA		
Combined Serial Converter Unit, JZDP-		657	658	659	660	661	
Applicable SERVOPACKs	SGD7S-	5R4D	120D	170D	170D	260D*3	

*1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. The values for other items are at 20°C. These are typical values.

*2. The rated forces are the continuous allowable force values at a ambient air temperature of 40°C with an aluminum heat sink of the dimen-sions given in the following table. Heat Sink Dimensions:


Dimensions: • 400 mm × 500 mm × 25 mm: SGLFW2-90D200A • 609 mm × 762 mm × 40 mm: SGLFW2-90D380A • 900 mm × 762 mm × 40 mm: SGLFW2-90D560A and -1DD380A • 1400 mm × 900 mm × 40 mm: SGLFW2-1DD560A

*3. Contact your YASKAWA representative for information on these servopack models.

Appendix

Linear Servomotors SGLF

Force-Motor Speed Characteristics




Notes:


- 1. These values are for operation in combination with a SERVOPACK when the temperature of the armature winding is 100°C. These are typical values.
- 2. The characteristics in the intermittent duty zone depend on the power supply voltage.
- 3. If the effective force is within the allowable range for the rated force, the Servomotor can be used within the intermittent duty zone.
- 4. If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque-motor speed characteristics will become smaller because the voltage drop increases.




Servomotor Overload Protection Characteristics

The overload detection level is set for hot start conditions with a Servomotor ambient air temperature of 40°C.








Notes:


The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher. Use the Servomotor so that the effective force remains within the continuous duty zone given in Force-Motor Speed Characteristics.

External Dimensions SGLFW2-30

Moving Coil with Polarity Sensor: SGLFW2-30D070AS



Moving Coil without Polarity Sensor: SGLFW2-30D070AT




Moving Coil Model SGLFM2-	L1	L2	L3	Approx. Mass [kg]
30D070AS	70	10	EA C	0.6
30D070AT	70	40	54.6	0.6

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-30 and -45.

L1

Moving Coils with Polarity Sensors: SGLFW2-30DDDDAS




50 min.

Polarity sensor

Unit: mm

Moving Coils without Polarity Sensors: SGLFW2-30D




Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Mair Moving Coils with Polarity Sensors: SGLFW2-30 and -45.



Linear Motors

SERVOPACKs

Magnetic Ways: SGLFM2-30




Unit: mm

Note: More than one Magnetic Way can be connected. Connect the Magnetic Ways so that the reference marks on them are aligned in the same direction as shown in the figure.

Mgnetic Way Model SGLFM2-	L1±0.1	L2	Ν	Approx. Mass [kg]
30270A	270	225 (45 × 5)	6	0.9
30450A	450	405 (45 × 9)	10	1.5
30630A	630	585 (45 × 13)	14	2.0

SGLFW2-45




Moving Coils with Polarity Sensors: SGLFW2-45DDDDAS

SGLFW2-		L2		Tiatriess	Approx. Mass [kg]
45D200AS	205	89.5	187	0.2	2.9
45D380AS	384	268.5	365.5	0.3	5.5

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-30 and -45.


Moving Coils without Polarity Sensors: SGLFW2-45DDDDAT



Moving Coil Model SGLFW2-	L1	L2	L3	Flatness	Approx. Mass [kg]
45D200AT	205	89.5	187	0.2	2.9
45D380AT	384	268.5	365.5	0.3	5.5
100000A1	004	200.0	000.0	0.0	0.0

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-30 and -45.


Magnetic Ways: SGLFM2-45



Note: More than one Magnetic Way can be connected. Connect the Magnetic Ways so that the reference marks on them are aligned in the same direction as shown in the figure.

Mgnetic Way Model SGLFM2-	L1±0.1	L2	Ν	Approx. Mass [kg]
45306A	306	204 (102 × 2)	3	1.5
45510A	510	408 (102 × 4)	5	2.5
45714A	714	612 (102 × 6)	7	3.4

SGLFW2-90




Moving Coils with Polarity Sensors: SGLFW2-90DDDDAS

Unit: mm

Moving Coil Model SGLFW2-	L1	L2	L3	Flatness	Approx. Mass [kg]
90D200AS	205	89.5	187	0.2	5.3
90D380AS	384	268.5	365.5	0.3	10.1
90D560AS	563	447.5	544	0.3	14.9

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sens ---- SGLFW2-90 and -1D.


Moving Coils without Polarity Sensors: SGLFW2-90DDDDAT



Moving Coil Model SGLFW2-	L1	L2	L3	Flatness	Approx. Mass [kg]
90D200AT	205	89.5	187	0.2	5.3
90D380AT	384	268.5	365.5	0.3	10.1

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-90 and -1D.


Magnetic Ways: SGLFM2-90



Note: More than one Magnetic Way can be connected. Connect the Magnetic Ways so that the reference marks on them are aligned in the same direction as shown in the figure.


Magnetic Way Model SGLFM2-	L1±0.1	L2	Ν	Approx. Mass [kg]
90306A	306	204 (102 × 2)	3	2.6
90510A	510	408 (102 × 4)	5	4.2
90714A	714	612 (102 × 6)	7	5.9

SGLFW2-1D



Moving Coils with Polarity Sensors: SGLFW2-1DDDDDAS

Moving Coils without Polarity Sensors: SGLFW2-1DDDDDAT




Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-90 and -1D.

Moving Coil Model SGLFW2-	L1	L2	L3	Flatness	Approx. Mass [kg]
1DD380A	384	268.5	365.5	0.3	14.6
1DD560A	563	447.5	544	0.3	21.5

Refer to the following section for the connector specifications for the Sensor Cable and Servomotor Main Circuit Cable or Moving Coils with Polarity Sensors: SGLFW2-90 and -1D.

Magnetic Ways: SGLFM2-1DDDDA



Note: More than one Magnetic Way can be connected. Connect the Magnetic Ways so that the reference marks on them are aligned in the same direction as shown in the figure.

Magnetic Way Model SGLFM2-	L1±0.1	L2	N	Approx. Mass [kg]
1D306A	306	204 (102 × 2)	3	3.7
1D510A	510	408 (102 × 4)	5	6.2
1D714A	714	612 (102 × 6)	7	8.6

Contents

Connector Specifications

Moving Coils with Polarity Sensors: SGLFW2-30 and -45

Servomotor Connector



Connector: ST-5EP1N8A9003S (1607706) Contact: ST-10KP030 (1618261) From Phoenix Contact GmbH & Co. KG

1	-
3	Phase U
4	Phase V
6	-
7	Phase W
Ground	FG
Case	Shield

1

2

З


4

5

6 7 8

9

• Polarity Sensor and Thermostat Connector




Pin connector: 17JE-23090-02 (D8C) -CG From DDK Ltd.

Mating Connector Socket connector: 17JE-13090-02 (D8C) A-CG Studs: 17L-002C or 17L-002C1


+5 V (thermal protector) +5 V (power supply)
Su
Sv
Sw
0 V (power supply)
Not used
Thermal protector

Polarity Sensor Output Signal

The following figures show the relationship between the Su, Sv, and Sw polarity sensor output signals and the inverse power of each motor phase Vu, Vv, and Vw when the Moving Coil moves in the direction indicated by the arrow in the dimensional drawings of the Moving Coil.




SGLFW2-45D200AS SGLFW2-45D380AS



Moving Coils without Polarity Sensors: SGLFW2-30 and -45

• Servomotor Connector



• Thermostat Connector

2	[1]
	[2]

Receptacle housing: 5557-02R
Terminals: 5556T or 5556TL

Connector: ST-5EP1N8A9003S (1607706)

Contact: ST-10KP030 (1618261) From Phoenix Contact GmbH & Co. KG

Mating Connector Plug housing: 5559-02P Terminals: 5558T or 5558TL

From Molex Japan Co., Ltd.

1	-
3	Phase U
4	Phase V
6	-
7	Phase W
Ground	FG
Case	Shield

1	Thermal protector
2	Thermal protector

Moving Coils with Polarity Sensors: SGLFW2-90 and -1D

Servomotor Connector



Connector: SF-5EP1N8A90A2 (1605496) Contact: SF-7MP2000 (1605626) From Phoenix Contact GmbH & Co. KG

1	Phase V
2	-
4	-
5	Phase U
6	Phase W
Ground	FG
Case	Shield

• Polarity Sensor and Thermostat Connector

_	
	\dots
$\left\ O \right\ $	

Pin connector: 17JE-23090-02 (D8C) -CG From DDK Ltd. Mating Connector

Socket connector: 17JE-13090-02 (D8C) A-CG Studs: 17L-002C or 17L-002C1

1	+5 V (thermal protector) +5 V (power supply)
2	Su
3	Sv
4	Sw
5	0 V (power supply)
6	
7	Not used
8	
9	Thermal protector


SERVOPACKs

Appendix

Moving Coils without Polarity Sensors: SGLFW2-90D and -1DD

Servomotor Connector

• Polarity Sensor Output Signal



Connector: SF-5EP1N8A90A2 (1605496) Contact: SF-7MP2000 (1605626) From Phoenix Contact GmbH & Co. KG

The figure on the right shows the relationship between the Su, Sv, and Sw polarity sensor output signals and the inverse power of each motor phase Vu, Vv, and Vw when the Moving Coil moves

in the direction indicated by the arrow in the dimensional drawings of the Moving Coil.

4	-
5	Phase U
6	Phase W
Ground	FG
Case	Shield

Phase V

1

2


• Thermostat Connector

1	
2	

Receptacle housing: 5557-02R Terminals: 5556T or 5556TL From Molex Japan Co., Ltd.

Mating Connector Plug housing: 5559-02P Terminals: 5558T or 5558TL

1	Thermal protector
2	Thermal protector



Electrical angle (°)

Content - SERVOPACKs



Content - SERVOPACKs

SERVOPACKs

SGD7S SGD7W



SGD7S Single Axis

Model Designation

Single Axis Amplifier

280 11.0kW 370 15.0kW

SG	D7S	-	1R9	D	AC)	В	000	F64			
Sigma-7 Sigma-7	7 Series 7S Models		1st 3rd	4th	5th + 6	_ 6th	7th	8th 10th	 11th 13	th digit		
	3rd digit - M Capacity	axim	um Applicabl	le	4th dig						10th digit - vare Options Specificat	ions
Code		ion			Code D	Spec 400 V	ificatior / AC	1		Code		Applicable Models
Three	phase, 400	V								000	Without Options	All models
1R9	0.5 kW				5th + 6	oth dig	it - Inter	face		026	With relay for holding	All models
3R5	1.0 kW				Code	Spec	ification	ı		020	brake	Airmoueis
5R4 8R4	1.5 kW 2.0 kW				A0	Ether comr		ion reference				
120	2.0 kW					MEC	HATRO	LINK-III *, RJ4	5	11th	. 13th digit - FT/EX Spe	cification
					30	comr	nunicat	ion reference		Code	Specification	
170	5.0 kW									F64	Zone table	
210	6.0 kW				7th dig	git - De	sign Re	vision Order		Bolded c	ptions are considered standa	rd
260	7.5 kW				В		dard Mo			warehouse products.		
000	44.01.144											

Ratings and Specifications

Ratings

Three-phase, 400 VAC

Model SGD7S-			1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applic	able Motor Capac	ity [kW]	0.5	1	1.5	2	3	5	6	7.5	11	15
Continuous Out	out Current [Arms]		1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneous N	laximum Output C	urrent [Arms]	5.5	8.5	14	21	28	42	55	65	70	85
Main Circuit	Power Supply			Т	hree-phase	e, 380 VAC	to 480 VA	C, -15% to	> +10%, 50) Hz/60 Hz		
Iviain Circuit	Input Current [/	t Current [Arms]*		2.9	4.3	5.8	8.6	14.5	17.4	21.7	31.8	43.4
Control Douvor	Powe	er Supply					24 VDC	±15%				
Control Power Supply Input Current [Arms]*		1.2						1.4		1.	.5	
Power Supply C	apacity [kVA]*		1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6
	Main Circuit Po	Circuit Power Loss [W]		30	62.3	89.4	136.8	188.7	188.4	228.5	278.2	389.8
	Control Circuit	rol Circuit Power Loss [W]			21			22	2	28	3	2
Power Loss*	Built-in Regene Power Loss [W	t-in Regenerative Resistor ver Loss [W]		14	28	28	28	36	(18	30)*	(24	·0)*
	Total Power Lo	ss [W]	54.2	65	111.3	138.4	185.5	246.7	216.4	256.5	310.2	389.8
	Built-In	Resistance $[\Omega]$	75	75	75	43	43	27		-		
Regenerative	Regenerative Resistor	Capacity [W]	70	70	140	140	140	180		-		
Resistor	Minimum Allow Resistance [Ω]	Minimum Allowable External		75	75	43	43	27	1	8	14.	.25
Overvoltage Cat												

* This is the net value at the rated load.

540 VDC

Model SGD7S-			1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applic	able Motor	Capacity [kW]	0.5	1	1.5	2	3	5	6	7.5	11	15
Continuous Out	out Current	[Arms]	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneous N	laximum Ou	Itput Current [Arms]	5.5	8.5	14	21	28	42	55	65	70	85
Main Circuit	Power S	Supply				513VDC	to 648 VD	C, -15% to	o +10 %			
Main Circuit	Input Cu	out Current [Arms]*		3.3	5.5	6.8	11	18	19.6	26.2	38.3	47.6
Cantral Douver	uppelu	Power Supply	24 VDC ±15 %									
Control Power S	upply	Input Current [Arms]*			1.	2			1	.4	1.	.5
Power Supply C	apacity [kVA	4]*	1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6
	Main Cir	cuit Power Loss [W]	16.4	24.4	48.5	73.7	110.4	144.5	188.4	228.5	278.2	389.8
	Control	Circuit Power Loss [W]			21			22	2	.8	3	2
Power Loss*		Built-in Regenerative Resistor Power Loss [W]		14	28	28	28	36	(18	30)*	(24	.0)*
	Total Po	wer Loss [W]	37.4	45.4	69.5	94.7	131.4	166.5	216.4	228.5	310.2	389.8
Overvoltage Category							II					


* This is the net value at the rated load.

SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C*.

An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed.

The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics. In most cases, that will be the overload protection characteristics of the Servomotor.



Note:

The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher For a YASKAWA-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the

torque-motor speed characteristic of the Servomotor.

* However, the range for the SGD7S-370D is -5°C to 40°C.

Specifications using EtherCAT Communication Reference

Control Method			Specification
CONTROLIVIETTOO			IGBT-based PWM control, sine wave current drive
oonaonnoanoa	With Rotary Servo	motor	Serial encoder: 24 bits (incremental encoder/absolute encoder)
Feedback	With Linear Servo		 Absolute linear encoder (The signal resolution depends on the absolute linear encoder.) Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)
	Surrounding Air Te	emperature*1	-5°C to 55°C (60°C with derating) However, the range for the SGD7S-370D is -5°C to 40°C.
	Storage Temperat	ture	-20°C to 85°C
	Surrounding Air H	lumidity	95 % relative humidity max. (with no freezing or condensation)
	Storage Humidity		95% relative humidity max. (with no freezing or condensation)
	Vibration Resistar	nce	4.9 m/s ²
Environmental	Shock Resistance)	19.6 m/s ²
Conditions	Degree of Protect	ion	IP10
	Pollution Degree		 2 Must be no corrosive or flammable gases. Must be no exposure to water, oil, or chemicals. Must be no dust, salts, or iron dust.
	Altitude		1,000 m or less (above 1,000 m with derating)
			Do not use the SERVOPACK in the following locations: Locations subject to static electricity
Applicable Standard	Others ds		noise, strong electromagnetic/magnetic fields, or radioactivity Refer to the section Compliance with UL Standards, EU Directives, and Other Safety Standards (in Combination with SERVOPACK).
Mounting			Base-mounted
	Speed Control Ra	inge	1:5,000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)
			± 0.01 % of rated speed max. (for a load fluctuation of 0 % to 100 %)
	Coefficient of Spe	ed Eluctuation*2	0% of rated speed max. (for a voltage fluctuation of ± 10 %)
Performance			
			\pm 0.1 % of rated speed max. (for a temperature fluctuation of 25 °C \pm 25 °C)
	Torque Control Pr	ecision (Repeatability)	±1 %
	Soft Start Time Se	etting	0s to 10s (Can be set separately for acceleration and deceleration.)
		0	Phase A, phase B, phase C: Line-driver output
	Encoder Divided F	Pulse Output	Number of divided output pulses: Any setting is allowed
	Linear Servomoto	r Overheat Protection	Number of input points: 1
	Signal Input		Input voltage range: 0 V to +5 V
	Sequence Input Signals	Input Signals that can be allocated	Number of input points: 7 Input method: Sink inputs or source inputs Input Signals • P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals • /Probe1 (Probe 1 Latch Input) signal • /Probe2 (Probe 2 Latch Input) signal • /Home (Home Switch Input) signal
			 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed.
			 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC
		Fixed Output	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1
I/O Signals		Fixed Output	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals
I/O Signals	Sequence Output Signals	Fixed Output Output Signals that can be allocated	A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.)
I/O Signals	Output Signals	Output Signals that can	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /VLT (Speed Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /ZONE0 (ZONE Signal 1 Output) signal /ZONE1 (ZONE Signal 3 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE4 (nzONE Output) signal /ZONE5 (nzONE Output) signal
/O Signals	Output Signals	Output Signals that can be allocated	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /MLT (Speed Limit Detection) signal /WARN (Warning) signal /NEAR (Near) signal /ZONE0 (ZONE Signal 1 Output) signal /ZONE2 (ZONE Signal 3 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /NZONE (nZONE Output) signal /DONE (DUPUE) signal /ZONE1 (JONE Signal 4 Output) signal /JONE1 (JUSP-OP05A-1-E)
/O Signals	RS-422A Communications	Output Signals that can be allocated	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /ZONE1 (ZONE Signal 1 Output) signal /ZONE1 (ZONE Signal 3 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /IZONE6 (InZONE Output) signal /IZONE6 (InZONE Output) signal /IZONE6 (InZONE Output) signal /IZONE7 (JUSP-OP05A-1-E) Up to N = 15 stations possible for RS-422A port
	Output Signals	Output Signals that can be allocated	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /ZONE1 (ZONE Signal 1 Output) signal /ZONE1 (ZONE Signal 3 Output) signal /ZONE2 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /IZONE0 (JUSP-OP05A-1-E) Up to N = 15 stations possible for RS-422A port
	RS-422A Communications (CN502)	Output Signals that can be allocated	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /ZONE0 (ZONE Signal 1 Output) signal /ZONE0 (ZONE Signal 2 Output) signal /ZONE1 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /DONE3 (ZONE Signal 4 Output) signal /DONE3 (ZONE Signal 4 Output) signal /DONE3 (ZONE Signal 4 Output) signal /DONE1 (JUSP-OP05A-1-E) Up to N = 15 stations possible for RS-422A port Set with parameters. Personal Computer (with SigmaWin+)
I/O Signals	RS-422A Communications	Output Signals that can be allocated	 /SI0 and /SI3 (General-Purpose Input) signals A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /V-CMP (Speed Coincidence Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /ZONE1 (ZONE Signal 1 Output) signal /ZONE1 (ZONE Signal 3 Output) signal /ZONE2 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Signal 4 Output) signal /ZONE1 (JUSP-OP05A-1-E) Up to N = 15 stations possible for RS-422A port

Continued from previous page.

Item		Specification				
Displays/Indicators		CHARGE, PWR, RUN, ERR, and L/A (A and B) indicators, and one-digit seven-				
EtherCAT Communica	tions Setting Switches	segment display EtherCAT secondary address (S1 and S2), 16 positions				
	Applicable Communications Standards	IEC 61158 Type 12, IEC 61800-7 CiA402 Drive Profile				
	Physical Layer	100BASE-TX (IEEE 802.3)				
	Communications Connectors	CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector				
	Cable	Category 5, 4 shielded twisted pairs * The cable is automatically detected with AUTO MDIX.				
	Sync Manager	SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SN Process data input				
EtherCAT Communi-	FMMU	FMMU 0: Mapped in process data output (RxPDO) area. FMMU 1: Mapped in process data input (TxPDO) area. FMMU 2: Mapped to mailbox status.				
cations	EtherCAT Commands (Data Link Layer)	APRD, FPRD, BRD, LRD, APWR, FPWR, BWR, LWR, ARMW, and FRMW (APRW, FPRW, BRW, and LRW commands are not supported.)				
	Process Data	Assignments can be changed with PDO mapping.				
	Mailbox (CoE)	Emergency messages, SDO requests, SDO responses, and SDO information (TxPDO/RxPDO and remote TxPDO/RxPDO are not supported.)				
	Distributed Clocks	Free-Run Mode and DC Mode (Can be switched.) Applicable DC cycles: 125 µs to 4 ms in 125-µs increments				
	Slave Information Interface	256 bytes (read-only)				
	Indicators	EtherCAT communications in progress: Link/Activity x 2 EtherCAT communications status: RUN x 1 EtherCAT error status: ERR x 1				
CiA402 Drive Profile		 Homing Mode Profile Position Mode Interpolated Position Mode Profile Velocity Mode Profile Torque Mode Cyclic Synchronous Position Mode Cyclic Synchronous Velocity Mode Cyclic Synchronous Torque Mode Touch Probe Function Torque Limit Function 				
Analog Monitor (CN5)		Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1 %): 1.2 ms (Typ)				
Dynamic Brake (DB)		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.				
Regenerative Process	ng	Built-in Refer to the catalog for details.				
Overtravel (OT) Preven	tion	Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal				
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.				
Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.				
	Inputs	/HWBB1 and /HWBB2: Base block signals for Power Modules				
Safety Functions	Output	EDM1: Monitors the status of built-in safety circuit (fixed output).				
	Applicable Standards*3	ISO13849-1 PLe (Category 3), IEC61508 SIL3				
Applicable Option Mod	dules	Fully-closed Modules, Option Module Safety				

*1. If you combine a Sigma-7 SERVOPACK with a Sigma-V Option Module, the surrounding air temperature specification of the Sigma-V SERVOPACKs must be used, i.e., 0 °C to 55 °C. Also, the applicable surrounding range cannot be increased by derating.

*2. The coefficient of speed fluctuation for load fluctuation is defined as follows: Coeficient of speed fluctuation = No-load motor speed - Total-load motor speed × 100%

Rated motor speed

*3. The SGD7S-210D, -260D, -280D, and -370D do not have a dynamic brake (DB). If a dynamic brake is necessary, create an external dynamic brake circuit.

*4. Always perform risk assessment for the system and confirm that the safety requirements are met.

Specifications using MECHATROLINK-III Communication Reference

Item			Specification
Drive Method			IGBT-based PWM control, sine wave current drive
	With Rotary Servon	notor	Serial encoder: 24 bits (incremental encoder/absolute encoder)
Feedback			Absolute linear encoder (The signal resolution depends on the absolute linear encoder.)
Teeuback	With Linear Servom	otor	Incremental linear encoder (The signal resolution depends on the incremental linear
			encoder or Serial Converter Unit.)
	Surrounding Air Ten	nperature*1	-5°C to 55°C (60°C with derating) However, the range for the SGD7S-370D is -5°C to 40°C.
	Storage Temperatu	۲ <u>۵</u>	-20°C to 85°C
	Surrounding Air Hu		
	Storage Humidity	multy	95% relative humidity max. (with no freezing or condensation) 95% relative humidity max. (with no freezing or condensation)
	Vibration Resistance	۵	4.9 m/s ²
En inconstal	Shock Resistance		19.6 m/s ²
Environmental Conditions	Degree of Protectio	n	IP10
Conditions	0		2
	Pollution Degree		 Must be no corrosive or flammable gases.
	r olladori Bogroo		Must be no exposure to water, oil, or chemicals.
	Altitude		Must be no dust, salts, or iron dust.
	Allitude		1,000 m or less (above 1,000 m with derating) Do not use the SERVOPACK in the following locations: Locations subject to static electricity
	Others		noise, strong electromagnetic/magnetic fields, or radioactivity
			Refer to the section Compliance with UL Standards, EU Directives, and Other Safety Standards
Applicable Standards			(in Combination with SERVOPACK).
Mounting			Base-mounted
5			1:5,000 (At the rated torque, the lower limit of the speed control range must not cause the
	Speed Control Ran	ge	Servomotor to stop.)
			±0.01 % of rated speed max. (for a load fluctuation of 0 % to 100 %)
	Coefficient of Speed	b	
Performance	Fluctuation*2		0% of rated speed max. (for a voltage fluctuation of $\pm 10\%$)
			± 0.1 % of rated speed max. (for a temperature fluctuation of 25 °C \pm 25 °C)
	Torque Control Pred	cision (Repeatability)	±1%
	Soft Start Time Set	tina	0s to 10s (Can be set separately for acceleration and deceleration.)
			Phase A, phase B, phase C: Line-driver output
	Encoder Divided Pu	ilse Output	Number of divided output pulses: Any setting is allowed.
	Linear Servomotor	Overheat Protection	Number of input points: 1
	Signal Input		Input voltage range: 0 V to +5 V
			Allowable voltage range: 24 VDC \pm 20 %
			Number of input points: 7
			Input method: Sink inputs or source inputs
	O a muse a la mut	Input Signals that can	Input Signals /DEC (Origin Return Deceleration Switch) signal
	Sequence Input Signals	be allocated	 /EXT1 to /EXT3 (External Latch Input 1 to 3) signals
	olghaid	boallocatod	 P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals
			• /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals
			 /P-DET (Polarity Detection) signal
			A signal can be allocated and the positive and negative logic can be changed.
		Fixed Output	Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1
		r ixed Output	Output signal: ALM (Servo Alarm) signal
I/O Signals			Allowable voltage range: 5 VDC to 30 VDC
. o olgi lalo			Number of output points: 5
			(A photocoupler output (isolated) is used.)
			Output Signals /COIN (Positioning Completion) signal
			 /V-CMP (Speed Coincidence Detection) signal
			 /TGON (Rotation Detection) signal
	Sequence Output		 /S-RDY (Servo Ready) signal
	Signals	Output Signals that	 /CLT (Torque Limit Detection) signal
		can be allocated	VLT (Speed Limit Detection) signal
			 /BK (Brake) signal AMA DN (Marriag) signal
			 /WARN (Warning) signal /NEAR (Near) signal
			 /NEAR (Near) signal /ZONE0 (ZONE Signal 1 Output) signal
			 /ZONE1 (ZONE Signal 2 Output) signal
			 /ZONE2 (ZONE Signal 3 Output) signal
			 /ZONE3 (ZONE Signal 4 Output) signal
			 /nZONE (nZONE output) signal
			A signal can be allocated and the positive and negative logic can be changed.
	DO 4004 O	Interfaces	Digital Operator (JUSP-OP05A-1-E)
	RS-422A Commu- nications (CN3)	1:N Communications	Up to N = 15 stations possible for RS-422A port
	100003 (0140)	Axis Address Setting	Set with parameters.
			Personal Computer (with SigmaWin+)
Communications		Interface	
Communications	USB Communica-	Interface	The software version of the SigmaWin+ must be version 7.11 or higher.
Communications	USB Communica- tions (CN7)	Communications	
Communications			The software version of the SigmaWin+ must be version 7.11 or higher. Conforms to USB 2.0 standard (12 Mbps).

Continued from previous page.

Item		Specification				
	Communications Protocol	MECHATROLINK-III				
MECHATROLINK-III	Station Address Settings	03 to EF hex (maximum number of slaves: 62) The rotary switches (S1 and S2) are used to set the station address.				
Communications	Transmission Speed	100 Mbps				
	Transmission Cycle	125 μs, 250 μs, 500 μs, 750 μs, 1.0 ms to 4.0 ms (multiples of 0.5 ms)				
	Number of Transmission Bytes	32 or 48 bytes/station A DIP switch (S3) is used to select the number of transmission bytes.				
	Performance	Position, speed, or torque control with MECHATROLINK-III communications				
Reference Method	Reference Input	MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.)				
	Profile	MEACHATROLINK-III standard servo profile				
MECHATROLINK-III G	ommunications Setting Switches	Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V)				
Analog Monitor (CN5)		Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)				
Dynamic Brake (DB)		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.				
Regenerative Processi	ng	Built-in Refer to the catalog for details.				
Overtravel (OT) Preven	tion	Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal				
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.				
Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.				
	Inputs	/HWBB1 and /HWBB2: Base block signals for Power Modules				
Safety Functions	Output	EDM1: Monitors the status of built-in safety circuit (fixed output).				
	Applicable Standards*3	ISO13849-1 PLe (Category 3), IEC61508 SIL3				
Applicable Option Modules		Fully-closed Modules				

*1. If you combine a Sigma-7 SERVOPACK with a Sigma-V Option Module, the surrounding air temperature specification of the Sigma-V SERVOPACKs must be used, i.e., 0 °C to 55 °C. Also, the applicable surrounding range cannot be increased by derating.

*2. The coefficient of speed fluctuation for load fluctuation is defined as follows: Coefficient of speed fluctuation = $\frac{\text{No-load motor speed}}{\text{Rated motor speed}} \times 100\%$

*3. The SGD7S-210D, -260D, -280D, and -370D do not have a dynamic brake (DB). If a dynamic brake is necessary, create an external dynamic brake circuit.

*4. Always perform risk assessment for the system and confirm that the safety requirements are met.


Front Cover Dimensions and Connector Specifications


The front cover dimensions and panel connectors depend on the SERVOPACK interface. Refer to the following figures.

Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

• Front Cover Dimensions and Connectors






* Dynamic Brake Connector only for SGD7S-1R9D up to -170D.

• Connector Specifications

Connector No.	Function	Model	YASKAWA Order Code	Number of Pins	Manufacturer
CN1	I/O Connector	DFMC1,5/15-ST-3,5-LRBK	JUSP-7CN001	30	Phoenix Contact
CN2	Encoder Connector	-	JZSP-CMP9-1-E	6	Sumitomo 3M Ltd.
CN3	Digital Operator	-	-	14	Honda Tsushin Kogyo Co., Ltd.
CN6A/ CN6B	Fieldbus Connector	-	-	8	Tyco Electronics Japan G.K.
CN7	USB Connector for Sig- maWin	-	-	5	Tyco Electronics Japan G.K.
CN8	Safety Connector Kit	-	2013595-1	8	Tyco Electronics Japan G.K.
CN8	Safety Jumper Connector	-	JZSP-CVH05-E	8	Tyco Electronics Japan G.K.
CN101	Main Power Connector SGD7S-1R9D to -170D	BLZ 7.62HP/08/180LR SN BK BX PRT	JUSP-7CN101	8	Weidmüller
CNTUT	Main Power Connector SGD7S-210D to -370D	BUZ 10.16HP/07/180F AG BK BX LPR SO	JUSP-7CN101-1	7	Weidmüller
CN102	Motor Power Connector SGD7S-1R9D to -170D	BLZ 7.62IT/04/180MF4 SN BK BX PRT	JUSP-7CN102	4	Weidmüller
GNTUZ	Motor Power Connector SGD7S-210D to -370D	BUZ 10.16IT/04/180MF4 AG BK BX LPR SO	JUSP-7CN102-1	4	Weidmüller
CN103	DC Power Input SGD7S-1R9D to -170D	BVZ 7.62IT/04/180MF3 SN BK BX PRT	JUSP-7CN103	4	Weidmüller
CINTOS	DC Power Input SGD7S-210D to -370D	BUZ 10.16IT/04/180MF3 AG BK BX LPR SO	JUSP-7CN103-1	4	Weidmüller
CN115	Dynamic Brake Connector SGD7S-1R9D to -170D	BLZ 7.62IT/03/180MF2 SN BK BX PRT	JUSP-7CN115	3	Weidmüller
CITID	Dynamic Brake Connector SGD7S-210D to -370D	No integrated Dynamic Brake circuit.	External Dynamic Brak	e circuit is p	ossible as an option.
CN117	Holding Brake Connector	BLF 5.08HC/04/180LR SN BK BX SO	JUSP-7CN117	4	Weidmüller
CN201	24 V Control Power Input	BLF 5.08HC/04/180LR SN OR BX SO	JUSP-7CN201	4	Weidmüller

Base-mounted SERVOPACKs


• Three-Phase, 400 VAC: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, and -120D




Mounting Hole Diagram

Approx. mass: SGD7S-1R9D, -3R5D, or -5R4D: 3.4 kg SGD7S-8R4D or -120D: 3.7 kg Unit: mm

• Three-Phase, 400 VAC: SGD7S-170D






Approx. mass: 5.5 kg Unit: mm


Contents


Approx. mass: 13.5 kg Unit: mm


• Three-Phase, 400 VAC: SGD7S-210D and -260D



• Three-Phase, 400 VAC: SGD7S-280D and -370D







SGD7W Dual Axis

Model Designation

Dual Axis Amplifier

SGD7W	-	2R6	D	AO	В	-	
Sigma-7 Series Sigma-7W Models		1st 3rd	4th	5th + 6th	7th	8th 10th	digit

1st 3rd digit - Maximum Applicable Motor Capacity					
Code	Specification				
Three-	phase, 400 V				
2R6	2 × 0.75 kW				
5R4 2 × 1.5 kW					

4th digit - Voltage					
Code	Specification				
D	400 V AC				

5th + 6	5th + 6th digit - Interface						
Code	Specification						
A0	EtherCAT communication reference						
30	MECHATROLINK-III, RJ45 communication reference						
7th digit - Design Revision Order							

B Standard Model

8th 10th digit - Hardware Options Specifications					
Code	Specification	Applicable Models			
-	Without Options	All models			
026	With relay for holding brake	All models			

Bolded options are considered standard warehouse products.

Ratings and Specifications

Ratings

Three-phase, 400 VAC

Model SGD7W-		2R6D	5R4D		
Maximum Applica	ble Motor Capacity	0.75	1.5		
Continuous Outpu	It Current per Axis	2.6	5.4		
Instantaneous Ma	ximum Output Cur	rent per Axis [Arms]	8.5	14	
Main Circuit	Power Supply			, 380 V AC to 480 V AC, +10 %, 50 Hz/60 Hz	
	Input Current [Ar	ms]*	4.4	8.6	
Control	Power	Supply	24	VDC ±15%	
Control	Input C	Current [Arms]*		1.2	
Power Supply Cap	pacity [kVA]*		3.5	6.8	
	Main Circuit Pow	ver Loss [W]	65.4	108.6	
Power Loss*	Control Circuit P	ower Loss [W]	21		
Power Loss	Built-in Regenera	ative Resistor Power Loss [W]	28	28	
	Total Power Loss	s [VV]	114.4	157.6	
	Built-In	Resistance $[\Omega]$	43	43	
Regenerative Resistor	Regenerative Resistor	Capacity [W]	140	140	
	Minimum Allowa	ble External Resistance [Ω]	43	43	
Overvoltage Categ	gory		111		

* This is the net value at the rated load.


540 V DC

Model SGD7W-		2R6D	5R4D	
Maximum Applica	able Motor Capacity per Axis [kW]	0.75	1.5	
Continuous Outp	ut Current per Axis [Arms]	2.6	5.4	
Instantaneous Ma	aximum Output Current per Axis [Arms]	8.5	14	
Main Circuit	Power Supply	513VDC to -15 % to	o 648VDC, o +10%	
	Input Current [Arms]*	5	11	
Control	Power Supply	24VDC ±15%		
Control	Input Current [Arms]*	1.2		
Power Supply Ca	pacity [kVA]*	3.5	6.8	
	Main Circuit Power Loss [W]	47.4	90.6	
Power Loss*	Control Circuit Power Loss [W]	2	1	
	Total Power Loss [W]	68.4	111.6	
Overvoltage Cate	gory	I	11	

* This is the net value at the rated load.

SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C. An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed. The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics. In most cases, that will be the overload protection characteristics of the Servomotor.



Note:

The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher. For a YASKAWA-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the torque-motor speed characteristic of the Servomotor.

Contents

Specifications using EtherCAT Communication Reference

Item			Specification
Control Method			IGBT-based PWM control, sine wave current drive
	With Rotary Serve	omotor	Serial encoder: 24 bits (incremental encoder/absolute encoder)
Feedback	With Linear Servo		 Absolute linear encoder (The signal resolution depends on the absolute linear encoder. Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)
	Surrounding Air T	emperature	-5°C to 55°C (60°C with derating)
	Storage Tempera	ture	-20°C to 85°C
	Surrounding Air H		95 % relative humidity max. (with no freezing or condensation)
	Storage Humidity	,	95% relative humidity max. (with no freezing or condensation)
	Vibration Resistar		4.9 m/s ²
	Shock Resistance	Э	19.6 m/s ²
Environmental Conditions	Degree of Protect	tion	IP10
Conditions	Pollution Degree		 2 Must be no corrosive or flammable gases. Must be no exposure to water, oil, or chemicals. Must be no dust, salts, or iron dust.
	Altitude		1,000 m or less (above 1,000 m with derating)
	Others		Do not use the SERVOPACK in the following locations: Locations subject to static electricity
	Others		noise, strong electromagnetic/magnetic fields, or radioactivity
Applicable Standards	5		Refer to the section Compliance with UL Standards, EU Directives, and Other Safety Standards (in Combination with SERVOPACK).
Mounting			Base-mounted
	Speed Control Ra	ange	1:5,000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)
			± 0.01 % of rated speed max. (for a load fluctuation of 0 % to 100 %)
Performance	Coefficient of Spe	ed Fluctuation*1	0% of rated speed max. (for a voltage fluctuation of \pm 10 %)
			± 0.1 % of rated speed max. (for a temperature fluctuation of 25 °C \pm 25 °C)
	Torque Control Pr	recision (Repeatability)	±1%
	Soft Start Time S	0	0s to 10s (Can be set separately for acceleration and deceleration.)
	Signal Input	or Overheat Protection	Number of input points: 1 Input voltage range: 0 V to +5 V
	olgi lai li ipat		Allowable voltage range: 24 VDC \pm 20 %
			Number of input points: 10
			Input method: Sink inputs or source inputs
			Input Signals P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals
	Sequence Input	Input Signals that can be	 P-OT (Forward Drive Profilion) and N-OT (Reverse Drive Profilion) signals /Probe1 (Probe 1 Latch Input) signal
	Signals	allocated	/Probe2 (Probe 2 Latch Input) signal
			/Home (Home Switch Input) signal
			/P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit)
			signals
			A signal can be allocated and the positive and negative logic can be changed. Allowable voltage range: 5 VDC to 30 VDC
		Fixed Output	Number of output points: 1
I/O Signals			Output signal: ALM (Servo Alarm) signal
			Allowable voltage range: 5 VDC to 30 VDC
			Number of output points: 6 (A photocoupler output (isolated) is used.)
			Output Signals
	Sequence		/COIN (Positioning Completion) signal
	Output Signals	Output Ciapala that a	/V-CMP (Speed Coincidence Detection) signal //CON (Patation Detection) signal
		Output Signals that can be allocated	 /TGON (Rotation Detection) signal /S-RDY (Servo Ready) signal
		be allocated	 /CLT (Torque Limit Detection) signal
			/VLT (Speed Limit Detection) signal
			• /BK (Brake) signal
			/WARN (Warning) signal //LEAD (Marning) signal
			 /NEAR (Near) signal A signal can be allocated and the positive and negative logic can be changed.
	RS-422A	Interfaces	Digital Operator (JUSP-OP05A-1-E)
	Communications	1:N Communications	Up to N = 15 stations possible for RS-422A port
	(CN502)		
Communications	. ,	Axis Address Setting	Set with parameters.
	USB Communi-	Interface	Personal Computer (with SigmaWin+) The software version of the SigmaWin+ must be version 7.11 or higher.
		Communications	
	cations (CN7)	Communications	Conforms to USB 2.0 standard (12 Mbps).

Continued on next page.

Continued from previous page.

F C C S	ns Setting Switches Applicable Communications Standards Physical Layer Communications Connectors Cable Sync Manager	 CHARGE, PWR, RUN, ERR, and L/A (A and B) indicators, and two, one-digit seven-segment display EtherCAT secondary address (S1 and S2), 16 positions IEC 61158 Type 12, IEC 61800-7 CiA402 Drive Profile 100BASE-TX (IEEE 802.3) CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector Category 5, 4 shielded twisted pairs The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input FMMU 0: Mapped in process data output (RxPDO) area. 		
EtherCAT Communication A F C C S	Applicable Communications Standards Physical Layer Communications Connectors Cable Sync Manager	EtherCAT secondary address (S1 and S2), 16 positions IEC 61158 Type 12, IEC 61800-7 CiA402 Drive Profile 100BASE-TX (IEEE 802.3) CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector Category 5, 4 shielded twisted pairs The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input		
A F C S	Applicable Communications Standards Physical Layer Communications Connectors Cable Sync Manager	IEC 61158 Type 12, IEC 61800-7 CiA402 Drive Profile 100BASE-TX (IEEE 802.3) CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector Category 5, 4 shielded twisted pairs The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input		
(()	Communications Connectors Cable Sync Manager	CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector Category 5, 4 shielded twisted pairs The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input		
C	Cable Sync Manager	CN6B (RJ45): EtherCAT signal output connector Category 5, 4 shielded twisted pairs The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input		
S	Sync Manager	The cable is automatically detected with AUTO MDIX. SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output, and SM3: Process data input		
		Process data input		
F	FMMU	EMMU 0: Mapped in process data output (RxPDO) area		
EtherCAT Communi-		FMMU 1: Mapped in process data input (TxPDO) area. FMMU 2: Mapped to mailbox status.		
	EtherCAT Commands (Data Link Layer)	APRD, FPRD, BRD, LRD, APWR, FPWR, BWR, LWR, ARMW, and FRMW (APRW, FPRW, BRW, and LRW commands are not supported.)		
F	Process Data	Assignments can be changed with PDO mapping.		
Ν	/lailbox (CoE)	Emergency messages, SDO requests, SDO responses, and SDO information (TxPDO/RxPDO and remote TxPDO/RxPDO are not supported.)		
C	Distributed Clocks	Free-Run Mode and DC Mode (Can be switched.) Applicable DC cycles: 125 µs to 4 ms in 125-µs increments		
S	Slave Information Interface	256 bytes (read-only)		
Ir	ndicators	EtherCAT communications in progress: Link/Activity x 2 EtherCAT communications status: RUN x 1 EtherCAT error status: ERR x 1		
CiA402 Drive Profile		 Homing Mode Profile Position Mode Interpolated Position Mode Profile Velocity Mode Profile Torque Mode Cyclic Synchronous Position Mode Cyclic Synchronous Velocity Mode Cyclic Synchronous Torque Mode Touch Probe Function Torque Limit Function 		
Analog Monitor (CN5)		Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)		
Dynamic Brake (DB)		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.		
Regenerative Processing		Built-in Refer to the catalog for details.		
Overtravel (OT) Prevention	n	Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal		
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.		
Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.		
Ir	nputs	/HWBB_A1, /HWWB_A2, /HWWB_B1 and /HWBB_B2: Base block signals for Power Modules		
Safety Functions	Dutput	EDM_A and EDM_B: Monitor the status of built-in safety circuits (fixed outputs).		
A	Applicable Standards*2	ISO13849-1 PLe (Category 3), IEC61508 SIL3		
Applicable Option Modules		Option Module Safety		

*1. The coefficient of speed fluctuation for load fluctuation is defined as follows: Coeficient of speed fluctuation = No-load motor speed - Total-load motor speed × 100%

Rated motor speed

 $^{\ast}\text{2}.$ Always perform risk assessment for the system and confirm that the safety requirements are met.

Specifications using MECHATROLINK-III Communication Reference

Item			Specification
Control Method			IGBT-based PWM control, sine wave current drive
	With Rotary Servo	omotor	Serial encoder: 24 bits (incremental encoder/absolute encoder)
Feedback	With Linear Servo	omotor	 Absolute linear encoder (The signal resolution depends on the absolute linear encoder. Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)
	Surrounding Air Te	emperature	-5°C to 55°C (60°C with derating)
	Storage Temperat	ture	-20°C to 85°C
	Surrounding Air H		95 % relative humidity max. (with no freezing or condensation)
	Storage Humidity	,	95 % relative humidity max. (with no freezing or condensation)
	Vibration Resistar		4.9 m/s ²
	Shock Resistance		19.6 m/s ²
Environmental	Degree of Protect	tion	IP10
Conditions	0		2
	Pollution Degree		 Must be no corrosive or flammable gases. Must be no exposure to water, oil, or chemicals. Must be no dust, salts, or iron dust.
	Altitude		1,000 m or less (above 1,000 m with derating)
			Do not use the SERVOPACK in the following locations: Locations subject to static electricity
	Others		noise, strong electromagnetic/magnetic fields, or radioactivity
Applicable Standard	S		Refer to the section Compliance with UL Standards, EU Directives, and Other Safety Standard
			(in Combination with SERVOPACK).
Mounting			Base-mounted
	Speed Control Ra	ange	1:5,000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)
			± 0.01 % of rated speed max. (for a load fluctuation of 0 % to 100 %)
	Coefficient of Spe	eed	0% of rated speed max. (for a voltage fluctuation of \pm 10%)
Performance	Fluctuation*1		
			± 0.1 % of rated speed max. (for a temperature fluctuation of 25 °C \pm 25 °C)
	Torque Control Pr (Repeatability)		±1%
	Soft Start Time Se	0	0s to 10s (Can be set separately for acceleration and deceleration.)
		or Overheat Protection	Number of input points: 1
	Signal Input		Input voltage range: 0 V to +5 V
			Allowable voltage range: 24 VDC ±20% Number of input points: 10
			Input method: Sink inputs or source inputs Input Signals
		Input Circula that can be	 /DEC (Origin Return Deceleration Switch) signal
	Sequence Input Signals	Input Signals that can be allocated	 /EXT1 to /EXT3 (External Latch Input 1 to 3) signals D OT (Courses Drive Deskibility) and N OT (Devenue Drive Deskibility) signals
			 P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals
			/P-DET (Polarity Detection) signal
			A signal can be allocated and the positive and negative logic can be changed.
		Final Onterit	Allowable voltage range: 5 VDC to 30 VDC
I/O Signals		Fixed Output	Number of output points: 1
			Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC
			Number of output points: 6
			(A photocoupler output (isolated) is used.)
			Output Signals
	Sequence		/COIN (Positioning Completion) signal
	Output Signals	Output Pienele Hast an	/V-CMP (Speed Coincidence Detection) signal //CON (Retation Detection) signal
	,	Output Signals that can be allocated	 /TGON (Rotation Detection) signal /S-RDY (Servo Ready) signal
		De allocateu	 /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal
			 VLT (Speed Limit Detection) signal
			/BK (Brake) signal
			• /WARN (Warning) signal
			• /NEAR (Near) signal
			A signal can be allocated and the positive and negative logic can be changed.
	RS-422A	Interfaces	Digital Operator (JUSP-OP05A-1-E)
	Communications	1:N Communications	Up to N = 15 stations possible for RS-422A port
	(CN3)		
Communications		Axis Address Setting	Set with parameters.
		Interface	Personal Computer (with SigmaWin+)
	USB Communi-	Communications	The software version of the SigmaWin+ must be version 7.11 or higher.
	cations (CN7)	Standard	Conforms to USB 2.0 standard (12 Mbps).
		otanuaru	

Continued on next page.

Cables & Periphery

Continued from previous page.

Item		Specification
Displays/Indicators		CHARGE, PWR, CN, L1 and L2 indicators, and two, one-digit seven-segment display
	Communications Protocol	MECHATROLINK-III
	Station Address Settings	03 to EF hex (maximum number of slaves: 62) The rotary switches (S1 and S2) are used to set the station address.
MECHATROLINK-III	Extended Address Setting	Axis A: 00 hex, Axis B: 01 hex
Communications	Raud Rate	100 Mbps
	Transmission Cycle	250 μs, 500 μs, 750 μs, 1.0 ms to 4.0 ms (multiples of 0.5 ms)
	Number of Transmission Bytes	32 or 48 bytes per station A DIP switch (S3) is used to select the number of transmission bytes.
	Performance	Position, speed, or torque control with MECHATROLINK-III communications
	Reference Input	MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.)
	Profile	MECHATROLINK-III standard servo profile
Analog Monitor (CN5)		Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)
Dynamic Brake (DB)		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.
Regenerative Processi	ng	Built-in Refer to the catalog for details.
Overtravel (OT) Preven	tion	Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.
Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.
	Inputs	/HWBB_A1, /HWWB_A2, /HWWB_B1 and /HWBB_B2: Base block signals for Power Modules
Safety Functions	Output	EDM_A and EDM_B: Monitor the status of built-in safety circuits (fixed outputs).
	Applicable Standards*2	ISO13849-1 PLe (Category 3), IEC61508 SIL3
Applicable Option Mod	lules	Option Module Safety

*1. The coefficient of speed fluctuation for load fluctuation is defined as follows:


 $Coefficient of speed fluctuation = \frac{No-load motor speed - Total-load motor speed}{Rated motor speed} \times 100\%$

*2. Always perform risk assessment for the system and confirm that the safety requirements are met.

Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

• Front Cover Dimensions and Connectors





Connector Specifications

Connector No.	Function	Model	YASKAWA Order Code	Number of Pins	Manufacturer
CN1	I/O Connector	DFMC1,5/15-ST-3,5-LRBK	JUSP-7CN001	30	Phoenix Contact
CN2A/CN2B	Encoder Connector Axis A Encoder Connector Axis B	-	JZSP-CMP9-1-E	6	Sumitomo 3M Ltd.
CN3	Digital Operator	-	-	14	Honda Tsushin Kogyo Co., Ltd.
CN6A/CN6B	Fieldbus Connector	-		8	Tyco Electronics Japan G.K.
CN7	USB Connector for Sig- maWin		-	5	Tyco Electronics Japan G.K.
CN8A	Safety Connector Kit	-	2013595-1	8	Tyco Electronics Japan G.K.
GNOA	Safety Jumper Connector	-	JZSP-CVH05-E	0	Tyco Electronics Japan G.K.
CN8B	Safety Connector Kit	-	2013595-1	8	Tyco Electronics Japan G.K.
CINOD	Safety Jumper Connector	-	JZSP-CVH05-E	0	TYCO Electronics Japan G.K.
CN101	Main Power Connector	BLZ 7.62HP/08/180LR SN BK BX PRT	JUSP-7CN101	8	Weidmüller
CN102A/ CN102B	Motor Power Connector Axis A Motor Power Connector Axis B	BLZ 7.62IT/04/180MF4 SN BK BX PRT	JUSP-7CN102	4	Weidmüller
CN103	DC Power Input	BVZ 7.62IT/04/180MF3 SN BK BX PRT	JUSP-7CN103	4	Weidmüller
CN115A/ CN115B	Dynamic Brake Connector Axis A Dynamic Brake Connector Axis B	BLZ 7.62IT/03/180MF2 SN BK BX PRT	JUSP-7CN115	3	Weidmüller
CN117	Holding Brake Connector	BLF 5.08HC/04/180LR SN BK BX SO	JUSP-7CN117	4	Weidmüller
CN201	24V Control Power Input	BLF 5.08HC/04/180LR SN OR BX SO	JUSP-7CN201	4	Weidmüller


Note: The above connectors or their equivalents are used for the SERVOPACKs.


Rotary Motors

Contents

Appendix

Base-mounted SERVOPACKs





Mounting Hole Diagram

Approx. mass: 2R6D: 4.1 kg 5R4D: 4.3 kg Unit: mm

Content - Option Modules

Option Modules

Option Module Safety108Option Module Feedback112

Option Module Safety

Option Module Safety

This Safety Module implements safety functions that conform to EN ISO 13849-1 (the harmonized EU Machinery Directive) and are specified in the individual IEC 61800-5-2 standard. You can combine it with a Sigma-7 400 V SERVOPACK to design optimum safety in a machine system according to industry needs.

SERVOPACKs, Option Module Safety and Mounting Rail need to be ordered separately. Please use the following model designations.

Option Module Safety

SGE	VC	-	OS	A01	А	000	FT900				
Option N	Nodule Safety	У	1st & 2nd	3rd 5th	6th	7th 9th	10th 14th	digit			
1st & 2	nd digit - M	lodule	е Туре		3rd 5t tions	h digit - Interfac	ce Specifica-			th digit - Hardware Option	
1st & 2 Code	nd digit - M Module	lodule	е Туре			h digit - Interfac	ce Specifica-		Code	Option Specification	
	Module				tions						
Code					tions Code A01	Interface			Code 000 10th	Option Specification Standard 14th digit - FT Specification	
Code	Module				tions Code A01	Interface Safety Module			Code 000	Option Specification Standard	

Mounting Rail for Option Cards

Mounting Rail for Option Cards for Sigma-7 400 V SERVOPACKs. Contact your YASKAWA representative for more information.

SERVOPACK Model	Order No.	Specification
All Models	JZSP-P7R2-8-E	€ € ₹9₽ ₽

Applicable Standards and Functions

Compliance with Safety Standards

Safety Standards	Applicable Standards	Products		
	Applicable Standards	SERVOPACK	SERVOPACK + Safety Module	
Safety of Machinery	EN ISO13849-1:2008/ AC:2009 EN 954-1 IEC 60204-1	\checkmark	V	
Functional Safety	IEC 61508 Series IEC 62061 IEC 61800-5-2	\checkmark	V	
EMC	IEC 61326-3-1	\checkmark	\checkmark	

Support for Functions Defined in IEC61800-5-2

Safety functions are implemented by using the hard wire base block (HWBB) in the SERVOPACK.

			Applicable	Products	
Safety Function	Description	SGD7S SGD7W Axis A + B	SGD7S + Safety Module	SGD7W Axis A + Safety Module	SGD7W Axis B
Safe BaseBlock Function* (SBB function)	This safety function is equivalent to an STO function. (It shuts OFF the power supply from the SERVOPACK to the motor.)	V	V	J	V
Safe BaseBlock with Delay Function (SBB-D function)	This safety function is equivalent to an SS1 function. (It monitors the deceleration opera- tion of the motor for the specified time and then shuts OFF the power supply from the SERVOPACK to the motor.)	—	J	J	_
Safe Position Monitor with Delay Function (SPM-D function)	This safety function is equivalent to an SS2 function. (It monitors the deceleration operation of the motor for the specified time and then monitors the position after the motor stops.)	_	1	J	_
Safely Limit Speed with Delay Function (SLS-D function)	This safety function is equivalent to an SLS function. (It monitors the deceleration operation of the motor for the specified time and then monitors the speed of the motor to confirm that it remains in the allowable range.)	_	V	J	_

* In combination with a Option Module Safety, the selection of Safe BaseBlock Function (Safe Torque Off) is possible on SERVOPACK CN8 or Option Module Safety.

SERVOPACK Saf		Safety Module	Safe Performance:	Safe Performance: Safety Module
SGD7S		SGDV-OS01A	CN8: Not apply (*2)	Apply
		SGDV-OS01A000FT900	CN8: Apply	Apply
000714/	Axis A*1	SGDV-OS01A	Apply	Apply
SGD7W	Axis B*1		CN8B: Apply	-
SGD7W	Axis A	SGDV-OS01A000FT900	CN8A: Apply	Apply
SGD/W	Axis B	-	CN8B: Apply	-

*1 When the Safety Module is attached to the SGD7W, the Safety Module operates for Axis A only.
*2 A safety jumper connector should be connected for not applied CN8^{II}.

Contents

Specifications and Ratings

Basic Specifications

Item		Specification	
Placement		Attached to the SERVOPACK	
Power Specification Power Supply Method		Supplied from the control power supply of	the SERVOPACK.
	Ambient Air Temperature	0°C to +55℃	
	Storage Temperature	–20°C to +85°C	
	Surrounding Air Humidity / Storage Humidity	90 % relative humidity max.	No freezing or condensation.
	Vibration Resistance	4.9 m/s ²	
Operating	Shock Resistance	19.6 m/s ²	
Conditions Protection Class / Pollution Degree		Protextion class: IP10, Pollution Degree: 2 An environment that satisfies the following Free of corrosive or explosive gases. Free of exposure to water, oil or cher Free of dust, salts or iron dust.	conditions.
	Altitude	1,000 m max.	
	Others	Free of static electricity, strong electromag	netic/magnetic fields, or radioactivity.


Compliance with UL Standards, EU Directives, and Other Safety Standards (in Combination with SERVOPACK)

Item				Specification		
	Number of Function	s: 2				
		la se sta	Number of Channels	2		
		Inputs	Function	Safety Request Input Signal (SRI-A1, SRI-A2)		
		Output	Number of Channels	1		
		Output	Function	External Device Monitor Output Signal (EDM-A)		
	Safety Function A			Safety Functions (IEC61800-5-2)	Function names of Safety Module	
	(CN21)			Safe Torque Off (STO)	Safe BaseBlock Function (SBB function)	
		Stopping	Methods	Safe Stop 1 (SS1)	Safe BaseBlock with Delay Function (SBB-D function)	
				Safe Stop 2 (SS2)	Safe Position Monitor with Delay Function (SPM-D function)	
Safety Functions				Safely-Limited Speed (SLS)	Safely Limited Speed with Delay Function (SLS-D function)	
		Inputs	Number of Channels	2		
		inputs	Function	Safety Request Input Signal (SRI-B1, SRI-B2)		
		Output	Number of Channels	1		
			Function	External Device Monitor Output Signal (EDM-B)		
	Safety Function B			Safety Functions (IEC61800-5-2)	Function names of Safety Module	
	(CN22)			Safe Torque Off (STO)	Safe BaseBlock Function (SBB function)	
		Stopping Methods		Safe Stop 1 (SS1)	Safe BaseBlock with Delay Function (SBB-D function)	
				Safe Stop 2 (SS2)	Safe Position Monitor with Delay Function (SPM-D function)	
				Safely-Limited Speed (SLS)	Safely Limited Speed with Delay Function (SLS-D function)	
Others				Active Mode Function		
Response Time				200 ms max.		
	Safety Integrity Leve	I		SIL2, SILCL2		
	Probability of Dange	rous Failure	per Hour	PFH $3.3 \ge 10^{-7} [1/h]$		
Cofe	Category			Cat3		
Safe Performance	Performance Level*			PLd (Category 2)		
	Mean Time to Dange	erous Failur	e of Each Channel	MTTFd: High		
	Average Diagnostic	Coverage		DCave: Medium		
Proof Test Interval		10 years				

* If Safe Torque Off is used on the SERVOPACK side CN8, the specification of Safe Performance changes to PLe, for specifics refer to the SERVOPACK Specifications in this catalogue.

Option Module Safety

Top View of SERVOPACK with safety module installed



Device Label	Model	Number of Pins	Manufacturer
CN21	1981080-1	8	Tyco Electronics Japan G.K.
CN22	1981080-1	8	Tyco Electronics Japan G.K.
CN8	1981080-1	8	Tyco Electronics Japan G.K.

Notes

The above connectors or their equivalents are used for SERVOPACKs. 0 Refer to the user's manual of the Safety Module for installation standards.

Cables for Option Module Safety

Name	Length	Oder No.	Specification
Cables with connectors*	1 m	JZSP-CVH03-01-E-G#	
Cables with connectors	3m	JZSP-CVH03-03-E-G#	

* When using safety functions, connect this Cable to the safety functions devices. When not using safety functions, connect the enclosed Safety Jumper Connector (JZSP-CVH05-E) to the SERVOPACK.

Specifications for JZSP-CVH03-03-E-G#

Pin No.	Signal	Lead Color	Marking Color
1	Not used	-	-
2	Not used	-	-
3	/HWBB1-	White	Black
4	/HWBB1+	White	Red
5	/HWBB2-	Gray	Black
6	/HWBB2+	Gray	Red
7	EDM1-	Orange	Black
8	EDM1+	Orange	Red

Fully-Closed Module

With fully-closed control, an externally installed encoder is used to detect the position of the controlled machine and the machine's position information is fed back to the SERVOPACK. High-precision positioning is possible because the actual machine position is fed back directly. To perform fully-closed loop control, a Fully-Closed Module and SERVOPACK are required.

SERVOPACKs, Option Module Feedback and Mounting Rail need to be ordered separately. Please use the following model designations.

Model Designation



1st & 2nd digit - Module Type		
Code	Module	
OF	Option Module Feedback	

tions	tions		
Code	Interface		
A01	for YASKAWA Serial Protocol		
B01	Serial and Sin/Cos Encoders		
B03	Pulse A quad B Encoders		
B04	Resolver		


6th digit - Design Revision Order		
Code	Specification	
Α	Initial Design	

Mounting Rail for Option Cards

Mounting Rail for Option Cards for Sigma-7 400 V SERVOPACKs. Contact your YASKAWA representative for more information.

SERVOPACK Model	Order No.	Specification
All Models	JZSP-P7R2-8-E	66 66 9 00 0 -

System Configuration with SGDV-OFA01A




* The connected devices and cables depend on the type of external Linear Encoder that is used. Note: Refer to the following section for the information on peripheral devices or chapter Peripheral Devices.

Connections to Linear Encoder from Heidenhain Corporation

Connections for a 1 Vp-p Analog Voltage Output Signal

You must make the connections through a YASKAWA Serial Converter Unit. The output signal will be multiplied by 8 bits (256 divisions) in the Serial Converter Unit.



No.	Item	Model
0	Fully-Closed Module (Purchased alone)	Fully-Closed Module*1 SGDV-OFA01A
0	Serial Converter Unit Cable	JZSP-CLP70-□□ ^{*3} -E
3	Serial Converter Unit ^{*2}	JZDP-H003-000
4	Linear Encoder Cable	JZSP-CLL30-DD*3-E


*1 When ordering a SERVOPACK and a Fully-Closed Module separately, use this Fully-Closed Module model number. Please use the YASKAWA mounting rail JZSP-P7R2-8-E in combination with a Fully-Closed Module.

*2 Contact your YASKAWA representative for specific information.

*3 The boxes () in the model number are reolaced with cable length when ordering. (1m = 01, 3m = 03, 5m = 05, 10m = 10, 15m = 15)

Connections when using a YASKAWA Serial Interface for the Output Signals


LIC4100 Linear Encoder with EIB3391Y Interpolator



* Use an Encoder Cable from Heidenhain Corporation. Contact Heidenhain Corporation for detailed Encoder Cable specifications.

Connections to Linear Encoder from Renishaw Plc

Connections for a 1 Vp-p Analog Voltage Output Signal



*2 Contact Renishaw plc for details on cables (analog 1 Vp-p output, D-sub 15-pin, male) from Renishaw plc. *3 If you use the origin signals with a Linear Encoder from Renishaw plc, the origin may sometimes be falsely detected. If that occurs, use the BID/DIR signal

"3 If you use the origin signals with a Linear Encoder from Renishaw plc, the origin may sometimes be falsely detected. If that occurs, use the BID/DIR signal to output the origin signal only in one direction.

No.	Item	Model
0	Fully-Closed Module (Purchased alone)	Fully-Closed Module*1 SGDV-OFA01A
2	Serial Converter Unit Cable	JZSP-CLP70-DD*3-E
3	Serial Converter Unit ^{*2}	JZDP-H005-000
4	Linear Encoder Cable	JZSP-CLL00-DD*3-E


*1 When ordering a SERVOPACK and a Fully-Closed Module separately, use this Fully-Closed Module model number. Please use the YASKAWA mounting rail JZSP-P7R2-8-E in combination with a Fully-Closed Module.

*2 Contact your YASKAWA representative for specific information.

*3 The boxes ($\Box\Box$) in the model number are reolaced with cable length when ordering. (1m = 01, 3m = 03, 5m = 05, 10m = 10, 15m = 15)

Connections to Linear Encoder from Magnescale Co., Ltd.


SL7D0 Linear Encoder and PL101-RY Sensor Head with Interpolator



* Refer to the following section for information on cables to connect Fully-Closed Modules and Linear Encoders or chapter Serial Converter Unit Cables.


Appendix

SR-75, SR-77, SR-85, and SR-87 Linear Encoders



* To connect the SERVOPACK and Linear Encoder, use a CH33-xx

RU77-4096ADF/RU77-4096AFFT01 Absolute Rotary Encoders



*To connect the SERVOPACK and Rotary Encoder, use a CE28-Series Extension Cable for RU77 from Magnescale Co., Ltd

Note: The RU77 is a single-turn absolute rotary encoder.

Connections to Linear Encoders from Mitutoyo Corporation **ST78 Linear Encoders**




* Refer to the following section for information on cables to connect Fully-Closed Modules and Linear Encoders or chapter Serial Converter Unit Cables.

Connectors

Device Label	Model	YASKAWA Order No.	Number of Pins	Manufacturer
CN31	3E106-0220KV	JZSP-CMP9-1-E-G#	6	3M Japan Ltd.

Note: The above connecor or their equivalent are used for the Fully-Closed Module.

System Configuration with SGDV-OFB0 CA



Appendix

Standard Specifications

Encoder Type		Specifications	
	Encoder Supply	Output voltage	Typ. 5 V
EnDat 2.2	Serial Interface (Synchronous)	Signal transfer	RS485
	Senai Interface (Synchronous)	Max. Baud rate	16 MHz
	Encoder Supply	Output voltage	Typ. 5 V
	Serial Interface (Synchronous)	Signal transfer	RS485
	Senai Interface (Synchronous)	Max. Baud rate	2 MHz
EnDat 2.1		Signal transfer	Differential signals, symmetric
ENDal 2.1		Differential voltage	0.5 to 1.25 Vss
	Sine-Cosine input	Terminating resistor	124 Ohm
		Signal frequency	250 kHz
		Resolution	13-bits (8192)
	Encoder Supply	Output voltage	7 to 12 V
	Serial Interface (Asynchronous)	Signal transfer	RS485
		Max. Baud rate	38.4 MHz
Llinerfees	Sine-Cosine input	Signal transfer	Differential signals, symmetric
Hiperface		Differential voltage	0.5 to 1.25 Vss
		Terminating resistor	124 Ohm
		Signal frequency	250 kHz
		Resolution	13-bits (8192)
	Encoder Supply	Output voltage	Typ. 5 V
		Signal transfer	Differential signals, symmetric
		Differential voltage	0.5 to 1.25 Vss
	Sine-Cosine input	Terminating resistor	124 Ohm
Sine-Cosine Encoder		Signal frequency	250 kHz
		Resolution	13-bits (8192)
		Signal transfer	Differential signals, symmetric
	Reference input	Differential voltage	0.2 V or more
		Terminating resistor	124 Ohm

Option Module Feedback Set-up for Fully-closepd Loop Control

The encoder parameters must be written into the module via the SERVOPACK using the SigmaWin+ engineering tool. Ask YASKAWA for preparation encoder parameter file for fully-closed loop.

Procedure to download the encoder parameter via SigmaWin+ Version 7.2x via Sigma-7 400 V to Option Module Feedback.

- 1. Install a motor, encoder and SERVOPACK.
- 2. In SigmaWin+ select "Parameters > Parameter edit". Set parameter Pn002.3 = 1 or 3.
- $\label{eq:start} \ensuremath{\texttt{Setup}}\xspace > \mathsf{Motor}\xspace \mathsf{parameter}\xspace \mathsf{scale}\xspace \mathsf{write}\xspace \mathsf{in}\xspace \mathsf{SigmaWin+}.$
- 4. Write configuration file to option module feedback.

Note: Refer to SigmaWin+ Operation manual for information on how to write parameters using SigmaWin+.

General Specification SGDV-OFB01A

Item		Specification	
Applicable SERVOPACK		All Sigma-7 Series SERVOPACKs	
Applicable SERVOPACK Firmware Version		Version 0023 or later	
Placement		Attached to the SERVOPACK	
Power Specification Power Supply Method		Supplied from the control power supply of the SERVOPACK.	
	Surrounding Air / Storage Temperature	0°C to +55 °C / -20 °C to +85 °C	
	Ambient / Storage Humidity	90% RH or less (with no condensation)	
	Vibration / Shock Resistance	4.9 m/s² / 19.8 m/s²	
Operating Conditions	Protection Class / Pollution Degree	Protection class: IP10, Pollution degree: 2 An environment that satisfies the following conditions. • Free of corrosive or explosive gases • Free of exposure to water, oil or chemicals • Free of dust, salts or iron dust	
	Altitude	1,000 m or less	
	Others	Free of static electricity, strong electromagnetic fields, magnetic fields or exposure to radioacti- vity	
Supported motors		Permanent magnet, Synchronous AC rotary or linear motor	
Max. output frequency	range	Must be lower than 500 [rev/sec]. Note: UL application: 400 [rev/sec] (200 V), 300 [rev/sec] (400 V). If UL is needed, the combination should be applied to UL on customer side.	
Supported scales for m	otor driving usage	EnDat2.1, EnDat2.2, HIPERFACE, Sin/Cos	
Supported scales for fu	lly-closed usage	EnDat2.1, EnDat2.2, HIPERFACE, Sin/Cos	
Motor pole information for motor driving	Without hall sensor signals	Sigma-5 detecting function is available. In case of EnDat2.1, EnDat2.2 and HIPERFACE, the function should be carried out once (after that, recognized data will be used). In other cases, the function should be carried out each boot-up.	
	With hall sensor signals	The data is used (any functions needed for the information).	
Unsupported devices		Advanced option module safety: SGDV-OSA01A Fully-closed option module: SGDV-OFA01A	

General Specification SGDV-OFB03A

Item		Specification
Applicable SERVOPACK		All Sigma-7 Series SERVOPACKs
Applicable SERVOPACK Firmware Version		Version 0023 or later
Placement		Attached to the SERVOPACK
Power Specification Power Supply Method		Supplied from the control power supply of the SERVOPACK.
	Surrounding Air / Storage Temperature	0°C to +55 °C / -20 °C to +85 °C
	Ambient / Storage Humidity	90% RH or less (with no condensation)
	Vibration / Shock Resistance	4.9 m/s ² / 19.8 m/s ²
Operating Conditions	Protection Class / Pollution Degree	 Protection class: IP10, Pollution degree: 2 An environment that satisfies the following conditions. Free of corrosive or explosive gases Free of exposure to water, oil or chemicals Free of dust, salts or iron dust
	Altitude	1,000 m or less
	Others	Free of static electricity, strong electromagnetic fields, magnetic fields or exposure to radioac- tivity
Supported motors		Permanent magnet, Synchronous AC rotary or linear motor
Max. output frequency range		Must be lower than 500 [rev/sec]. Note: UL application: 400 [rev/sec] (200 V), 300 [rev/sec] (400 V). If UL is needed, the combination should be applied to UL on customer side.
Supported scales for me	otor driving usage	A quad B
Supported scales for ful	ly-closed usage	A quad B
Motor pole information	Without hall sensor signals	Sigma-5 detecting function is available. In other cases, the function should be carried out each boot-up.
for motor driving	With hall sensor signals	The data is used (any functions needed for the information).
Unsupported devices		Advanced option module safety: SGDV-OSA01A Fully-closed option module: SGDV-OFA01A

General Specification SGDV-OFB04A

Item		Specification
Applicable SERVOPAC	<	All Sigma-7 Series SERVOPACKS
Applicable SERVOPACK Firmware Version		Version 0023 or later
Placement		Attached to the SERVOPACK
Power Specification	Power Supply Method	Supplied from the control power supply of the SERVOPACK.
	Surrounding Air / Storage Temperature	0°C to +55 °C / -20 °C to +85 °C
	Ambient / Storage Humidity	90% RH or less (with no condensation)
	Vibration / Shock Resistance	4.9 m/s² / 19.8 m/s²
Operating Conditions	Protection Class / Pollution Degree	 Protection class: IP10, Pollution degree: 2 An environment that satisfies the following conditions. Free of corrosive or explosive gases Free of exposure to water, oil or chemicals Free of dust, salts or iron dust
	Altitude	1,000 m or less
	Others	Free of static electricity, strong electromagnetic fields, magnetic fields or exposure to radioac- tivity
Supported motors		Permanent magnet, Synchronous AC rotary or linear motor
Max. output frequency range		Must be lower than 240 [rev/sec]. Note: UL application: 400 [rev/sec] (200 V), 300 [rev/sec] (400 V). If UL is needed, the combination should be applied to UL on customer side.
Motor pole information	Incremental usage	Sigma-5 detecting function is available. The function should be carried out at each boot-up.
for motor driving	Absolute usage	The data is used (any functions needed for the information). The pole detection function should be carried out only once after the card or the motor has been replaced.
Unsupported devices		Advanced option module safety: SGDV-OSA01A Fully-closed option module: SGDV-OFA01A

Connectors

Device Label	Function	Model	YASKAWA Order Code	Number of Pins	Manufacturer
CN31	Connector Kit for CN1	Case: 10326-52A0-008 Connector: 10126-3000PE	JZSP-CSI9-2-E	26	3M Japan Ltd.


Note: The above connecor or their equivalent are used for the Fully-Closed Module SGDV-0FB0 A.


Content - Cables & Periphery

Cables & Periphery

Cables for Rotary Servomotors	122
Cables for Linear Servomotors	126
Serial Converter Units	129
Cables and Connectors for SERVOPACKs	134
Periphery	141

System Configurations





Notes:

- If you use a Servomotor Main Circuit Cable that exceeds 20 m, the intermittent duty zone in the torque speed characteristics will become smaller because the voltage drop increases. 1.
- 2.
 - Refer to the following manual for the following information. Cable dimensional drawings and cable connection specifications

 - Order numbers and specifications of individual connectors for cables
 Order numbers and specifications for wiring materials

Sigma-7-Series AC Servo Drive Peripheral Device Selection Manual.

Cables for Rotary Servomotors

Power Cables for rotary servomotors without holding brake

Servomotor Model	Cable & connector type	Length	Order No.	Specification
		3m	JZSP-C7M143-03-E-G6	
		5m	JZSP-C7M143-05-E-G6	
SGM7J-02 to -08 SGM7A-02 to -08	Flexible Power cable 4 x 1.5 mm ² with M17 connector	10 m	JZSP-C7M143-10-E-G6	
		15m	JZSP-C7M143-15-E-G6	
		20 m	JZSP-C7M143-20-E-G6	
		3m	JZSP-C7M144-03-E-G6	
SGM7J-15 SGM7A-10 to -25		5m	JZSP-C7M144-05-E-G6	
SGM7G-05 to -20	Flexible Power cable 4 x 1.5 mm ² with M23 connector	10m	JZSP-C7M144-10-E-G6	21 D - 32
SGM7G-05 to -09 High Speed		15m	JZSP-C7M144-15-E-G6	
		20 m	JZSP-C7M144-20-E-G6	
		3m	JZSP-C7M154-03-E-G6	
SGM7A-30	Flexible Power cable 4 x 2.5 mm ² with M23 connector	5m	JZSP-C7M154-05-E-G6	
SGM7G-30 SGM7G-13 to -20		10m	JZSP-C7M154-10-E-G6	Ed D=se
High Speed		15m	JZSP-C7M154-15-E-G6	
		20 m	JZSP-C7M154-20-E-G6	
		3m	JZSP-C7M164-03-E-G6	
SGM7A-40 to -50		5m	JZSP-C7M164-05-E-G6	
SGM7G-44 SGM7G-30 High	Flexible Power cable 4 x 4 mm ² with M23 connector	10m	JZSP-C7M164-10-E-G6	21 D - 32
Speed		15m	JZSP-C7M164-15-E-G6	
		20 m	JZSP-C7M164-20-E-G6	
		3m	JZSP-C7M175-03-E-G6	
SGM7A-70		5m	JZSP-C7M175-05-E-G6	
SGM7G-55 to -75 SGM7G-44 High	Flexible Power cable 4 x 6.0 mm ² with M40 connector	10m	JZSP-C7M175-10-E-G6	
Speed		15m	JZSP-C7M175-15-E-G6	
		20 m	JZSP-C7M175-20-E-G6	
		3m	JZSP-C7M185-03-E-G6	
	Flexible Power cable 4 x	5m	JZSP-C7M185-05-E-G6	
SGM7G-1A to -1E	10.0 mm ² with M40 con-	10 m	JZSP-C7M185-10-E-G6	
	nector	15m	JZSP-C7M185-15-E-G6	
		20 m	JZSP-C7M185-20-E-G6	

Motor Connection Shielding Clamp

Shielding clamp mountable on Sigma-7 400 V SERVOPACKs up to 15 kW. Contact your YASKAWA representative for more information.

SERVOPACK Model	Order No.	Specification
Sigma-7 400V up to 3.0kW	KLBUE 4-13.5_SC	
Sigma-7 400V from 5kW up to 7.5kW	KLBUE 10-20_SC	B
Sigma-7 400V for 11 kW & 15 kW	KLBUE 15-32_SC	aê î



Cables for Rotary Servomotors

Power Cables for rotary servomotors with holding brake

Servomotor Model	Cable & connector type	Length	Order No.	Specification
	Flexible Power cable 4 x	3m	JZSP-C7M343-03-E-G6	
		5m	JZSP-C7M343-05-E-G6	
SGM7J-02 to -08 SGM7A-02 to -08	$1.5mm^2$ & 2 x $1.5mm^2$ for	10 m	JZSP-C7M343-10-E-G6	
	brake with M17 connector	15m	JZSP-C7M343-15-E-G6	
		20 m	JZSP-C7M343-20-E-G6	
		3m	JZSP-C7M344-03-E-G6	
SGM7J-15 SGM7A-10 to -25	Flexible Power cable 4 x	5m	JZSP-C7M344-05-E-G6	
SGM7G-05 to -20	1.5 mm ² & 2 x 1.5 mm ² for	10 m	JZSP-C7M344-10-E-G6	
SGM7G-05 to -09 High Speed	brake with M23 connector	15m	JZSP-C7M344-15-E-G6	
		20 m	JZSP-C7M344-20-E-G6	
		3m	JZSP-C7M354-03-E-G6	
SGM7A-30	Flexible Power cable 4 x 2.5 mm ² & 2 x 1.5 mm ² for brake with M23 connector	5m	JZSP-C7M354-05-E-G6	
SGM7G-30 SGM7G-13 to -20		10 m	JZSP-C7M354-10-E-G6	
High Speed		15m	JZSP-C7M354-15-E-G6	
		20 m	JZSP-C7M354-20-E-G6	
		3m	JZSP-C7M364-03-E-G6	
SGM7A-40 to -50	Flexible Power cable 4 x	5m	JZSP-C7M364-05-E-G6	
SGM7G-44 SGM7G-30 High	$4 \text{ mm}^2 \& 2 \times 1.5 \text{ mm}^2$ for	10 m	JZSP-C7M364-10-E-G6	
Speed	brake with M23 connector	15m	JZSP-C7M364-15-E-G6	
		20 m	JZSP-C7M364-20-E-G6	
		3m	JZSP-C7M375-03-E-G6	
SGM7A-70	Flexible Power cable 4 x	5m	JZSP-C7M375-05-E-G6	
SGM7G-55 to -75 SGM7G-44 High	$6.0mm^2\&2x1.5mm^2$ for	10 m	JZSP-C7M375-10-E-G6	
Speed	brake with M40 connector	15m	JZSP-C7M375-15-E-G6	
		20 m	JZSP-C7M375-20-E-G6	
		3m	JZSP-C7M385-03-E-G6	
	Flexible Power cable 4 x	5m	JZSP-C7M385-05-E-G6	
SGM7G-1A to -1E	10.0 mm ² & 2 x 1.5 mm ² for	10 m	JZSP-C7M385-10-E-G6	
	brake with M40 connector	15m	JZSP-C7M385-15-E-G6	
		20 m	JZSP-C7M385-20-E-G6	

Motor Connection Shielding Clamp

SERVOPACK Model	Order No.	Specification
Sigma-7 400V up to 3.0kW	KLBUE 4-13.5_SC	
Sigma-7 400V from 5kW up to 7.5kW	KLBUE 10-20_SC	B
Sigma-7 400 V for 11 kW & 15 kW	KLBUE 15-32_SC	

125

Cable & connector type	Length	Sigma-7 cable for absolute encoder*	Sigma-7 cable for incremental encoder	Appearance
	3m	JZSP-C7PA2M-03-E-G	JZSP-C7PI2M-03-E-G6	
Flexible Encoder cable	5m	JZSP-C7PA2M-05-E-G	JZSP-C7PI2M-05-E-G6	
with straight connector M12	10m	JZSP-C7PA2M-10-E-G	JZSP-C7PI2M-10-E-G6	
IVI 12	15m	JZSP-C7PA2M-15-E-G	JZSP-C7PI2M-15-E-G6	
	20 m	JZSP-C7PA2M-20-E-G	JZSP-C7PI2M-20-E-G6	
	3m	JZSP-C7PA2N-03-E-G	JZSP-C7PI2N-03-E-G6	
Flexible Encoder cable	5m	JZSP-C7PA2N-05-E-G	JZSP-C7PI2N-05-E-G6	
with angled connector M12	10m	JZSP-C7PA2N-10-E-G	JZSP-C7PI2N-10-E-G6	
IVI12	15 m	JZSP-C7PA2N-15-E-G	JZSP-C7PI2N-15-E-G6	Second 1
	20 m	JZSP-C7PA2N-20-E-G	JZSP-C7PI2N-20-E-G6	
Sigma-7 Extension for Encoder cable with Con- nectors length 0.3m for Abs. Encoder	0.3 m	JZSP-CSP12-E-G5	-	SERVOPACK End 0.3 m Encoder End Battery Case (Battery attached)

Encoder cables for rotary servomotors

* Sigma-7 cables for absolute encoders have a battery case (Battery attached). Currently under preparation.

Fan cables for rotary servomotors

Description	Cable & connector type	Length	Sigma-7 Flexible Cable	Appearance		
	Flexible Power cable for FAN 4 x 1.5 mm ² & 2 x 1.5 mm ² with M17 connector (Standard Power cable used for FAN)	3m	JZSP-C7M343-03-E-G6			
			5m	JZSP-C7M343-05-E-G6		
SGM7A-70 conr (Standard F		10 m	JZSP-C7M343-10-E-G6			
		`	· · · · · · · · · · · · · · · · · · ·	15 m	JZSP-C7M343-15-E-G6	
		20 m	JZSP-C7M343-20-E-G6			




Connector: ST-5ES1N8A8005S (1624544) Contact: ST-10KP030 (1618261) From Phoenix Contact GmbH & Co. KG

Pin No.	Function	Wire Color
1	Alarm terminal	Black
2	Not used	_
3	Fan motor	Black
4	Fan motor	Black
5	PE	Green-yellow
6	Alarm terminal	White
7	Not used	Black
Housing	-	Shield

Appendix

Cables for Linear Servomotors

System Configurations



* You can connect directly to an absolute linear encoder.

Notes:

- 1. The above system configurations are for SGLFW2 Servomotors with F-Type Iron Cores (with thermal protectors). Refer to the manual for the Linear Servomotor for configurations with other models.
- 2. Refer to the following manual for the following information.
 - Cable dimensional drawings and cable connection specifications - Order numbers and specifications of individual connectors for cables
 - Order numbers and specifications of individual connectors for cables
 Order numbers and specifications for wiring materials

Sigma-7-Series AC Servo Drive Peripheral Device Selection Manual.

Cables for Linear Servomotors

Power Cables for Linear Servomotors

Linear Motor Model	Cable & connector type	Length	Order No.	Specification
		3m	JZSP-C7M143-03-E-G6	
SGLFW2-30D070	Flexible Power cable	5m	JZSP-C7M143-05-E-G6	
to SGLFW2-45D380	4 x 1.5 mm ² with M17 connector	10m	JZSP-C7M143-10-E-G6	
3GLFW2-43D360	connector	15m	JZSP-C7M143-15-E-G6	
		20 m	JZSP-C7M143-20-E-G6	
	Flexible Power cable 4 x 2.5 mm² with M23 connector	3m	JZSP-C7M154-03-E-G6	
SGLFW2-90D200		5m	JZSP-C7M154-05-E-G6	
to SGLFW2-1DD380		10m	JZSP-C7M154-10-E-G6	24 D-32
3GLFW2-100360		15m	JZSP-C7M154-15-E-G6	
		20 m	JZSP-C7M154-20-E-G6	
		3m	JZSP-C7M164-03-E-G6	
	Flexible Power cable 4 x 4 mm² with M23 connector	5m	JZSP-C7M164-05-E-G6	
SGLFW2-1DD560		10m	JZSP-C7M164-10-E-G6	24 D-32
		15m	JZSP-C7M164-15-E-G6	
		20 m	JZSP-C7M164-20-E-G6	

Motor Connection Shielding Clamp

Shielding clamp mountable on Sigma-7 400 V SERVOPACKs up to 15 kW. Contact your YASKAWA representative for more information.

SERVOPACK Model	Order No.	Specification
Sigma-7 400V up to 3.0kW	KLBUE 4-13.5_SC	
Sigma-7 400 V from 5 kW up to 7.5 kW	KLBUE 10-20_SC	B
Sigma-7 400V for 11kW & 15kW	KLBUE 15-32_SC	

Appendix

Linear Encoder Cables


Servomo	Servomotor Model		Order No.	Specification
		1m	JZSP-CLL00-01-E	
		3m	JZSP-CLL00-03-E	
	For linear encoder from Renishaw PLC	5m	JZSP-CLL00-05-E	
		10m	JZSP-CLL00-10-E	Serial Converter Linear encoder
All Models		15m	JZSP-CLL00-15-E	
AII MODEIS		1 m	JZSP-CLL30-01-E	
	For linear encoder from Heidenhain Corporatio n	3m	JZSP-CLL30-03-E	
		5m	JZSP-CLL30-05E	
		10m	JZSP-CLL30-10-E	
		15m	JZSP-CLL30-15-E	

* When using a JZDP-J000-DDD-E Serial Converter Unit, do not exceed a cable length of 3 m.

Serial Converter Unit Cables

Servomotor Model	Length	Order No. Specification	
	1 m	JZSP-CLP70-01-E	
	3m	JZSP-CLP70-03-E	SERVOPACK Serial Converter
	5m	JZSP-CLP70-05-E	
All Models	10 m	JZSP-CLP70-10-E	
	15 m	JZSP-CLP70-15-E	
	20 m	JZSP-CLP70-20-E	

Sensor Cables



Serial Converter Units

Model Designations

		JZDP	- [-		
					Applicable		
	Serial Co	nverter Unit Mode	l		Servomoto	Linear Servo Model	Code
Code	Appearance	Applical Linear Encoder	Polarity Sensor	Thermal Protector		30D070A	651
H003		From Heidenhain	None	None		30D120A	652
J003		Corp.				30D230A	653
H005 J005		From Renishaw PLC	None	None	SGLEW2	45D200A	654
0000		1 20			(Models with	45D380A	655
H006 J006		From Heidenhain Corp.	Yes	Yes	F-Type Iron Cores)	90D200A	657
0000		00ip.				90D380A	658
H008 J008		From Renishaw PLC	Yes	Yes		90D560A	659
1008		PLU				1DD380A	660
						1DD560A	661


Notes:

1. Code H

2. Refer to the catalog for detailed specifications of the Serial Converter Unit.

3. Contact your YASKAWA representative for information on the water cooling specifications of the SGLFW2.

Serial Converter Unit without Polarity Sensor Cable (for Linear Encoder with Heidenhain Corporation connector)




Note:

1. Do not connect the unused pins.

2. Contact Heidenhain Corporation for details on cables (analog 1 Vp-p output, D-sub 15-pin, male) from Heidenhain Corporation.

Serial Converter Unit without Polarity Sensor Cable (for Linear Encoder with Renishaw PLC connector)



♦ Model: JZDP-□005-□□□

Note:

1. Do not connect the unused pins.

Contact Renishaw plc for details on cables (analog 1 Vp-p output, D-sub 15-pin, male) from Renishaw plc. However, the BID and DIR signals are not connected.
 Use the Linear Encoder connector to change the origin position specifications of the Linear Encoder.

14

15

Case

Not used

Shield

Inner shield (0 V)

Linear Encoder-end analog signal inputs



17-Series Connector: 17JE-13150-02 (D8C) A-CG



Contents

Rotary Motors


Linear Motors

SERVOPACKs

Option Modules

Serial Converter Unit with Polarity Sensor Cable (for Linear Encoder with Heidenhain Corporation connector)

◆ Model: JZDP-□006-□□□



Case Shield

Note:


1. Do not connect the unused pins.

Contact Heidenhain Corporation for details on cables (analog 1 Vp-p output, D-sub 15-pin, male) from Heidenhain Corporation.
 The phase U, V, and W inputs are internally pulled up with 10 kΩ.

Serial Converter Units

Serial Converter Unit with Polarity Sensor Cable (for Linear Encoder with Renishaw PLC connector)

◆ Model: JZDP-□008-□□□



3	Phase-V input
4	Phase-W input
5	0 V
6	Not used
7	Not used
8	Not used
9	Thermal protector input
Case	Shield

Note:


1. Do not connect the unused pins.

Contact Renishaw plc for details on cables (analog 1 Vp-p output, D-sub 15-pin, male) from Renishaw plc. However, the BID and DIR signals are not connected.
 Use the Linear Encoder connector to change the origin position specifications of the Linear Encoder.

4. The phase U, V, and W inputs are internally pulled up with 10 $\ensuremath{k\Omega}$

System Configurations up to 5 kW

SGD7S Single-axis EtherCAT Reference **SERVOPACKs**




 \neq *1. repr nts twisted-pair wires

*2. Consect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
*4. Refer to the manual if you use a safety function device. If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.
*5. Always use line receivers to receive the output signals.
*6. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24-VDC to the control power supply input terminals.
*7. The CN117 connector is only used for SERVOPACKs with built-in Servomotor brake control, SGD7S-oooDooB026F64 and SGD7W-oooDooB026.
*8. If using these terminals, contact your YASKAWA representative.
*9. The CN115 Dynamic Brake Connector is only for SGD7S-1R9D up to -170D.

Cables and Connectors for SERVOPACKs

System Configurations with 6 kW and more


SGD7S Single-axis EtherCAT Reference **SERVOPACKs**



- \neq repre ents twisted-pair w
- /hen using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery Connect th
- c. com rect a reservine using an ausonue encouer. If the Encoder Cable with a battery Case is connected, do not connect a backup battery.
 *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
 *4. Refer to the manual if you use a safety function device. If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.
 *5. Always use line receivers to receive the output signals.
 *6. Use an SELV-compliant power supply according to ENVIEC 60950-1 to input 24-VDC to the control power supply input terminals.
 *7. The CN117 connector is only used to SERVOPACKs with built-in Servomotor brake control, SGD7S-oooDooB026F64 and SGD7W-oooDooB026.
 *8. If using these terminals, contact your YASKAWA representative.

System Configurations up to 5 kW

SGD7S Single-axis MECHATROLINK-III Reference **SERVOPACKs**




- represents twisted-pair wires.

- Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation. Refer to the manual if you use a safety function device. If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CNB when you use the SERVOPACK. Always use line receivers to receive the output signals.
- www.ys use time receivers to receive the output signals.
 46. Use an SELV-compliant power supply according to EN/EC 60950-1 to input 24-VDC to the control power supply input terminals.
 7. The CN117 connector is only used for SERVOPACKs with built-in Servomotor brake control, SGD7S-oooDooB026F64 and SGD7W-oooDooB026.
 *8. If using these terminals, contact your YASKAWA representative.
 *9. The CN115 Dynamic Brake Connector is only for SGD7S-1R9D up to -170D.

Cables and Connectors for SERVOPACKs

System Configurations with 6 kW and more

SGD7S Single-axis MECHATROLINK-III Reference **SERVOPACKs**




- *1. 🗲 represents twisted-pair wires

2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
 *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
 *4. Refer to the manual if you use a safety function device. If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.
 *5. Always use line receivers to receive the output signals.
 *6. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24-VDC to the control power supply input terminals.
 *7. The CN117 connector is only used for SERVOPACK with built-in Servomotor brake control, SGD7S-oooDooB026F64 and SGD7W-oooDooB0266.
 *8. If using these terminals, contact your YASKAWA representative.

System Configurations up to 2×1.5 kW

SGD7W Dual-axis EtherCAT Reference SERVOPACKs



*1. \checkmark represents twisted-pair wires.

- *2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- *4. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.
 *5. The CN117 connector is used for SERVOPACKs with built-in Servomotor brake control. SERVOPACKs without built-in Servomotor brake control do not have the CN117 connector.


Note: 1. You can use parameter settings to change some of the I/O signal allocations.

If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
 Default settings are given in parentheses.

Cables and Connectors for SERVOPACKs

System Configurations up to 2×1.5 kW

SGD7W Dual-axis MECHATROLINK-III Reference SERVOPACKs



*1. \checkmark represents twisted-pair wires.

- *2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- *4. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.
 *5. The CN117 connector is used for SERVOPACKs with built-in Servomotor brake control. SERVOPACKs without built-in Servomotor brake control do not have the CN117 connector.

Note: 1. You can use parameter settings to change some of the I/O signal allocations.

- If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
- 3. Default settings are given in parentheses.

Cables for SERVOPACKs



1. Use the cable specified by YASKAWA for the computer cable. Operation may not be dependable with any other cable.

Notes:

Refer to the manual for the following information. Cable dimensional drawings and cable connection specifications. Order numbers and specifications of individual connectors for cables. Sigma-7-Series AC Servo Drive Peripheral Device Selection Manual.

Nam	e	Length (L)	Order Number	Appearance
Analog Monit	Analog Monitor Cable 1 m		JZSP-CA01-E	
Digital Operator (including 1 m cable)		1m	JUSP-OP05A-1-E	
Digital Opera	Digital Operator Cable		JZSP-CVS07-A3-E ²	
Computer	Computer Cable		JZSP-CVS06-02-E	
		1m	JZSP-CVH03-01-E-G#	. L .
Safety Function	Cables with Connectors ^{*1}	3m	JZSP-CVH03-03-E-G#	▲ 三中頓[]
Device Cable	Connect	or Kit ^{*2}	Contact Tyco Electronics Japan Product name: Industrial Mini I/0 Model number: 2013595-1	ı G.K. O D-shape Type 1 Plug Connector Kit
		0.2 m	CM3RDM0-00P2-E	
		0.5 m	CM3RDM0-00P5-E	
		1 m	JZSP-CM3R□M0-01-E	
		3m	JZSP-CM3R□M0-03-E	<►
MECHATROLINK Communicatior		5m 10m	JZSP-CM3R□M0-05-E	[= ••• ••] [] [] [] [] [] [] [] [] [] [] [] [] []
Communication	IS Caples"	20m	JZSP-CM3R□M0-10-E JZSP-CM3R□M0-20-E	
		20m 30m	JZSP-CM3RUM0-20-E JZSP-CM3RUM0-30-E	
		40 m	JZSP-CM3R□M0-30-E	
		50 m	JZSP-CM3R□M0-50-E	
		00111	SEST ONOTIENTO SU E	

*1. When using the safety function, connect this cable to the safety devices.

Even when not using the safety function, use SERVOPACKs with the Safe Jumper Connector (model: JZSP-CVH05-E) connected.

*2. Use the connector kit when you make cables yourself.

*3. This cable is available in two variants. The order number for these cables differs at the marked \Box , an "R" at this place is used for Cables with RJ45 Connectors on both ends, while an "M" is used for Cables with RJ45 Connector on One End and IMI Connector on the other End.


Motor Connection Shielding Clamp

Shielding clamp mountable on Sigma-7 400 V SERVOPACKs up to 15 kW. Contact your YASKAWA representative for more information.


SERVOPACK Model	Order No.	Specification
Sigma-7 400V up to 3.0kW	KLBUE 4-13.5_SC	
Sigma-7 400V from 5kW up to 7.5kW	KLBUE 10-20_SC	B
Sigma-7 400V for 11 kW & 15 kW	KLBUE 15-32_SC	

Cables & Periphery





Periphery



Top and Bottom View of SERVOPACKs

Main circuit terminals With Front Cover Open DC power Motor terminals supply terminals \$\$2. [] Control power Servomotor brake power supply terminals, \sim Dynamic brake supply terminals terminals*

* Dynamic Brake Connector only for SGD7S-1R9D up to -170D

Peripheral Device Selection Table

SERVOPACK Maximum Model **Main Circuit** Magnetic Digital Applicable Surge EMC-Filter*1 DC Reactor*2 Motor Capacity Power Supply Contactor Absorber Operator SGD7S-SGD7W-[kW] 1R9D X5074 0.5 1.0 3R5D SC-4-1/G X5075 5R4D FESS-4009A*3 1.5 2.0 8R4D X5076 SC-5-1-/G 3.0 120D 5.0 170D FESS-4015A*3 X5077 Three phase, JUSP-OP05A-1-E LT-C35G102WS 400 V A C 6.0 210D SC-N1/G FESS-4022A*3 7.5 260D 11.0 280D FESS-4044A*3 15.0 370D 2 x 0.75 2R6D X5075 SC-4-1/G FESS-4009A*3 5R4D 2 x 1.5 X5076 SC-5-1/G

Device	Enquires
Noise Filters	EPA GmbH
Surge Absorbers	Yaskawa Controls Co., Ltd.
DC Reactors	faskawa Controis Co., Etd.
Magnetic Contactors	Fuji Electric FA Components & Systems Co., Ltd.

*1.

Some Noise Filters have large leakage currents. The grounding conditions also affect the size of the leakage current. If necessary, select an appropriate leakage detector or leakage breaker taking into account the grounding conditions and the leakage current from the Noise Filter. The last digit of an RoHS-compliant serial number is R. Consult with Yaskawa Controls Co., Ltd. for RoHS-compliant reactors

*2. *3. Can be installed separate or as footprint filter.

Note: 1. Consult the manufacturer for details on s.


Refer to the following section for information on Digital Operator Converter Cables.
 Refer to the -7 Series AC Servo Drive Peripheral Device Selection Manual (Manual No. SIEP S800001 32) for the following information.

Dimensional drawings, ratings, and specifications of peripheral devices.




Dimensions of EMC-Filters

FESS-4009A




FESS-4015A



FESS-4022A*



FESS-4044A*



EMC-Filter Leakage Current		Ambient Temperature	Measurements	Weight
FESS-4009A	0.3 mA nom. (28 mA max.)	55 °C	366 x 80 x 50 mm	1.3 kg
FESS-4015A	0.3 mA nom. (40 mA max.)	55°C	366 x 100 x 50 mm	1.6 kg
FESS-4022A*	0.3 mA nom. (40 mA max.)	55 °C	416 x 80 x 50 mm	2.0 kg
FESS-4044A*	0.3 mA nom (40 mA max.)	55 °C	435 x 180 x 50 mm	3.2 kg

* Available soon.

Molded-case Circuit Breakers and Fuses

Use a molded-case circuit breaker and fuse to protect the power supply line. They protect the power line by shutting OFF the circuit when overcurrent is detected. Select these devices based on the information in the following tables.

Notes:

To comply with the Low Voltage Directive, always connect a fuse to the input side to protect against short-circuit accidents. Select fuses or molded-case circuit breakers that are compliant with UL standards. The following tables provide the net values of the current capacity and inrush current. Select a fuse and a molded-case circuit breaker that meet the following conditions.

• Main circuit and control circuit: No breaking at three times the current value given in the table for 5 s. • Inrush current: No breaking at the current value given in the table for 20 ms

Main Circuit Power Supply	Maximum Applicable Motor Capacity [kW]	Model		Power Supply Capacity per SERVOPACK	Current Capacity		Inrush Current	
						Control		
		SGD7S-	SGD7W-	[kVA]	Main Circuit [Arms]	Power Supply [Arms]	Main Circuit [A0-p]	Control Power Supply [A0-p]
Three phase, 400VAC	0.5	1R9D	-	1.1	1.4	1.2	19	
	1.0	3R5D	-	2.3	2.9			
	1.5	5R4D	-	3.5	4.3			
	2.0	8R4D	-	4.5	5.8		38	
	3.0	120D	-	7.1	8.6			
	5.0	170D	-	11.7	14.5			
	6.0	210D	-	12.4	17.4	1.4 1.7	68	
	7.5	260D	-	14.4	21.7			
	11.0	280D	-	21.9	31.8			
	15.0	370D	-	30.6	43.4			
	2 x 0.75	-	2R6D	3.5	4.4	1.2	19	
	2 x 1.5	-	5R4D	6.8	8.6		38	

Periphery

Sigma-7 Amplifier Connectors

SERVOPACK Model	Description	Order No.	Specification
	Development (ON1404)	JUSP-7CN101* (SGD7S-1R9D to -170D)	
	Power Input connector (CN101)	JUSP-7CN101-1* (SGD7S-210D to -370D)	
		JUSP-7CN103 (SGD7S-1R9D to -170D)	
	Power DC Input connector (CN103)	JUSP-7CN103-1 (SGD7S-210D to -370D)	
	Motor power connector (CN102)	JUSP-7CN102* (SGD7S-1R9D to -170D)	
	Motor power connector (CN102)	JUSP-7CN102-1* (SGD7S-210D to -370D)	
	24VDC Input connector (CN201)	JUSP-7CN201*	
All Models	DB Resistor connector for external DB (CN115)	JUSP-7CN115*	
	Brake power connector (CN117)	JUSP-7CN117*	
	I/O connector (CN1)	JUSP-7CN001	
	Enclosed Safety Jumper Connector (CN8)	JZSP-CVH05-E*	= = = = <u>=</u>

* Connectors are included by ordering YASKAWA SERVOPACKs. The other connectors can be ordered separately if necessary.

SERVOPACK Main Circuit Wires

This section describes the main circuit wires for SERVOPACKs.



These specifications are based on IEC/EN 61800-5-1, UL 61800-5-1, and CSA C22.2 No.14.

1. To comply with UL standards, use UL-compliant wires.

2. Use copper wires with a rated temperature of 75° or higher.

3. Use copper wires with a rated withstand voltage of 300 V or higher.

Note:

To use 600-V heat-resistant polyvinyl chloride-insulated wire (HIV), use the following table as reference for the applicable wires.
 The specified wire sizes are for three bundled leads when the rated current is applied with a surrounding air temperature of 40°C.

Select the wires according to the ambient temperature.

Three Phase, 400 V Wires for SGD7S SERVOPACKs

	Terminal					SERVO	PACK Model	SGD7S-			
Cables	Symbol	1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Main Circuit Power Cable	L1, L2, L3	AWG	16 (or 1.5	mm²)	AWG 14 (c	or 2.5 mm²)	AWG (or 4.0		AWG 10 (or 6.0 mm²)	AW (or 10	
Servomotor Main Circuit Cable	U, V, W	AWG	16 (or 1.5	mm²)	AWG 14 (c	or 2.5 mm²)	AWG 12 (or 4.0 mm ²)		G 10 0 mm²)	AW (or 10	
Control Power Cable	24V, 0V					AV	VG 16 (or 1.5 m	m²)			
External Regenerative Resistor Cable	B1/ ⊕,B2		AV	VG 16 (or	1.5 mm²)		AWG 14 (or 2.5 mm²)		G 12 0mm²)	AWG 10 (or 6.0 mm²)	AWG 8 (or 10 mm ²)
Ground Cable		AWG	16 (or 1.5	mm²)	AWG 14 (c	or 2.5 mm²)	AWG (or 4.0		AWG 10 (or 6.0 mm ²)	AW((or 10	

Three Phase, 400 V Wires for SGD7W SERVOPACKs

		SERVOPACK N	Iodel SGD7W-
Cables	Terminal Symbol	2R6D	5R4D
Main Circuit Power Cable	L1, L2, L3	AWG 14 (c	r 2.5 mm²)
Servomotor Main Circuit Cable	U, V, W	AWG 16 (c	r 1.5 mm²)
Control Power Cable	24V, 0V	AWG 16 (c	r 1.5 mm²)
External Regenerative Resistor Cable	B1/ ⊕,B2	AWG 16 (c	r 1.5 mm²)
Ground Cable		AWG 14 (o	r 2.5 mm²)

Wire Types

The following table shows the wire sizes and allowable currents for three bundled leads.

HIV Specification	IS*	Allowable Cu	rrent at Ambient Tempe	ratures [Arms]
Nominal Cross-selectional Area [mm ²]	Configuration [Wires/mm ²]	30°C	40°C	50°C
0.9	37/0.18	15	13	11
1.25	50/0.18	16	14	12
2.0	7/0.6	23	20	17
3.5	7/0.8	32	28	24
5.5	7/1.0	42	37	31
8.0	7/1.2	52	46	39
14.0	7/1.6	75	67	56
22.0	7/2.0	98	87	73

* This is reference data based on JIS C3317 600-V-grade heat-resistant polyvinyl chloride-insulated wires (HIV).

Surge Absorbers for Holding Brakes (Varistors) and Diodes

Surge Absorbers for Holding Brakes (Varistors)

Select an appropriate Surge Absorber for the power supply voltage and current of the brake. Surge absorbers are not provided by YASKAWA.

Brake Power Supply Vol	tage	24 VDC	
Surge Absorber Manufac	turer	Nippon Chemi-Con Corporation	SEMITEC Corporation
	1 A max.	TNR5V121K	Z5D121
Dual va Data d Orimmant	2 A max.	TNR7V121K	Z7D121
Brake Rated Current	4 A max.	TNR10V121K	Z10D121
	8 A max.	TNR14V121K	Z15D121

Regenerative Resistors

Types of Regenerative Resistors

The following regenerative resistors can be used:

• Built-in regenerative resistors: Some models of SERVOPACKs have regenerative resistors built into them.

• External regenerative resistors: These resistors are used when the internal capacitor and built-in regenerative resistor in the SERVOPACK cannot consume all of the regenerative power.

Use Yaskawa's SigmaSize+, an AC Servo drive capacity selection program, to determine if a regenerative resisitor is required.

Note: If you use an external regenerative resistor, you must change the setting parameter Pn600.

Built-In Regenerative Resistor

The following table gives the specifications of the built-in regenerative resistors in the SERVOPACKs and the amount of regenerative power (average values) that they can process. A built-in regenerative resistor is provided as a standard feature. Install an external regenerative resistor when the built-in regenerative resistor cannot process all the regenerative power.

SERVOPA	ACK Model	Bu	uilt-In Regenerative	Resistor
SGD7S-	SGD7W-	Resistance [Ω]	Capacity [W]	Minimum Allowable Resistance [Ω]
1R9D, 3R5D	-	75	70	75
5R4D	-	70	140	70
8R4D, 120D	-	43	140	43
170D	-	27	180	27
-	2R6D	43	140	49
-	5R4D	43	140	43

External Regenerative Resistor

SE	RVOPACK Specifi	cation		Resistor Specif	ication	
SERV	OPACK	Minimum Allo- wable External Resis- tance [Ω]	Model Resistor	Resistance [Ω]	Power [W]	Manufacturer
	1R9D					
	3R5D	75	RH-0520W120-UL-T	120	520	
	5R4D					
	8R4D	43	RH-0400W045-UL-T	45		
SGD7S-	120D	43	RH-04000045-0L-1	40	400	
00070	170D	27	RH-0400W032-UL-T	32		Heine
	210D	18				T IOI IO
	260D	10	RH-4800W022-10-UL-T	22	1,000	
	280D	14.25	1111-40000022-10-UL-1	22	1,000	
	370D	14.20				
SGD7W-	2R6D	43	RH-0400W045-UL-T	45	400	
5GD7 W-	5R4D	40	NI 1-040070040-0L-1	40	400	

Periphery

SEF	VOPACK Specifi	cation		Resistor Spec	ification	
SERVC	DPACK	Minimum Allo- wable External Resis- tance [Ω]	Model Resistor	Resistance [Ω]	Power [W]	Manufacturer
	1R9D	20	-	-	-	-
	3R5D	7.5	-	-	-	-
	5R4D	C. 1	-	-	-	-
	8R4D	7.8	-	-	-	-
SGD7S-	120D	4	-	-	-	-
Gabro	170D	3.3	-	-	-	-
	210D					
	260D		No integrated	l Dynamic Brake ci	rouit	
	280D		NO Integrated		iouit.	
	370D					
SGD7W-	2R6D	7.5	-	-	-	-
000700-	5R4D	1.0	-	-	-	-

Note:

Contact your YASKAWA representative for information on Sigma-7 400V Dynamic Brake Resistors.

Calculate the energy that must be consumed by the resistance for one dynamic brake stop. To simplify the energy consumption calculation, assume that all the kinetic energy until the Servomotor stops is consumed by the dynamic brake resistor and use the following formula. Out of all possible operation patterns, use the one which maximizes the kinetic energy of the Servomotor.

Rotary Servomotors

Energy consumption of the dynamic brake resistor: $E_{_{DB}}$ [J] Motor moment of inertia*: $J_{_{M}}$ [kgm2] Load inertia: $J_{_{L}}$ [kgm2] Motor speed just before stopping with the dynamic brake: N [min-1] * For detailed information on the motor moment of inertia, refer to the catalog or Servomotor product manual.

Linear Servomotors

Energy consumption of the dynamic brake resistor: $\mathsf{E}_{_{\mathsf{DB}}}\left[J\right]$ Moving Coil mass*: m_{_{M}}\left[kg\right] Load mass: m_{_{L}}\left[kg\right] Motor speed just before stopping with the dynamic brake: v [m/s]

* For detailed information on Moving Coil mass, refer to the catalog or Servomotor product manual.

 $E_{DB} = \frac{1}{2} \times (J_M + J_L) \times \left(\frac{2\pi}{60} \times N\right)^2$

 $E_{DB} = \frac{1}{2} \times (m_M + m_L) \times v^2$

Appendix

Option Modules

Linear Motors

SERVOPACKs

Batteries for Servomotors with Absolute Encoders


If you use an absolute encoder, you can use an Encoder Cable with a Battery Case connected to it to supply power and retain the absolute position data. You can also retain the absolute position data by supplying power from a battery on the host controller. The Battery Case is sold as a replacement part for the Battery Case that is included with an Absolute Encoder Cable.

Name	Order Number	Remarks
Battery case (case only)	JUSP-BA01-E	The Encoder Cable and Battery are not included. (This is a replacement part for a damaged Battery Case.)
Lithium Battery	JZSP-BA01	This is a special battery that mounts into the Battery Case.




1. You cannot attach the Battery Case to an Incremental Encoder Cable.

2. Install the Battery Case where the ambient temperature is between -5°C and 60°C.



• Mounting a Battery in the Battery Case


Obtain a Lithium Battery (JZSP-BA01) and mount it in the Battery Case.



ER3V (3.6 V, 1000 mAh) from Toshiba Battery Co., Ltd.

• Connecting a Battery to the Host Controller

Use a battery that meets the specifications of the host controller. Use an ER6VC3N Battery (3.6 V, 2,000 mAh) from Toshiba Battery Co., Ltd. or an equivalent battery.



Periphery

Software

SigmaSize+: AC Servo Capacity Selection Program

You can use the SigmaSize+ to select Servomotors and SERVOPACKs. There are two versions of the software: A Web-based version and a stand-alone version. The software supports all standard servo products sold by Yaskawa.

Features •


- Provides a vast amount of new product information.
- · Lets you select servo products with a wizard.
- As long as you have a connection to the Internet, you can access and use the software
- anytime, anywhere. (Communications are encrypted for security)
- You can access and reuse previously entered data.

Examples of the Servo Selection Interface

Mechanism Selection View



Speed Diagram Entry View



Servomotor Selection View

1	19.00	(). 100010000	÷.,	-			-
50	States and	1.001-001	11000	140.00	1011-001	100-00	Parmate:
	TORN STAT	11004-001	17404-001	1100+102	(4106-01)	100440	Same
	Distances and the	(1994)	100+00	(100+100	(TIMOT	(Income)	TTOL AND
0	10004404	1106-01	105-00	100+000	1124-001	100440	1000000
301	20012044	1004407	(1554-00)	(100+02)	12708-001	(STREET	12736-007
3)1	DORV STOR	(100MIN)	100400	120+02	1208-022	100400	Contractory of
1	30400-704-8	(HEN-DE	(7999-100)	(186+100	(1)89-182	(STATE)	
5	Setor Revel	1000-001	(368-66)	100+00	WHITE	(Allowing)	Contraction in the local division in the loc
	BURGE SAME	1 (1986)-991	(11100-001)	1100-00	(1Minute)	100-96	(Tablaty
81	-	(100-01)	(1996-001)	(100wiger)	(170-00)	(1014-08	
		00 90	4	1	-)	Salary.

System Requirements

Item	System Requirement
Browser (Required for web-based version only)	Internet Explorer 5.0 SP1 or higher
OS	Windows XP, Windows Vista, or Windows 7 (32-bit or 64-bit edition)
CPU	Pentium 200 MHz min.
Memory	64 MB min. (96 MB or greater recommended)
Available Hard Disk Space	20 MB min.

Machine Specification Entry View



Operating Conditions Selection View

Annes	
ALL IN THE SECTION	
A REAL PROPERTY AND	

SERVOPACK Selection View

	(mai)	-	10000		0	factorial room
Ο.	STON-STREET A	1284-101	105-02	110-02		Caureal.
	NEW-SEATIA	(1106-001))	C LEWIS COT	1110-40		and the second second
						North State

SigmaWin+ Version 7: AC Servo Drive Engineering Tool

The SigmaWin+ Engineering Tool is used to set up and optimally tune Yaskawa Sigma-series Servo Drives.

Features

- Set parameters with a wizard.
- Display SERVOPACK data on a computer just like you would on an oscilloscope.
- Estimate moments of inertia and measure vibration frequencies.
- Display alarms and alarm diagnostics.

• Examples of the Interface


Setting Parameters with a Wizard

(reaction of the second	1.
Contraction on	
· ····	I Server Server - Content Server
120	Automatical and a second second
R Landson	Report Ball (Sector International Control of the Sector Se
A	Anneal and an anneal and a state
	Information of the second state of the second state of the second state
	Municipality .
A Construction	Schedular in an entropy of a set of the set of the
	Anna tautana tauta
A restaurance	A second se
	Attactor
	200
2 million	Not below and all all all all all all all all all al

Estimating Moments of Inertia and Measuring Vibration Frequencies

New orientiany solarshe from Constit	
Next control for the second se	Name Hann Selfer of Hann S Andreak Hann Hangeboor service Andreak State (State State

Displaying SERVOPACK Data on a Computer Just Like You Would on a Oscilloscope



Displaying Alarms and Alarm Diagnostics

-		Testani (m. 7	
Charleson San	and the local		las fa
(The second second			• ** Mas
Contraction of the local division of the			
ALL OF TAXABLE PARTY.			
NAME ADDRESS OF	10.10		
The other series	. 21		
And the proper printing of	1.2		
O hanna anta			

• System Requirements

Item	System Requirement
Supported Languages	English and Japanese
OS	Windows XP, Windows Vista, or Windows 7 (32-bit or 64-bit edition)
CPU	Pentium 200 MHz min.
Memory	64 MB min. (96 MB or greater recommended)
Available Hard Disk Space	For Standard Setup: 350 MB min. (400 MB or greater recommended for installation)

Content - Appendix

Appendix

Capacity Selection for Servomotors	154
Capacity Selection for Regenerative Resistors	161
International Standards	162
Warranty	163


Selecting the Servomotor Capacity

Use Yaskawa's SigmaSize+, an AC servo drive capacity selection program, to select Servomotor capacity. With the SigmaSize+, you can find the optimum Servomotor capacity by simply selecting and entering information according to instructions from a wizard.

If you select a Servomotor capacity with a formula, refer to the following selecation examples.

Capacity Selection Example for a Rotary Servomotor: For Speed Control


1. Mechanical Specifications



Item	Code	Value
Load Speed	v_L	15 m/min
Linear Motion Section Mass	т	250 kg
Ball Screw Length	ℓ_B	1.0 m
Ball Screw Diameter	d _B	0.02 m
Ball Screw Lead	P_B	0.01 m
Ball Screw Material Density	ρ	7.87 x 10 ³ kg/m ³
Gear Ratio	R	2 (gear ratio: 1/2)
External Force on Linear Motion Section	F	0 N

Item	Code	Value
Gear and Coupling Moment of Inertia	J_G	0.40 × 10 ⁻⁴ kg⋅m ²
Number of Feeding Operations	n	40 rotations/min
Feeding Distance	l	0.275 m
Feeding Time	tm	1.2 s max.
Friction Coefficient	μ	0.2
Mechanical Efficiency	η	0.9 (90%)

2. Speed Diagram



3. Motor Speed

☑ Load shaft speed	$n_L = \frac{v_L}{P_B} = \frac{15}{0.01} = 1,500 \text{ (min}^{-1}\text{)}$
Motor shaft speed	$n_M = n_L \cdot R = 1,500 \times 2 = 3,000 \text{ (min}^{-1}\text{)}$

4. Load Torque

$$T_{L} = \frac{(9.8 \cdot \mu \cdot m + F) \cdot P_{B}}{2\pi R \cdot \eta} = \frac{(9.8 \times 0.2 \times 250 + 0) \times 0.01}{2\pi \times 2 \times 0.9} = 0.43 \text{ (N·m)}$$

YASKAWA SIGMA-7 | CATALOG

Contents

5. Load Moment of Inertia

☑ Linear motion section

$$J_{L1} = m \left(\frac{P_B}{2\pi R}\right)^2 = 250 \times \left(\frac{0.01}{2\pi \times 2}\right)^2 = 1.58 \times 10^{-4} \text{ (kg·m}^2\text{)}$$

Ball screw

$$J_B = \frac{\pi}{32} \rho \cdot \ell_B \cdot d_B^4 \cdot \frac{1}{R^2} = \frac{\pi}{32} \times 7.87 \times 10^3 \times 1.0 \times (0.02)^4 \cdot \frac{1}{2^2} = 0.31 \times 10^{-4} \text{ (kg·m^2)}$$

 \square Coupling $J_G = 0.40 \times 10^{-4}$ (kg \square m²)

 $\ensuremath{\boxtimes}$ Load moment of inertia at motor shaft

$$J_L = J_{L1} + J_B + J_G = (1.58 + 0.31 + 0.40) \times 10^{-4} = 2.29 \times 10^{-4} (\text{kg} \cdot \text{m}^2)$$

6. Load Moving Power

$$P_{O} = \frac{2\pi n_{M} \cdot T_{L}}{60} = \frac{2\pi \times 3,000 \times 0.43}{60} = 135 \text{ (W)}$$

7. Load Acceleration Power

$$Pa = \left(\frac{2\pi}{60} n_{M}\right)^{2} \frac{J_{L}}{ta} = \left(\frac{2\pi}{60} \times 3,000\right)^{2} \times \frac{2.29 \times 10^{-4}}{0.1} = 226 \text{ (W)}$$

8. Servomotor Provisional Selection

① Selection Conditions

 $\boxtimes T_L \leq Motor rated torque$

$$\boxtimes \frac{(Po + Pa)}{2}$$
 < Provisionally selected Servomotor rated output < (Po + Pa)

 $\boxtimes n_M \leq \text{Rated motor speed}$

 $\boxtimes J_L \leq$ Allowable load moment of inertia

The following Servomotor meets the selection conditions. ☑ SGM7J-02A Servomotor

2 Specifications of the Provisionally Selected Servomotor

Item	Value
Rated Output	200 (W)
Rated Motor Speed	3,000 (min ⁻¹)
Rated Torque	0.637 (N·m)
Instantaneous Maximum Torque	2.23 (N·m)
Motor Moment of Inertia	0.263 × 10 ⁻⁴ (kg⋅m ²)
Allowable Load Moment of Inertia	$0.263 \times 10^{-4} \times 15 = 3.94 \times 10^{-4} (\text{kg} \cdot \text{m}^2)$

9. Verification of the Provisionally Selected Servomotor

 $\ensuremath{\boxtimes}$ Verification of required acceleration torque:

$$T_P = \frac{2\pi n_M (J_M + J_L)}{60ta} + T_L = \frac{2\pi \times 3,000 \times (0.263 + 2.29) \times 10^{-4}}{60 \times 0.1} + 0.43$$

≈ 1.23 (N·m) < Maximum instantaneous torque...Satisfactory

☑ Verification of required deceleration torque:

$$T_{S} = \frac{2\pi n_{M} (J_{M} + J_{L})}{60td} - T_{L} = \frac{2\pi \times 3,000 \times (0.263 + 2.29) \times 10^{-4}}{60 \times 0.1} - 0.43$$

 \approx 0.37 (N·m) < Maximum instantaneous torque...Satisfactory


☑ Verification of effective torque value:

$$Trms = \sqrt{\frac{T_P^2 \cdot ta + T_L^2 \cdot tc + Ts^2 \cdot td}{t}} = \sqrt{\frac{(1.23)^2 \times 0.1 + (0.43)^2 \times 1.0 + (0.37)^2 \times 0.1}{1.5}}$$

≈ 0.483 (N·m) < Rated torque...Satisfactory


10.Result

It has been verified that the provisionally selected Servomotor is applicable. The torque diagram is shown below.



Capacity Selection Example for a Rotary Servomotor: For Position Control


1. Mechanical Specifications



Item	Code	Value
Load Speed	v_L	15 m/min
Linear Motion Section Mass	т	80 kg
Ball Screw Length	ℓ_B	0.8 m
Ball Screw Diameter	d _B	0.016 m
Ball Screw Lead	P _B	0.005 m
Ball Screw Material Density	ρ	$7.87 \times 10^3 \text{ kg/m}^3$
External Force on Linear Motion Section	F	0 N
Coupling Mass	m _C	0.3 kg

Item	Code	Value
Coupling Outer Diameter	d _C	0.03 m
Number of Feeding Operations	n	40 rotation/min
Feeding Distance	l	0.25 m
Feeding Time	tm	1.2 s max.
Electrical Stopping Precision	δ	±0.01 mm
Friction Coefficient	μ	0.2
Mechanical Efficiency	η	0.9 (90%)

2. Speed Diagram



$$t = \frac{60}{n} = \frac{60}{40} = 1.5 \text{ (s)}$$

If ta = td and ts = 0.1 (s),
$$ta = tm - ts - \frac{60\ell}{\nu_L} = 1.2 - 0.1 - \frac{60 \times 0.25}{15} = 0.1 \text{ (s)}$$
$$tc = 1.2 - 0.1 - 0.1 \times 2 = 0.9 \text{ (s)}$$

156 YASKAWA SIGMA-7 | CATALOG

Contents

3. Motor Speed

Load shaft speed

$$n_L = \frac{0_L}{P_B} = \frac{15}{0.005} = 3,000 \text{ (min}^{-1})$$

Motor shaft speed

Direct coupling gear ratio
$$1/R = 1/1$$

Therefore, $n_M = n_L \boxtimes R = 3,000 \times 1 = 3,000 \text{ (min}^{-1)}$

4. Load Torque

 $T_L = \frac{(9.8 \ \mu \cdot m + F) \cdot P_B}{2\pi R \cdot \eta} = \frac{(9.8 \times 0.2 \times 80 + 0) \times 0.005}{2\pi \times 1 \times 0.9} = 0.139 \text{ (N-m)}$

5. Load Moment of Inertia

☑ Linear motion section

$$J_{L1} = m \left(\frac{P_B}{2\pi R}\right)^2 = 80 \times \left(\frac{0.005}{2\pi \times 1}\right)^2 = 0.507 \times 10^{-4} \text{ (kg·m}^2\text{)}$$

 $\boxtimes \text{ Ball screw } J_B = \frac{\pi}{32} \ P \cdot \ell_B \cdot d_B^4 = \frac{\pi}{32} \times 7.87 \times 10^3 \times 0.8 \times (0.016)^4 = 0.405 \times 10^{-4} \text{ (kg·m^2)}$ $\boxtimes \text{ Coupling } J_C = \frac{1}{8} \ m_C \cdot d_C^2 = \frac{1}{8} \times 0.3 \times (0.03)^2 = 0.338 \times 10^{-4} \text{ (kg·m^2)}$

Icoad moment of inertia at motor shaft

$$J_L = J_{L1} + J_B + J_C = 1.25 \times 10^{-4} (\text{kg} \cdot \text{m}^2)$$

6. Load Moving Power

$$P_{O} = \frac{2\pi n_{M} \cdot T_{L}}{60} = \frac{2\pi \times 3,000 \times 0.139}{60} = 43.7 \text{ (W)}$$

7. Load Acceleration Power

$$Pa = \left(\frac{2\pi}{60} n_M\right)^2 \frac{J_L}{ta} = \left(\frac{2\pi}{60} \times 3,000\right)^2 \times \frac{1.25 \times 10^{-4}}{0.1} = 123.4 \text{ (W)}$$

8. Servomotor Provisional Selection

① Selection Conditions

 ∇

 $\boxtimes T_{L} \leq Motor rated torque$

$$\boxed{\frac{(PO + Pa)}{2}} < \text{Provisionally selected Servomotor rated output} < (PO + Pa)$$

 $\boxtimes n_M \leq \text{Rated motor speed}$

 $\boxtimes J_L \leq$ Allowable load moment of inertia

The following Servomotor meets the selection conditions. ☑ SGM7J-01A Servomotor

© Specifications of the Provisionally Selected Servomotor

Item	Value		
Rated Output	200 (W)		
Rated Motor Speed	3,000 (min ⁻¹)		
Rated Torque	0.318 (N·m)		
Instantaneous Maximum Torque	1.11 (N·m)		
Motor Moment of Inertia	0.0659 × 10 ⁻⁴ (kg·m ²)		
Allowable Load Moment of Inertia	$0.0659 \times 10^{-4} \times 35 = 2.31 \times 10^{-4} \text{ (kg·m}^2\text{)}$		
Encoder Resolution	24 bits (16,777,216 pulses/rev)		

9. Verification of the Provisionally Selected Servomotor

☑ Verification of required acceleration torque:

$$T_P = \frac{2\pi n_M (J_M + J_L)}{60ta} + T_L = \frac{2\pi \times 3,000 \times (0.0659 + 1.25) \times 10^{-4}}{60 \times 0.1} + 0.139$$

≈ 0.552 (N·m) < Maximum instantaneous torque...Satisfactory

☑ Verification of required deceleration torque:

$$T_{S} = \frac{2\pi n_{M} (J_{M} + J_{L})}{60td} - T_{L} = \frac{2\pi \times 3,000 \times (0.0659 + 1.25) \times 10^{-4}}{60 \times 0.1} - 0.139$$

≈ 0.274 (N·m) < Maximum instantaneous torque...Satisfactory

☑ Verification of effective torque value:

$$Trms = \sqrt{\frac{T_P^2 \cdot ta + T_L^2 \cdot tc + Ts^2 \cdot td}{t}} = \sqrt{\frac{(0.552)^2 \times 0.1 + (0.139)^2 \times 0.9 + (0.274)^2 \times 0.1}{1.5}}$$

≈ 0.192 (N·m) < Rated torque...Satisfactory

It has been verified that the provisionally selected Servomotor is applicable in terms of capacity. Position control is considered next.

10. Position Detection Resolution

Position detection unit: $\Delta^{\ell} = 0.01 \text{ mm/pulse}$ The number of pulses per motor rotation must be less than the encoder resolution (pulses/rev).

The number of pulses per revolution (pulses) = $\frac{P_B}{\Delta^{\ell}} = \frac{5 \text{ mm}}{0.01 \text{ mm}} = 500 < \text{Encoder resolution [16777216 (pulses/rev)]}$

11. Reference Pulse Frequency

 $vs = \frac{1,000 \,^{\text{o}}L}{60 \times \Delta \iota} = \frac{1,000 \times 15}{60 \times 0.01} = 25,000 \text{ (pps)}$


Confirm that the maximum input pulse frequency[™] is greater than the reference pulse frequency. ØRefer to the specifications in the SERVOPACK manual for the maximum input pulse frequency.

It has been verified that the provisionally selected Servomotor is applicable for position control.

8. Result


It has been verified that the provisionally selected Servomotor is applicable. The torque diagram is shown below.

Torque (NMn)



Servomotor Capacity Selection Example for Linear Servomotors


1. Mechanical Specifications



Item	Code	Value	
Load Mass	m_W	1 kg	
Table Mass	m_T	2 kg	
Motor Speed	V	2 m/s	
Feeding Distance	1	0.76 m	
Friction Coefficient	μ	0.2	

Item	Code	Value
Acceleration Time	t _a	0.02 s
Constant-speed Time	t _c	0.36 s
Deceleration Time	t _d	0.02 s
Cycle Time	t	0.5 s
External Force on Linear Motion Section	F	0 N

2. Operation Pattern



- **3.** Steady-State Force (Excluding Servomotor Moving Coil) $F_L = \{9.8 \times \mu \times (m_W + m_T)\} + F = 9.8 \times 0.2 \times (1 + 2) + 0 = 5.88 \text{ (N)}$
- 4. Acceleration Force (Excluding Servomotor Moving Coil)

$$F_P = (m_W + m_T) \times \frac{v}{t_a} + F_L = (1 + 2) \times \frac{2}{0.02} + 5.88 = 305.88$$
 (N)

- 5. Provisional Selection of Linear Servomotor
 - **①** Selection Conditions

 $\boxtimes F_P \leq Maximum \text{ force } \times 0.9$

 $\boxtimes F_s \leq Maximum \text{ force } \times 0.9$

 $\boxtimes F_{rms} \leq \text{Rated force} \times 0.9$

Contents

2 Specifications of the Provisionally Selected Servomotor

Item	Value		
Maximum Force	440 (N)		
Rated Force	147 (N)		
Moving Coil Mass (m _M)	0.82 (kg)		
Servomotor Magnetic Attraction (F _{att})	0 (N)		

 $F_L = \mu \{9.8 \times (m_W + m_T + m_M) + F_{att}\} = 0.2 \{9.8 \times (1 + 2 + 0.82) + 0\} = 7.5 (N)$ \Big Verification of Acceleration Force

$$F_P = (m_W + m_T + m_M) \times \frac{v}{t_a} + F_L = (1 + 2 + 0.82) \times \frac{2}{0.02} + 7.5$$

= 389.5 (N) \leq Maximum force x 0.9 (= 396 N)... Satisfactory

☑ Verification of Deceleration Force

$$F_S = (m_W + m_T + m_M) \times \frac{v}{t_a} - F_L = (1 + 2 + 0.82) \times \frac{2}{0.02} - 7.5$$

= 374.5 (N) \leq Maximum force \times 0.9 (= 396 N)... Satisfactory

☑ Verification of Effective Force

$$F_{rms} = \sqrt{\frac{F_P^2 \cdot t_a + F_L^2 \cdot t_c + F_s^2 \cdot t_d}{t}} = \sqrt{\frac{389.5^2 \times 0.02 + 7.5^2 \times 0.36 + 374.5^2 \times 0.02}{0.5}}$$

= 108.3 (N) \leq Rated force x 0.9 (= 132.3 N)... Satisfactory

7. Result


It has been verified that the provisionally selected Servomotor is applicable.

161

Capacity Selection for Regenerative Resistors

Calculating the Regenerative Energy

This section shows how to calculate the regenerative resistor capacity for the acceleration/deceleration operation shown in the following figure.



In Calculation Procedure for Regenerative Resistor Capacity

Step	Item	Code	Formula
1	Calculate the rotational energy of the Servo- motor.	E _S	$E_S = Jn_M^2 / 182$
2	Calculate the energy consumed by load loss during the deceleration period	EL	$E_L = (\pi/60) n_M T_L t_D$ Note: If the load loss is unknown, calculate the value with E_L set to 0.
3	Calculate the energy lost from Servomotor winding resistance.	E _M	(Value calculated from the graphs in \blacklozenge Servo- motor Winding Resistance Loss on page 271) $\times t_D$
4	Calculate the energy that can be absorbed by the SERVOPACK.	E _C	Calculate from the graphs in ◆ SERVOPACK- absorbable Energy on page 270
5	Calculate the energy consumed by the regenerative resistor.	E _K	$E_{K} = E_{S} - (E_{L} + E_{M} + E_{C})$ $E_{K} = E_{S} - (E_{L} + E_{M} + E_{C}) + E_{G} \boxtimes$ Note: Use this formula if there will be con- tinuous periods of regenerative oper- ation, such as for a vertical axis.
6	Calculate the required regenerative resistor capacity (W).	W _K	$W_{\mathcal{K}} = E_{\mathcal{K}}/(0.2 \times \mathrm{T})$

 $\boxtimes E_G$ (joules): Energy for continuous period of regenerative operation

 $E_G = (2\pi/60) \; n_{MG} T_G t_G$

 $\boxtimes \mathcal{T}_G \text{: Servomotor's generated torque in continuous period of regenerative operation (N \ensuremath{\underline{M}} n)$

 $\boxtimes n_{MG}$: Servomotor's motor speed for same operation period as above (min⁻¹)

 $\boxtimes t_G$: Same operation period as above (s)

Note: 1. The 0.2 in the equation for calculating W_K is the value when the regenerative resistor's utilized load ratio is 20%.

2. The units for the various symbols are given in the following table.

Code	Description	Code	Description
E_S to E_K	Energy in joules (J)	T_L	Load torque (NMm)
W _K	Required regenerative resistor capacity (W)	t _D	Deceleration stopping time (s)
J	$= J_M + J_L (\mathrm{kg} \cdot \mathrm{m}^2)$	Т	Servomotor repeat operation cycle (s)
n _M	Servomotor motor speed (min ⁻¹)		

If the value of W_K does not exceed the capacity of the built-in regenerative resistor of the SERVO-PACK, an External Regenerative Resistor is not required. For details on the built-in regenerative resisters, refer to the SERVOPACK specifications. If the value of W_K exceeds the capacity of the built-in regenerative resistor, install an External Regenerative Resistor with a capacity equal to the value for W calculated above. Appendix

Product Model		Model	UL/CSA Standards	CE Marking	KC Mark	RoHS Directive
SERVOPACKs		SGD7S	٠	٠	•	٠
		SGD7W	٠	٠	٠	٠
Safety Option	Safety Module	SGDV-OSA01A000FT900*1	٠	٠	٠	•

Product	Model	UL/CSA Standards	CE Marking	RoHS Directive
Rotary Servomotors	SGM7J	٠	٠	٠
	SGM7A	۰	۰	۰
	SGM7G	٠	٠	٠
Linear Servomotors	SGLFW2 (SGLFM2)*2	Scheduled for 2017	٠	٠

*1. Use this model number to purchase the Option Module separately.*2. The model numbers of the Magnetic Ways of Linear Servomotors are given in parentheses.



Details of Warranty

Warranty Period

The warranty period for a product that was purchased (hereinafter called the "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

Warranty Scope

YASKAWA shall replace or repair a defective product free of charge if a defect attributable to YASKAWA occurs during the above warranty period. This warranty does not cover defects caused by the delivered product reaching the end of its service life and r eplacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- Causes not attributable to the delivered product itself
- Modifications or repairs not performed by YASKAWA
- Use of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from YASKAWA
- Events for which YASKAWA is not responsible, such as natural or human-made disasters

Limitations of Liability

- YASKAWA shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- YASKAWA shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- YASKAWA shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the YASKAWA product is used in combination with any other products.
- The customer must confirm that the YASKAWA product is suitable for the systems, machines, and equipment used by the customer.
- Consult with YASKAWA to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
 - » Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
 - » Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
 - » Systems, machines, and equipment that may present a risk to life or property
 - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or
 - systems that operate continuously 24 hours a day
 - » Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the YASKAWA product is properly rated and installed
- The circuit examples and other application examples described in product catalogs and manuals are for
- reference. Check the functionality and safety of the actual devices and equipment to be used before using the product
 Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties

Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your YASKAWA representative to confirm the actual specifications before purchasing a product.



YASKAWA Europe GmbH Drives & Motion Division Hauptstr. 185 65760 Eschborn Germany

+49 6196 569-500 support@yaskawa.eu.com www.yaskawa.eu.com

Specifications are subject to change without notice for ongoing product modifications and improvements. © YASKAWA Europe GmbH. All rights reserved. 01/2018 | YEU_MuC_Sigma7_400V_Cat_EN_v6 YASKAWA